

INSTALLATION INSTRUCTIONS FOR INSTALLING THE SANITARY LIFT COVER KIT ON THE NATIONAL VENDORS®, CROWN SEVENTY TWO®, ECM-72 AND EPM-72, ELECTRIC CANDY MERCHANDISER

These instructions cover the procedure for installing the Sanitary Lift Cover Kit on the Crown Seventy Two, ECM-72 and EPM-72 Electric Candy Merchandiser.

Read these instructions carefully and thoroughly before installing the Kit. Retain these instructions for part number and installation information.

Kit, Part Number 130-2200, contains the following parts:

Part Number	Description	Quantity
130-2201	Sanitary Lift Cover	1
117-2136	Hanger	2
9900-174	No.8-32 x 5/16 RHS T/C Screw	2
117-2132	Right Hand Drill Template	1
117-2133	Left Hand Drill Template	1
130-2203	Installation Instructions	1
	* * *	

TO INSTALL THE KIT

1. Open the Cabinet Door.
2. Remove the four Screws which attach the Lower Trim beneath Lower Display Glass and remove the Lower Trim.

CAUTION

Remove only Lower Trim.

3. Lay the Lower Trim on a flat surface, front side up with the right end to your right. See Figure A-1.
4. Place the Right Hand Drill Template on the right end of the Trim. See Figure A-1.
5. Use a 9/64" Drill Bit to drill a hole through the Trim. The Hole in the Template is the pilot for the Drill Bit.
6. Place the Left Hand Drill Template on the left end of the Trim. See Figure A-1 and drill a 9/64" diameter hole through the left end of the Trim.
7. Place the Hangers on the Sanitary Lift Cover. The Flat side of the Hanger fits toward the top of the Cover. See Figure A-2.
8. Install the Lower Trim on the Cabinet Door and attach the Trim with the four Screws removed in Step 2.
9. Insert the Sanitary Lift Cover from the external side of the Cabinet Door and attach the Cover to the Lower Trim with the two No.8-32 x 5/16 Round Head Thread Cutting Screws. See Figure A-3.
10. Close the Cabinet Door. The Sanitary Lift Cover should fit smoothly over the Delivery Pan Casting and cover it completely.

