

**INSTRUCTIONS FOR INSTALLATION OF A GUM SPACER KIT TO UP-DATE THE
NATIONAL VENDORS[®], ECM-72 SERIES AND GOLDEN FURNITURE LINE
CANDY MERCHANDISERS**

The Gum Spacer Kit, part number 130-9093 consists of the following:

Part Number	Description	Quantity
130-9089	Gum Spacer	6
130-2197	Gum and Mint Unit Column Loading and Price Tagging Instructions - Label	1
130-2235	Candy Magazine Column Loading and Price Tagging Instructions - Label	1
130-9094	Installation Instructions * * *	1

The purpose of this Kit is to make ECM-72 Candy Merchandisers capable of vending all available sizes of Gum and Mint packages.

To install the Up-Dating Kit part number 130-9093.

1. Unlock and open the Merchandiser Door.
2. Install the Gum and Mint Unit Column Loading and Price Tagging Instructions Label, (part number 130-2197), on the Delivery Mechanism Door Assembly. Carefully peel off the Label backing and apply the Label to the outside of the Delivery Mechanism Door Assembly. Center the Label on the Door horizontally about 3 inches down from the top of the Door. The newly installed label should be visible to the right of the Gum and Mint Columns with the Merchandiser Cabinet Door open, the Delivery Mechanism Door Assembly closed, and facing the Gum and Mint Columns.
3. Install the Candy Magazine Column Loading and Price Tagging Instructions Label, (part number 130-2235), on the inside of the Delivery Mechanism Door Assembly. Carefully peel off the Label backing and apply the Label approximately centered both vertically and horizontally over the Gum and Mint Unit and Candy Magazine Column Loading and Price Tagging Instruction Label already on the Door.
4. When loading the Merchandiser follow the instructions on the Loading Labels.
5. Store the unused Gum Spacers (130-9089); the unused Gum and Mint Adaptors (130-9065) and the unused small Mint Adaptor (130-9057) in the 5" x 7" Cloth Bag that came with the Merchandiser.
6. After loading the Merchandiser, rotate the Delivery Mechanism back into the Cabinet if it had been moved out for Candy Column loading, close the Delivery Mechanism Door Assembly if opened, and close and lock the Cabinet Door.
7. Test vend all Columns.