

**KIT PART NUMBER 1454026**

**INSTRUCTIONS FOR INSTALLING AN M-1 LOCK KIT ON A MAKA NB SERIES VALIDATOR**

**CHECK THE PARTS RECEIVED IN THE KIT WITH THE PARTS LIST IN THESE INSTRUCTIONS. IF ANY PARTS ARE MISSING, CONTACT NATIONAL VENDORS' PARTS DEPARTMENT IMMEDIATELY.**

Read these instructions carefully before installing the kit.  
Retain these instructions for part numbers and for future reference.

This kit contains the following:

PART NUMBER	DESCRIPTION	QUANTITY
1454045	Top Plate	1
1454044	Bottom Plate	1
1454046	Screw	1
1454047	Installation Instructions	1

1. Secure the Top Lock Plate to the upper stacker plate. The necessary mounting holes are already in the stacker plate.
2. Position the Bottom Lock Plate on the rear stacker plate so the large holes in the top and bottom lock plates line up.
3. Mark the mounting hole locations on the rear stacker plate using the bottom lock plate as a guide.
4. Center punch the two mounting hole locations.
5. Drill a clearance hole for the mounting screw at each of the center punched locations.
6. Secure the Bottom Lock Plate to the rear stacker plate.
7. Examine the stacker and validator carefully and remove all metal chips.

