

KIT PART NUMBER 4521019 (BAG ASSEMBLY - DUCT)

INSTRUCTIONS FOR INSTALLING THE CONDENSOR OUTLET DUCT

CHECK THE PARTS RECEIVED IN THE KIT WITH THE PARTS LIST IN THESE INSTRUCTIONS. IF ANY PARTS ARE MISSING, CONTACT THE NATIONAL VENDORS PARTS DEPARTMENT IMMEDIATELY.

Read these instructions carefully before installing the kit.
Keep these instructions for part numbers and for future reference.

This kit contains the following:

PART NUMBER	DESCRIPTION	QUANTITY
4521018	CONDENSER OUTLET DUCT	1
4741050	SCREW - 8-32 X .50 HEX HD - T/F	4
4520011	INSTALLATION INSTRUCTIONS	1

1. At the rear of the cabinet, remove the middle 4 screws holding the vent screen assembly. Discard the screws.
2. Hold the condenser outlet duct in place and install one of the top 2 screws (4741050).
3. Install the remaining 3 screws.

