



## KIT PART NUMBER 4747161

### INSTRUCTIONS FOR INSTALLING A RAIL EXTENSION KIT IN A COLD CAN MODULE

Read these instructions carefully before installing the kit.  
Keep these instructions for part numbers and for future reference.

Refer to figure 1.

1. Remove the bottom tray to gain access to the can module.
2. Remove the door from the cold can module.
3. Locate four rail extensions with **NO HOLES** drilled in their ends.

#### NOTE

For the next step, you will need to use a wood block with a hammer, or a plastic or wood mallet, or other suitable tool to avoid damaging the rail extension.

4. Slide each rail extension onto the top right rail where the cans are loaded. Using your tools, force the rail extension into the can module until the dimples in the rail extension lock into the holes in the rail.
5. Repeat steps 3 and 4 with the rail extensions having **3 HOLES** drilled in their ends, on the next set of rails down.

#### CAUTION

Take care to avoid damaging the wiring harnesses inside the can module during the next two steps.

6. Repeat steps 3 and 4 with the rail extensions having **2 HOLES** drilled in their ends, on the next set of rails down.
7. Repeat steps 3 and 4 with the rail extensions having **1 HOLE** drilled in their ends, on the next set of rails down.
8. Replace the can module door and the lower tray.

