KIT PART NUMBER 7800035 and 7800040 INSTRUCTIONS FOR INSTALLING BOTTLE/CAN TRAY KIT

CHECK THE PARTS RECEIVED IN THE KIT WITH THE PARTS LIST IN THESE INSTRUCTIONS. IF ANY PARTS ARE MISSING, CONTACT THE NATIONAL VENDORS PARTS DEPARTMENT IMMEDIATELY.

Read these instructions carefully before installing the kit. Keep these instructions for part numbers and for future reference.

THIS KIT CONTAINS THE FOLLOWING:

PART NUMBER	DESCRIPTION	QUANTITY
7800038	BOTTLE TRAY ASSY- 6CT (ONLY IN KIT 7800035)	1
7800039	BOTTLE TRAY ASSY- 7CT (ONLY IN KIT 7800040)	1
7800036	KIT INSTRUCTIONS BOTTLE/CAN TRAY	1

- 1. Turn power off from machine.
- 2. Remove snack or candy tray from machine. This is going to be the tray that you are going to replace.
- 3. Disconnect tray harness from tray board.
- 4. Remove both tray rails in machine. Be sure to save all screws and hardware.
- 5. Remove any tray shield and/or tray rail board from the right side tray rail.
- 6. Remove both rails from bottle tray. These rails should slide straight out. See figures below.

Note:

There is one safety catch on each rail. The right side catch needs to be pushed down and the left side catch needs to be pushed up.

- 7. Attach all hardware that was removed in step 4 to the right bottle tray rail.
- 8. Attach the bottle tray rails to the inside left and right side of the machine using the pre-existing screws that were removed in step 3. Depending on the product height you may wish to adjust the bottle tray rails up or down in the cabinet.
- 9. Attach the tray rail harness to the tray board on the bottle tray.
- 10. Slide the bottle tray onto the tray rails in the machine. It might be easier to push the rails in first and then align the tray on the rails.

11. Load bottle tray with product checking for proper clearance. You may need to adjust the bottle tray rails if product is too tall. Turn machines power on and check for proper operation.



