

FOAM TAPE INSTALLATION DELIVERY DOOR

M025.0

Order: 903,600,20x.x1 ½"x2" Foam Tape (44" to do 1 large port delivery door)

Installation Instructions:

1. Cut the foam tape in four 11" (279.4mm) pieces.
2. Place the foam tape on the ribbed side (to the front of the vender) of the delivery door, starting at the top and working your way to the bottom.
3. The last piece will have to be trimmed so it is not longer than the delivery door.

