

## M055.0 DN5000 Lock cover Installation

December 16, 2002

**Models Affected:** All DN5000 Venders

**Reason:** To provide additional security for the T-handle and lock cylinder.

**Order:** For Coke Glass Front Venders

1 – 626,054,70x.x4	DN5000 CGFV Lock Cover Kit – Red
Contents:	1 – 626,054,50x.x3 DN5000 CGFV Lock Cover Assy. – Red
	4 – 900,201,56x.x1 Carriage bolt ¼ - 20 X ¾
	4 – 900,800,67x.x1 Keps nut ¼ - 20

For Dasani Glass Front Venders

1 – 626,054,8x.x4	DN5000 DGFV Lock Cover Kit - Black
Contents:	1 – 626,054,60x.x3 DN5000 DGFV Lock Cover Assy. - Black
	4 – 900,201,56x.x1 Carriage bolt ¼ - 20 X ¾
	4 – 900,800,67x.x1 Keps nut ¼ - 20

### Installation instructions:

1. Unplug the vender.
2. Use the Lock Cover as a template.
3. Place the Lock Cover in position and mark the four (4) hole locations on the service door.
4. Remove the Lock Cover.
5. Drill four 5/16” holes in the locations marked in step 3.
6. Be sure to clean all metal filings from the vender after drilling.
7. Place the Lock Cover in position.
8. Install the carriage bolts provided in the kit, through the Lock Cover.
9. Secure in place with keps nuts provided.
10. Ensure the T-handle “Pops Out” freely. If not, loosen keps nuts and adjust Lock Cover.

