# SERVICE INFORMATION

### M131.1

MODELS AFFECTED: All CGFV Revised: November 22, 2013

MODEL NUMBERS: DN5000/3000

### **RE: Evaporator Fan Assembly Retrofit Kit**

Reason: New Evaporator Fan developed to replace Original Component

without the use of a choke.

Order: 62604360 CGFV Evaporator Fan Retro Fit Kit, Domestic only



Description	62604360 CGFV Evaporator Fan Retro Fit Kit, Domestic only	QTY
Evap Fan Assy.	CR0021837	1
Screw, #8-32	80030438	3
Perma-Gum Sealer, White	80360113	.06250 lb.
Installation Instructions	M131.x	1

#### <u>Tools Required:</u> Phillips Head Screwdriver

#### Evaporator Fan Kit Installation:

- 1. Remove power to the Vender.
- 2. Remove the Refrigeration System from the Vender.
- 3. Remove existing Evaporator Fan Assy and harness.
- 4. Place the Evaporator fan assembly CR0021837 in the evaporator shroud. Make sure the edge of the shroud and the straight edge of the fan assembly are parallel.





## SERVICE INFORMATION

- 5. Turn the Evaporator Fan Assembly so the holes in it line up with the holes in Evap Shroud.
- 6. Attach the Evaporator Fan Assembly to the evaporator shroud with the 3 screws (80030438) using the Phillips head screwdriver.
- 7. Thread the Evaporator Fan Harness through the hole in the Evaporator Drain Pan front as shown and plug the hole with white perma-gum 80360113.
- 8. Install the deck in the machine, secure, plug in, and test for proper operation.

