

SIID CONTROL BOX CURTAIN INSTALLATION

M0012.1

1. Unplug the vender.
2. Remove the SIID control box from the vender.
 - ◆ DeAmertek control boxes measure approximately 7" high x 8½" wide.
 - ◆ Ardac control boxes measure approximately 8" high x 8½" wide.
3. Wipe any excess oil or dirt from the back of the control box.
4. On the back of the Control Board measure 1½" down and draw a horizontal line across the board. See figure 2.
5. Cut a piece of two sided tape (part# 903,600,650.01) nine inches (9") long.
6. Place the tape on the back of the Control Board so the lower edge of it lines up with the line drawn in step 4.
7. The clear curtain measures 14½" high by 9" wide.
8. Align one end of the 9" side of the curtain with the two-sided tape installed on the back of the board. Center in position and rub to secure.
9. The curtain (801,903,380.01) goes over top and front of the SIID Control Board.
 - ◆ On DeAmertek Boards it will over hang approximately 3½". See figure 3.
 - ◆ On Ardac Boards it will over hang approximately 1¾".
10. To install in the vender, fold the excess at the top corners down. See figure 3.
11. Note: You may want to tape this to hold in place for ease of installation.
12. Place in position.
13. Lift the curtain and secure the SIID Control Box and ground wire with screws removed in step 2.
14. Plug in the vender and test for proper operation.




Figure 1




Figure 2




Figure 3