

INSTALLATION OF PEPSI/GENERIC ROUND HIGH SECURITY TOP HASP ASSEMBLY M037.2

Kit:	609,023,60x.x4	High Security Top Hasp Assembly
Parts Required:	1 - 801,305,95x.x1	Hinged Top Hasp Assembly, Cabinet
	1 - 592,051,36x.x3	Top Front Hasp, Door
	1 - 609,020,06x.x3	Top Hasp Plate, Cabinet
	1 - 592,010,08x.x3	Hasp Backing Plate, Cabinet
	1 - 609,050,54x.x3	Rain Guard, Wide High Security
	2 - 800,303,19x.x1	Bolt, Carriage, 1/4 - 20 x 5/8 Grade 5
	4 - 900,202,20X.X1	Bolt, Carriage, 1/4 - 20
	6 - 900,800,67x.x1	Nut, Keps, 1/4 - 20
	1 - M037.x	Installation Instructions

Tools Required:	7/16" socket	Ratchet for socket	Drill	5/16" drill bit
	Phillips screwdriver	Center punch	Hammer	

NOTE: PLEASE READ ALL INSTRUCTIONS THOROUGHLY PRIOR TO BEGINNING WORK. ALSO SEE TECHNICAL BULLETIN 513 FOR COMPLETE HIGH SECURITY KIT PARTS.

Instructions:

Note: Prior to installing the top hasp assembly, ensure that the high security (wide) vandal panel has been installed on the door.

1. Remove the original Rain Guard from the door and install the High Security Rain Guard. The notched out portion of the replacement should be over the coin insert side of the door. The Rain Guard should be sealed with silicon sealer to prevent moisture intrusion into the door.
2. Install the Top Front Hasp to the top of the door and secure with two carriage bolts on the vandal panel side of the door.
3. Using the installed Top Front Hasp as a template, mark the location for the remaining two holes in the front of the door.
4. Remove the Top Front Hasp.
5. Drill two 5/16" holes marked in step 3.
6. Reinstall the Top Front Hasp and secure with all four carriage bolts.
7. With the door closed, place the Hinged Top Hasp Assembly on the top of the cabinet so that the assembly is up against the side of the cabinet and the lock holes are aligned. Also, the hinged mounting plate should be under the Hinged Top Hasp Assembly.
8. Using the Hinged Top Hasp Assembly as a template, carefully mark the four holes on the top of the cabinet.
9. Remove the Hinged Top Hasp Assembly and drill four 5/16" holes in the locations marked in step 8. As the holes will need to be drilled completely through the cabinet, it is very important that they be drilled straight.
10. Place the Top Hasp Plate on the top of the cabinet with the 90° bend to the right side facing down, and aligned with the four holes drilled in step 9.
11. Place the Hinged Top Hasp Assembly (with the hinged mounting plate under the Hinged Top Hasp Assembly) on top of the Top Hasp Plate oriented as in step 7.
12. Insert four 1-3/4" carriage bolts through the Hinged Top Hasp Assembly, the Top Hasp Plate, and the cabinet.
13. Install the Hasp Backing Plate over the four carriage bolts inside the cabinet, and secure with nuts.

Hinged Top Hasp Assembly



Top Front Hasp ⇒

⇐ Top Hasp Plate