

Technical Bulletin

Bulletin Number: 371 Revision Number: R-03

Release Date: October 10, 1988 Revision Date: January 12, 2000

SUBJECT: INNER DOOR PATCH PLATE

MODELS AFFECTED: All Dixie-Narco Venders that have the T-Handle in the coin insert casting.

REASON: To provide a patch plate to cover the area, of the inner door, around the hole for the T-Handle stud.

NOTE: INSULATION IS NOT AVAILABLE FOR THIS PATCH PLATE INSTALLATION.

ORDER PARTS LISTED:

1	000,005,780.06	Front Patch
1	000,005,790.06	Rear Patch
32	901,100,530.01	Pop Rivet, 1/8" aluminum

Installation Instructions:

1. Remove the pull knob and snap bushings from the inner door.
2. Remove the sheet metal screws securing the inner door gasket in the area the patch is to be installed.
3. Place the rear patch in position under gasket as shown in illustration on page 2.
4. Using the patch as a template, drill sixteen (16) holes 9/64" in diameter.
5. Secure the patch in position with the pop rivets used in kit.
6. Install the front patch by repeating steps 2, 3 and 4.
7. Install the pull knob and snap bushings.
8. Install the sheet metal screws to secure the inner door gasket.

IMPORTANT: CONDENSATION MAY DEVELOPE IN THE AREA OF THE PATCH IF THE INNER DOOR INSULATION HAS BEEN REMOVED.

