

INSTRUCTIONS FOR INSTALLING A CONTROLLER UPGRADE KIT IN A SNACKTRON 1 OR
SNACKTRON 2

**CHECK THE PARTS RECEIVED IN THE KIT WITH THE PARTS LIST
IN THESE INSTRUCTIONS. IF ANY PARTS ARE MISSING,
CONTACT NATIONAL VENDORS' PARTS DEPARTMENT IMMEDIATELY.**

Read these instructions carefully before installing the kit.
Keep these instructions for part numbers and for future reference.

This kit contains the following:

INDEX	PART NUMBER	DESCRIPTION	QUANTITY
1	1451236	Label, Programming	1
2	1452218	Label, Coverup	1
3	1452219	Label, Coverup - 1	1
4	1450029	Programming Supplement	1
-	1450030	Installation Instructions	1
-	1451231	Controller Assembly	1

INSTALL THE CONTROLLER UPGRADE KIT AS FOLLOWS:

- UNPLUG THE MERCHANDISER BEFORE DOING ANYTHING ELSE!**
- Remove the existing controller assembly. Note all connections for ease of reassembly.
- Install the new controller assembly in place of the old one. All harnesses, mountings, connections, etc. are identical.
- Install the programming label (1) on the controller chassis cover.

Refer to Figure 1.

- Install coverup label (2) and coverup label (3) as shown.
- From the Snacktron Set-up instructions manual (part number 1450020), remove pages 2-3 through 2-8. Discard those pages.
- Install the Programming Supplement (4) into your Snacktron Set-up instructions manual.
- Plug in the merchandiser and turn on the power.
- Follow the programming steps outlined in the CONFIGURATION section of the programming supplement. This ensures the new controller is programmed correctly.




Figure 1. Coverup Label Installation Diagram