

P/N 1470051

INCORPORATE THIS SUPPLEMENT

IN

The 147/148 PROGRAMMING GUIDE

(Part Number 1470059 Rev. D)

**INSTRUCTIONS FOR INCORPORATING
THIS SUPPLEMENT
IN YOUR 147/148 - 474/475/476 - 461/462
PROGRAMMING GUIDE**

REMOVE THESE PAGES FROM YOUR GUIDE:

**REPLACE THEM WITH THESE PAGES FROM THE
SUPPLEMENT PACKAGE:**

1 and 2

1 and 2

3 and 4

3 and 4

27 and 28

27 and 28

49 and 50

49 and 50

55 and 56

55 and 56

THE PROCEDURES IN THIS PROGRAMMING GUIDE
ARE FOR USE WITH:

MODEL 147, 148, 461, 462, AND 474 SOFTWARE VERSION

RC3-9

MODEL 465 AND 476 MAIN CONTROLLER SOFTWARE VERSION

RC3-9

MODEL 475: FRESH BREW HOT DRINK MODULE SOFTWARE VERSION

503B0

MODEL 476: FREEZE DRY HOT DRINK MODULE SOFTWARE VERSION

503B0

Complete the Software Version retrieval procedure on page 94 of this PROGRAMMING GUIDE.

The version number/numbers in the display should be the same as the version number listed above.

If the version number in the display is **NOT** the same as the version number listed above, contact National Vendors' Service Department at 1-800-325-8811.

FUNCTION	IF YOU WANT TO...		COMPLETE THIS PROCEDURE	ON THIS PAGE	
CODE	Access functions/procedures reserved for the supervisor		P0-1	26	
	Print the data list or the price list		P0-2	27	
	Assign a new Master User Code		P0-3	29	
	Water Time		P0-4	30	
	Steep Time		P0-6	32	
	Air Compressor Time		P0-7	33	
PRICE	Price an individual selection		P1-1	35	
	Set a tray to one price		P1-2	36	
	Set entire machine to one price		P1-3	37	
	Check the price of an individual selection		P1-1	35	
DATA	COUNTS (Volume)	TOTAL VENDS	For the machine	P2-2	38
			For a tray	P2-2	38
			For a selection	P2-2	38
		FREE VENDS	For the machine	P2-3	39
			For a tray	P2-3	39
			For a selection	P2-3	39
		TEST VENDS	For the machine	P2-15	40
			For a tray	P2-15	40
			For a selection	P2-15	40
		WIN VENDS	For the machine	P2-17	41
			For a tray	P2-17	41
			For a selection	P2-17	41
		DISCOUNT VENDS	For the machine	P2-18	42
			For a tray	P2-18	42
			For a selection	P2-18	42
	SALES (Value)	TOTAL SALES	For the machine	P2-7	43
			For a tray	P2-7	43
			For a selection	P2-7	43
		FREE VEND SALES	For the machine	P2-8	44
			For a tray	P2-8	44
			For a selection	P2-8	44
		WIN SALES	For the machine	P2-19	45
			For a tray	P2-19	45
			For a selection	P2-19	45
		DISCOUNT SALES	For the machine	P2-20	46
			For a tray	P2-20	46
			For a selection	P2-20	46
	Validator stacker bill inventory			P2-13	47
	Cash Box inventory			P2-16	48
	Rinse Cycle count since category was last cleared			P2-21	49
	View the number of failure messages from the serial validator			P2-22	49
	FREE VEND	Put the merchandiser on free vend		P3-1	50
		Take merchandiser off free vend		P3-2	51

FUNCTION	IF YOU WANT TO...	COMPLETE THIS PROCEDURE	ON THIS PAGE	
CONFIGURE	Lock or unlock functions - MASTER USER ONLY	P4-000	52	
	Clear all resettable data (RAM Clear) - MASTER USER ONLY	P4-0000	54	
	Identify the type of coin mech being used	P4-1	56	
	Select language to be used in display messages	P4-2	57	
	Set the message scrolling speed	P4-3	58	
	Identify the trays being used	P4-4	59	
	Couple or uncouple two positions of a tray	P4-5	60	
	Define the bill validator being used	P4-6	61	
	Select denomination of bills to be accepted	P4-15	61	
	Set the validator for escrow or no escrow	P4-8	63	
	Activate or de-activate the declining balance feature	P4-9	64	
	Activate or de-activate the winner feature	P4-10	65	
	Set the basic configuration for the machine	P4-11	66	
	Compressor cycle temperature for can unit	P4-12	67	
	Chilled candy target air temperature	P4-12	67	
	Cup size	P4-13	68	
	Hot drink product mix	P4-14	69	
	Rinse cycle frequency	P4-16	70	
	Ratio - Percent chocolate ingredient in Cappuccino drink	P4-17	71	
Whipped coffee drinks - default settings	P4-18	72		
PAYOUT	A single coin	Quarter	P5-1	73
		Dime	P5-2	74
		Nickel	P5-3	75
	Inventory of an entire tube	Quarter	P5-4	76
		Dime	P5-5	77
		Nickel	P5-6	78
	All coins in all tubes	P5-7	79	
SET TIME	Set day and time for internal clock	P6-1	80	
	Set month, date and year for internal clock	P6-2	81	
	Set inhibit vending controls	P6-3	82	
	Set free vending controls	P6-4	85	
	Set discounted vending controls	P6-5	88	
	Set custom message controls	P6-6	91	
SERVICE	Retrieve the software version number	P7-1	94	
	Check operation of the display elements	P7-2	95	
	Test for faults	P7-3	96	
	Put all of the motors in the home position	P7-4	97	
	Last can vending	P7-5	98	
	Check communication with the coin mech	P7-6	99	
	Check communication with the bill validator	P7-7	101	
	Cup drop	P7-8	103	
	Whipper motor test	P7-9	104	
	Air compressor test	P7-10	105	
	Brewer mechanism test	P7-11	106	
	Brewer rinse test	P7-12	107	

FUNCTION	IF YOU WANT TO...	COMPLETE THIS PROCEDURE	ON THIS PAGE
SERVICE (Continued)	Bowl rinse test	P7-13	108
TEST VEND	A single selection without establishing credit	P13-1	109
	A single selection after establishing EXACT credit	P13-2	110
	A single selection after establishing LESS credit than required	P13-3	111
	A single selection after establishing MORE credit than required	P13-4	112

(PAGE 9 IS THE NEXT PAGE IN THIS DOCUMENT)

An optional printer is available for recording price and data information as shown in the display.

1. Locate the printer connector inside the machine.
2. Plug the connector into the receptacle in the front of your printer.
3. Turn the printer ON.
4. Follow the steps in the table on the next page.




Figure P0-2

PRINT THE DATA LIST OR THE PRICE LIST:

STEP	ENTER THIS KEYSTROKE...	AND THE DISPLAY INDICATES	COMMENTS
1	TIME OF DAY	SET TIME	Time set mode entered
2	↓	PRINTER X	The printer screen, where X = baud rate: 0 = 1200 baud 1 = 2400 baud 2 = 4800 baud 3 = 9600 baud
3	ENTER/ACTION	The baud rate changes	Keep pressing ENTER/ACTION until the correct baud rate for your printer is displayed.
4	O P T I O N S	Press DATA	The data list will print
		Press PRICE	The price list will print

NOTE: Step 3 only works while PRINTER X is displayed. If printer mode is not selected, normal data and price lists will show on the display.

VIEW THE NUMBER OF RINSE CYCLES COMPLETED SINCE THIS CATEGORY WAS LAST CLEARED:

STEP	ENTER THIS KEYSTROKE...	AND THE DISPLAY INDICATES	COMMENTS
1	DATA	DATA	Data mode entered
2	→	**CT XXXX	
3	Press ↓ six times	RINSE XX	XX = The number of times a rinse cycle was initiated since the last time this category was cleared.
4	Continue		Options: 1. Close monetary door 2. Press another function switch 3. See advanced programming section for other options

VIEW THE NUMBER OF FAILURE MESSAGES FROM THE SERIAL VALIDATOR:

STEP	ENTER THIS KEYSTROKE...	AND THE DISPLAY INDICATES	COMMENTS
1	DATA	DATA	Data mode entered
2	→	**CT XXXX	
3	Press ↓ seven times	CNT XX	XX = The number of failure messages from the serial validator.
4	Continue		Options: 1. Close monetary door 2. Press another function switch 3. See advanced programming section for other options

PUT THE MERCHANDISER ON FREE VEND:

STEP	ENTER THIS KEYSTROKE...	AND THE DISPLAY INDICATES	COMMENTS
1	FREE VEND	NO MONEY / REQUIRED	Free vend mode entered
2	CONTINUE		Options: 1. Close monetary door 2. Press another function switch 3. See advanced programming section for other options

DEFINE THE COIN MECH BEING USED:

STEP	ENTER THIS KEYSTROKE...	AND THE DISPLAY INDICATES	COMMENTS	
1	CONFIG	CONFIGURE	Configure mode entered	
2	➔	CNFG MACH		
3	➔	Current coin mech option is displayed	Option	Use
			DUMB MECH EXEC MECH NO MECH	US + Canada Europe
4	ENTER/ACTION		Scroll through the list of coin mech options until the type you want to use is displayed.	
	CONTINUE		Options: 1. Close monetary door 2. Press another function switch 3. See advanced programming section for other options	