

SUPPLEMENT 1570045




Installation Instructions

Install this supplement at the end of your *Snack Center and Refreshment Center Programming Guide* (part number 1570003).

SNACK CENTER PROGRAMMING GUIDE

DOWNLOAD DATA

Once you have selected the clearing option, perform the following steps to download data into your PDCD:






STEP	ENTER THIS KEYSTROKE...	AND THE DISPLAY INDICATES	COMMENTS
1		<i>CODE</i>	
2		<i>DEX</i>	
3		<i>SEND DEX</i>	This is displayed until all data is transferred (about 30 seconds).
4	CONTINUE	<i>READY</i>	Options: 1. Close monetary door. 2. Press another function switch. 3. See advanced programming section in the programming handbook for other options.

APPENDIX A DEX/UCS INTERFACE OPERATION

This appendix is intended for use with Snack Centers equipped with the DEX/UCS interface option. Connect and operate your portable data collection device (PDCD) per its instructions. The following instructions explain how to select whether or not your data is cleared from machine memory upon collection.

NOTE

Once you have completed the steps in this table, you need not perform them again until you wish to change options.

STEP	ENTER THIS KEYSTROKE...	AND THE DISPLAY INDICATES	COMMENTS
1		<i>CODE</i>	
2		<i>DEX</i>	
3		O P T I O N S <i>DEX.CLR ON</i>	Machine memory will be cleared after data is downloaded.
		<i>DEX.CLR OFF</i>	Data will remain in machine memory after download.
4	O P T I O N S  To change from OFF to ON.	<i>DEX.CLR ON</i>	
	 To change from ON to OFF..	<i>DEX.CLR OFF</i>	
5	CONTINUE	<i>READY</i>	Options: 1. Close monetary door. 2. Press another function switch. 3. See advanced programming section in the programming handbook for other options.

APPENDIX A. DEX/UCS INTERFACE OPERATION

Continued on Next Page...