



**MERCHANDISING SYSTEMS™** A Crane Co. Company  
**GPL**

## SERVICE BULLETIN

12955 Enterprise Way  
Bridgeton, MO 63044-1200

Technical Service 800-628-8363  
Parts (800) 621-7278  
Parts Fax (800) 531-2580  
General Information (800) 325-8811

---

**DATE: 5 May 2001**

**ISSUE: 118**

**SUBJECT: 170-171 Motor Test Procedure**

**From Standby Mode:**

**Press Mode Button**

**Press “#” key repeatedly until display shows “TEST”**

**Press and HOLD “\*” key then press “#” , display shows “init”**

**Press “\*” until display shows “P.test”**

**OPTIONS:**

- . Press A : Runs all motors in the machine
- . Press B-F Runs all selections on individual shelf selected
- . Pressing the same letter again will stop the motor test
- . Display shows current selection that is running

**1) Decimal point ON = Cycle switch open (home Position)**

**2) Decimal point OFF = Cycle switch closed (mid-cycle)**

# 88.88

# of motors  
failed

# of motors  
good

**Pressing 0 will show a list of failed motors**