

# Technical Bulletin

Bulletin Number: 487 Revision Number: R-02

Release Date: May 31, 1994 Revision Date: October 26, 2000

**SUBJECT:** CHANGE CUP EXTENSION

**MODELS:** All models that use the plastic change cup, prior to 0001-6439DV.

**REASON:** To provide an extension to the change cup to prevent coins from bouncing out of cup and into the vault of the main door.

**ORDER:** 491,010,64x.x3 Change Cup Extension – all plastic change cups prior to 0001-6439DV  
491,011,16x.x3 Change Cup Extension, Wide – all plastic change cups 0001-6439DV.

**TO INSTALL:**

1. Loosen the keps nut that secures the right side of the plastic change cup. (See area "A", figure 1.)
2. Position the Change Cup Extension so area "B", figure 1 goes over the threadstud between the keps nut loosened in step one and the back of the change cup.
3. Tighten the keps nut to secure.
4. Open and close access door slowly to ensure coin hopper does not hit the extension.

