

ADDITIONAL INFORMATION:


CHANGING KEY COMBINATIONS The new Flex-Ace lock enables you to quickly change the tumblers of the lock without removing the lock from the cabinet. Here's how it works.

YOU CAN ORDER a new tumbler combination from the factory, which is shipped to you in a disposable plastic pre-loaded coder, and a key cut to the new combination. It is recommended that extra coders and keys be kept available for immediate change of combination if necessary.

AFTER UNLOCKING THE LOCK with the original key, you then follow the simple instructions for removing the lock cap with the release pin, extracting the old tumblers and inserting the new ones by using the loading tool.



PRE-LOADED
CODER
4301-51B




LOADING TOOL
4301-52B


4301-54 RELEASE PIN

HERE'S ALL YOU DO:

1 Insert key and rotate to unlocked position.



2 Insert release pin, press in firmly, and rotate to release position.



3 Remove key. Use hooked end of release pin to remove cap.



4 Insert magnet end of loader tool and be certain to remove all seven tumblers.




5 Insert new coder containing seven new tumblers.



6 Insert prong end of loader tool and press in firmly.



7 Remove empty coder and loader tool as one. Be certain all seven tumblers are in place.



8 Replace cap, insert new key, press cap in firmly, and rotate to locked position.

