Vend Test Database

-)3/30/2000 16.9 OZ	-	*Model: *Type:	600E SERIES 90 PET		Cour		USA	"SLIMLINE" BOTTLE
Pkg. Dia. Pkg. Dia.	(inches): (mm):	2.49 63.25		Pkg Ht. (inches): Pkg. Ht. (mm):	8.4 213.36		◯ New ◯ Revise		Instructions:

ECN #: 2000-034-01

Wide Co	olumn Setup Deep: 2	2			
Qty	Part Number	Description			
8	801,812,04x.x1	3/32 flat shim (4 each side)			
4	801,809,81x.x1	3/32 short flat shim (2 each side next to bottles)			
1	324,010,21x.x3	extension, oscillator paddle w/bottle stop			
1	900,302,02x.x1	screw, #8-18x3/4			
1	801,809,80x.x1	vending cam, grey			
1	801,809,79x.x1	adjustable cam, red			
Notes:					

Cam set in hole #: 3 Rear Spacer set in hole #: 19 Load Package: caps to the back

Narrow Column Setup Deep: 2

Qty	Part Number	Description				
1	805,701,14x.x1	can stop shim, right				
1	801,903,73x.x1	bottle divider assy.				
2	800,503,83x.x1	rod & spring assy.				
1	801,903,23x.x1	red tube				
1	801,903,24x.x1	white tube				

Notes: Place rod with white tube in hole "C" of rotor. Place rod with red tube in hole "A" of rotor.

Cam set in hole #: 5Rear Spacer set in hole #: 19Load Package: caps to the back

Discharge Member:	large port	Wide Column Capacity:	72
Closure Strip:	large port	Narrow Column Capacity:	38
Can Chute Accessories:	large port	Total Capacity:	376