Vend Test Database

ECN #: 001642 Test #: 95-432-17

Date:

03/03/2004

*Model: 501E SERIES 90

USA Country:

*Size: 500 ML

*Type: PET

*Description: EVIAN ON ICE

Release Level:

Pkg. Dia. (inches): 2.48 Pkg. Dia. (mm):

Pkg Ht. (inches): 8.45

Pkg. Ht. (mm): 214.6 O New Revised Instructions:

Wide Column Setup Deep: 2						
Qty	Part Number	Description				
4	801,812,04x.x1	3/32 flat shim (2 each side next to column wall)				
4	801,809,81x.x1	3/32 short flat shim (2 each side)				
4	801,810,53x.x1	anti-nosedive shim (2 each side next to bottles)				
1	801,809,80x.x1	vending cam, grey				
1	801,809,79x.x1	adjustable cam, red				

Notes:

Cam set in hole #: 1 Rear Spacer set in hole #: 21

Load Package: caps to the back

Narrow Column Setup Deep: 2

Qty	Part Number	Description		
1	805,701,14x.x1	can stop shim, right		
1	609,072,80x.x3	bottle neck guide assy.		
1	801,903,72x.x1	bottle divider assy.		
2	800,503,83x.x1	rod & spring assy.		
1	801,903,23x.x1	red tube		
1	801,903,24x.x1	white tube		
1	609,070,63x.x3	filler shim, left (wide part to the front of vender)		

Notes: Assemble bottle neck guide assy, to rear spacer. Place rod with white tube in hole "C" of rotor. Place rod with red tube in hole "A" of rotor.

Cam set in hole #: 5 Rear Spacer set in hole #: 21

Load Package: back bottles first caps to the back, then install bottle divider assy., then front bottles caps

to the back

Discharge Member: Wide Column Capacity: large port **Closure Strip:** Narrow Column Capacity: 32 large port **Total Capacity:** Can Chute Accessories: large port 318