Vend Test Database

ECN#: 98-049-03 Test #: 98-556-08

Date: 05/05/99 *Model: 501E4 SERIES 90 Country: **ENGLAND** *Size: 500 ML *Type: PET *Description: LILT

Release Level:

Pkg. Dia. (inches): 2.68 Pkg Ht. (inches): 9.15

O New Pkg. Dia. (mm): Pkg. Ht. (mm): 68.07 232.41 Revised

Instructions:

Wide Co	Nide Column Setup Deep: 2			
Qty	Part Number	Description		
4	801,812,04x.x1	3/16 flat shim (2 each side)		
4	801,809,81x.x1	3/32 short flat shim (2 each side next to bottles)		
1	801,809,80x.x1	vending cam, grey		
1	801,809,79x.x1	adjustable cam, red		
Motoo	•	·		

Notes:

Cam set in hole #: 3 Rear Spacer set in hole #: 24

Load Package: Caps to the back.

Narrow Column Setup Deep: 2

Qty	Part Number	Description
1	801,305,21x.x1	rotor, shim
1	900,301,97x.x1	screw, philips 8/32 X 1/4
1	609,070,15x.x3	bottle shim, right
1	609,072,80x.x3	bottle neck guide assy.
1	609,010,50x.x3	column wall assy., right
1	800,503,83x.x1	Assy, R, Rod Bottle E-Model
1	801,903,25x.x1	yellow tubing
1	801,806,18x.x1	vend cam, brown
1	801,806,61x.x1	adjustable cam, brown

Notes: Place rod with yellow tube in hole "A" rear and hole "B" front of rotor. Install rear bottle neck guide assy. to rear spacer. Install rotor shim in rotor.

Cam set in hole #: 5 Rear Spacer set in hole #: 24

Load Package: Caps to the back.

Discharge Member: Wide Column Capacity: 58 Large Port Closure Strip: Narrow Column Capacity: 32 Large Port Can Chute Accessories: Large Port **Total Capacity:** 314