## **Vend Test Database**

ECN #: 001968

	05/25/2004 500 ML	-	I: 276E SERIES 90 PET		Test #: 98- Country: *Description:	ENGLAND
-	a. (inches): a. (mm):	2.68 68.1	Pkg Ht. (inches): Pkg. Ht. (mm):	9.15 232.4	<ul><li>○ New</li><li>● Revis</li></ul>	Instructions:

Vide Column Setup Deep: n/a					
Qty	Part Number	Description			
		•			

Notes:

Cam set in hole #: Load Package: Rear Spacer set in hole #:

Narrow Column Setup Deep: 2

Qty	Part Number	Description
1	805,701,15x.x1	bottle shim, right
1	609,072,80x.x3	rear bottle neck guide assy.
1	609,010,50x.x3	assy. column wall, right
1	800,503,83x.x1	Assy, R, Rod Bottle E-Model
1	801,903,25x.x1	yellow tubing

Notes: Place rod with yellow tube in hole "B" front and hole "A" rear of rotor. Assemble bottle neck guide assy. to rear spacer.

Cam set in hole #: 5Rear Spacer set in hole #: 24Load Package: caps to the back

Discharge Member:large portClosure Strip:large portCan Chute Accessories:large port

Wide Column Capacity:0Narrow Column Capacity:32Total Capacity:224