

# Vend Test Database

ECN #: 98-164-02

Test #: 98-606-07

**Date:** 05/05/99

**\*Model:** 276E4 SERIES 90

**Country:** ENGLAND

**\*Size:** 500 ML

**\*Type:** PET

**\*Description:** DR. PEPPER "DUMBELL"

**Release**

**Level:**

**Pkg. Dia. (inches):** 2.68

**Pkg Ht. (inches):** 9.18

New

Instructions:

**Pkg. Dia. (mm):** 68.07

**Pkg. Ht. (mm):** 233.17

Revised

**Wide Column Setup    Deep:** n/a

Qty	Part Number	Description

**Notes:**

**Cam set in hole #:**

**Rear Spacer set in hole #:**

**Load Package:**

**Narrow Column Setup    Deep:** 2

Qty	Part Number	Description
1	801,305,21x.x1	rotor, shim
1	900,301,97x.x1	screw, philips 8/32 X 1/4
1	609,070,15x.x3	bottle shim, right
1	609,072,80x.x3	bottle neck guide assy.
1	609,010,50x.x3	column wall assy., right
1	800,503,83x.x1	Assy, R, Rod Bottle E-Model
1	801,903,25x.x1	yellow tubing
1	801,806,18x.x1	vend cam, brown
1	801,806,61x.x1	adjustable cam, brown

**Notes:** Place rod with yellow tube in hole "A" rear and hole "B" front of rotor. Install rear bottle neck guide assy. to rear spacer. Install rotor shim in rotor.

**Cam set in hole #:** 5

**Rear Spacer set in hole #:** 24

**Load Package:** Caps to the back.

**Discharge Member:** Large Port

**Wide Column Capacity:** 0

**Closure Strip:** Large Port

**Narrow Column Capacity:** 30

**Can Chute Accessories:** Large Port

**Total Capacity:** 210