

Vend Test Database

Date: 02/03/2004
***Size:** 12 OZ

***Model:** 501E SERIES 90
***Type:** NR

ECN #: 001533
Test #: 98-662-08
Country: USA
***Description:** JAMAICAN GRAPE
 (LONG NECK)

Release 3
Level:

Pkg. Dia. (inches): 2.44
Pkg. Dia. (mm): 61.98

Pkg. Ht. (inches): 8.13
Pkg. Ht. (mm): 206.5

New
 Revised

Instructions:

Wide Column Setup Deep: 2

| Qty | Part Number | Description |
|-----|----------------|--|
| 12 | 801,812,04x.x1 | 3/32 flat shim (6 each side) |
| 2 | 801,809,81x.x1 | 3/32 short flat shim (1 each side) |
| 2 | 609,070,63x.x3 | filler shim (1 each side next to bottles) |
| 1 | 324,010,21x.x3 | extension, oscillator paddle w/bottle stop |
| 1 | 900,302,02x.x1 | screw, #8-18x3/4 |
| 1 | 801,809,80x.x1 | vending cam, grey |
| 1 | 801,809,79x.x1 | adjustable cam, red |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |



Notes:

Cam set in hole #: 3 **Rear Spacer set in hole #:** 18
Load Package: caps to the back

Narrow Column Setup Deep: 2

| Qty | Part Number | Description |
|-----|----------------|--------------------------|
| 1 | 609,072,80x.x3 | assy. bottle guide, rear |
| 1 | 805,701,14x.x1 | can stop shim, right |
| 1 | 609,011,20x.x3 | assy. column wall |
| 1 | 609,075,20x.x3 | bottle divider assy. |
| 2 | 800,503,83x.x1 | rod & spring assy. |
| 2 | 801,903,24x.x1 | white tube |
| | | |
| | | |
| | | |
| | | |

Notes: Assemble bottle neck guide assy. to rear spacer. Install column wall. Place one rod with white tube in hole "A" of rotor. Place one rod with white tube in hole "C" of rotor.

Cam set in hole #: 2 **Rear Spacer set in hole #:** 18
Load Package: Back bottles first caps to the back, then install bottle divider assy., then front bottles caps to the back.

Discharge Member: large port **Wide Column Capacity:** 60
Closure Strip: large port **Narrow Column Capacity:** 30

Can Chute Accessories: large port

Total Capacity: 300