



MERCHANDISING SYSTEMS

SERVICE INFORMATION

M136.1 (102094)

MODELS AFFECTED: All BevMax 4/3/2 Model Venders.

MODEL NUMBERS: DN5800/3800 – BevMax 4/3/2 Venders

Revised: 9/14/18

RE: BevMax Slide Cleaning Information.



Reason: To provide cleaning information for slides in BevMax 4/3/2 Venders. If you have any issues please contact your Crane Merchandising Systems Representative or the Technical Service Department at 803-266-5001.

Order: 1 – 111174 (previous #65700780) Kit, Food Grade Glass Front Slide Lubricant
Includes: 1 – 102917 (previous #80340007) 16oz Bottle of Food Grade Release Agent
1 – 102930 (previous #80510032) Spray Nozzle
1 – 102094 M136.1 BevMax Cleaning Procedure Instructions

Index:

Cleaning Indicatorspg. 2
Performance Issues Related To Dry or Dirty Slidespgs. 2 & 3
Proper Cleaningpg. 3
Lubricating Chemicalspg. 4

CRANE[®] MERCHANDISING SYSTEMS

SERVICE INFORMATION

Cleaning Indicators

1. Dirt and syrup buildup in the Delivery Cup (A) and on the slides (B) should be cleaned to avoid performance issues.



Performance Issues Related to Dry or Dirty Slides and Delivery Cup Base.

1. Products not sliding down the slides or tipping products on the tray are indicators that slides are dry or dirty.



CRANE[®] MERCHANDISING SYSTEMS SERVICE INFORMATION

2. Products found in the bottom of the machine also may be a result of dry or dirty slides.



Proper Cleaning Chemicals

1. Cleaning:

- a. A mild detergent (such as Dawn) mixed with warm water may be used as a cleaner. After cleaning the slides you will need to apply a Liquid Silicone Emulsion to re-lubricate.



2. Lubricating Chemicals:

- a. Use approved Food Grade Silicone based Release Agent from ECO-Lab/Kay Chemicals.



3. DO NOT USE:

- a. Any Type of Degreaser or glass cleaner. These will dry out the plastics and cause permanent damage.



CRANE[®] MERCHANDISING SYSTEMS

SERVICE INFORMATION

Proper Slide Lubricating Procedure

1. Silicone spray and a cotton towel should be used to lubricate slides.



2. Apply Silicone spray to towel.
 - a. Minimize overspray as much as possible by spraying close to the towel.



3. Place sprayed portion of towel at the base of the pusher.
 - a. Slowly wipe lubricant onto slide.
 - b. When finished slide should be wet but not dripping.

