

Dixie-Narco®



Lawrence Street
Ranson, West Virginia 25438

(304) 725-3481
(800) 624-0553

Service Bulletin # 215

Date: 3/30/79
(temporary) Revised

MODELS: Adaptable Red Cam and Dual Adaptable Red Cam
DN300/175-5 Only serialized as 001-2257 thru 800-2257.
DN432/246-6 Only serialized as 001-2266 thru 800-2266.

INCLUSIVE SERIALIZATION: 001-2257 thru 800-2257 and 001-2266 thru 800-2266.

PERMANENT BEGINNING SERIAL NUMBER: 001-2287

REASON: To make everyone aware of certain vender differences and to make available part numbers and part descriptions as they relate to these differences, since they do not presently appear in the Red Cam Service Manual.

1. Column Walls will no longer have the "Wings" formed at bottom front.
2. New injection molded parts installed as:
 - a. Delivery door mounted in the Discharge Frame in the Inner door.
 - b. Discharge Frame is of a different configuration.
 - c. Delivery chute for main door is of a different configuration.

Part Numbers are:

C801,804,200.01	Delivery door
C801,804,210.01	Discharge Frame
D801,804,220.01	Delivery Chute

THE ABOVE DIFFERENCES APPLY TO ADAPTABLE RED CAM VENDERS BASED ON SERIAL NUMBER 001-2287 AND TO ALL DUAL ADAPTABLE RED CAM VENDERS.

804,200,190.01	Vend Sequencer - located on bracket on Inner Door adjacent to coin changer socket. Not used on all Dual Adaptables.
C231,070,400.03	Vend Motor Assembly for narrow column.
D801,200,980.21	Vend Rotor - Located in narrow column.
B231,070,230.03	Can Shims - narrow column.
804,100,490.01	Sold out switch (2/col.) Cluster.

THE ABOVE DIFFERENCES APPLY TO DUAL ADAPTABLE RED CAM VENDERS ONLY.

Service Department
Dixie-Narco, Inc.