

# Dixie-Narco®



Lawrence Street  
Ranson, West Virginia 25438

(304) 725-3481  
(800) 624-0553

## Service Bulletin # \_\_\_\_\_

275

Date: July 20, 1984  
Revised: February 20, 1985

MODELS: DNCB 1½" Deeper

BEGINNING SERIAL NUMBER:

SUBJECT: Shimming Instructions - 250 ml can


CHARACTERISTICS OF: 250 ml can

1. Overall length - 5¼"
2. Outside diameter of can at top - 2 1/8"


- LOCATIONS WHERE USED:
1. Canada Dry - Rawlings, England
  2. Trinidad
  3. Kuwait

### SHIMMING INSTRUCTIONS


PACKAGE	SHIMS - WIDE COLUMNS	SHIMS - NARROW COLUMNS	BACK SPACER & VEND MOTOR CAM SETTING
250 ml Cans <u>DOUBLE-DEPTH</u> (As shipped Vender is set for these cans.)	(1) 250 ml "C" Can Shim Each Side.	(1) 250 ml Can Shim "D" on Left Side. (1) 250 ml Can Shim "E" on Right Wall Plus (1) Narrow Column Formed Metal Shim "F" on Right Wall. (1) Rod with Plastic Tube "H" in "C" Hole of Vend Rotor.	Back Guide in 21st Hole. Wide Column Vend Motor Cam set for 4 Notches. Narrow Column Vend Motor Cam set for 2 Notches.




C B267,010,140.13-Wide Column Shim (Left & Right Side)



E B2970.06-Narrow Column Can Shim (Right Side)



D B267,010,150.13-Narrow Column Can Shim (Left Side)



F B267,010,130.03-Narrow Column Can Shim (Right Side)



H 267,012,300.03-Rod Assembly with 801,901,900.01-Plastic Tube