Vend Test Database

ECN #: 2000-099-02 Test #: 2000-795-05

Date: 08/16/2000 *Model: 501E SERIES 90 Country: LAREUNION *Size: 350 ML *Type: PET *Description: LEMONICE

Release Level:

Pkg. Dia. (inches): 2.56 Pkg Ht. (inches): 6.98

Pkg. Dia. (mm): Pkg. Ht. (mm): 65.02 177.29

| ○ New | |
|---------|--|
| Revised | |

Instructions:

| Wide Column Setup Deep: 2 | | | | |
|---------------------------|----------------|--|--|--|
| Qty | Part Number | Description | | |
| 8 | 801,812,04x.x1 | 3/32 flat shim (4 each side) | | |
| 2 | 801,809,81x.x1 | 3/32 short flat shim (1 each side next to bottles) | | |
| 1 | 801,809,80x.x1 | vending cam, grey | | |
| 1 | 801,809,79x.x1 | adjustable cam, red | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

Notes:

Cam set in hole #: 1 Rear Spacer set in hole #: 12

Load Package: Caps to the back.

Narrow Column Setup Deep: 2

| Qty | Part Number | Description |
|-----|----------------|-------------------------------|
| 1 | 609,070,64x.x3 | long lip can stop shim, right |
| 1 | 609,072,80x.x3 | rear bottle neck guide assy. |
| 1 | 801,903,72x.x1 | bottle divider assy. |
| 2 | 800,503,83x.x1 | rod & spring assy. |
| 1 | 801,903,23x.x1 | red tube |
| 1 | 801,903,24x.x1 | white tube |
| | | |
| | | |
| | | |
| | | |

Notes: Assemble bottle neck guide assy. to rear spacer. Place one rod with red tube in hole "A" of rotor. Place one rod with white tube in hole "C" of rotor.

Cam set in hole #: 5 Rear Spacer set in hole #: 12

Load Package: Back bottles first caps to the back, then front bottles caps to the back.

Discharge Member: Wide Column Capacity: large port Closure Strip: Narrow Column Capacity: 32 large port Can Chute Accessories: large port **Total Capacity:** 316