INSTRUCTIONS FOR KIT PART NO. 3152396 KIT PART NO. 6202324

FREE VEND KEY SWITCH AND ACCESSORY ASSEMBLY


CHECK THE PARTS RECEIVED IN THE KIT WITH THE PARTS
LIST IN THESE INSTRUCTIONS. FIGURE 1 SHOWS ALL
THE PARTS IN THE KIT. IF ANY PARTS ARE MISSING,
CONTACT NATIONAL VENDORS' PARTS DEPARTMENT IMMEDIATELY.

Read these instructions carefully and completely before installing the kit. Retain these instructions for part numbers and for future reference.

These kits contain the following:

Part Number COMMON PARTS	Description	Quantity
3152393 3152394 9989435 4047095 1211161 3152395 KIT 3152396	Channel Backup Cover Jumper-Free Vend Switch Assembly-Free Vend Screw #8-32 x 5/16 PHS T/C W/Lockwasher 1/4" Cable Clamp Installation Instructions	1 1 1 2 1
3152497 3152498 <i>KIT 6202324</i>	IC Assy Eprom - Program U2 IC Assy Eprom - Program U3	1 1
6202323 6202325	IC Assy Eprom - Program U2 IC Assy Eprom - Program U3	1 1













KEYS (Part of Switch Assembly)





1/4" CABLE CLAMP



EPROM U2 & U3

DRILLING HOLE IN CABINET DOOR

- 1. Cut the template provided in the kit along the lines indicated.
- 2. Position the template as shown in Figure 2. Use tape to hold template in place during the drilling operation.
- 3. Drill hole in door, corresponding with indicated hole dimension on template.





FIGURE 2

MOUNTING THE KEY SWITCH IN THE CABINET DOOR


- 1. Remove nut from key switch.
- 2. Push harness and key switch through door from outside.
- 3. Replace nut and tighten securely. See Figure 3.



3152395

CONNECTING THE KEY SWITCH TO THE CONTROLLER PC BOARD

- 1. Remove the Door Controller Cover.
- 2. Remove backup cover, retain existing screws.
- 3. Snap end of harness into backup cover provided in delt, as shown in Figure 4.
- 4. Plug other end of harness into Door Controller & C Board as indicated in Figure 4.



5. Plug harness from keyswitch into harness from Controller PC Board.

REPLACING THE DOOR CONTROLLER EPROMS

OBSERVE PROPER ELECTRO-STATIC DISCHARGE PRACTICES WHEN HANDLING THE EPROMS. FAILURE TO DO SO MAY RESULT IN DAMAGE TO THE EPROMS.

- 1. Carefully remove Eproms U2 and U3. See Figure 5.
- 2. Replace the two Eproms with the two provided in kit.

3. Use the two cable clamps to secure the Key Switch Harness to the cabinet door.




FIGURE 5

4. Replace Door Controller Cover and return merchandiser to service.

USING THE FREE VEND KEY SWITCH

- 1. As long as the Key Switch is connected to J56 on the Door Controller PC Board, you cannot enter the FREE VEND mode by using the Function Switch Panel.
- 2. NORMAL VENDING will occur when the key slot is in the vertical position.



3. FREE VENDING will occur when the key slot is in the horizontal position.





