

# Vend Test Database

**Date:** 05/05/99  
**\*Size:** 500 ML  
**Release Level:**

**\*Model:** 501E4 SERIES 90  
**\*Type:** PET

**ECN #:** 98-009-03  
**Test #:** 97-545-08  
**Country:** ENGLAND  
**\*Description:** FANTA

**Pkg. Dia. (inches):** 2.68  
**Pkg. Dia. (mm):** 68.07

**Pkg. Ht. (inches):** 9.18  
**Pkg. Ht. (mm):** 233.17

New  
 Revised

Instructions:

**Wide Column Setup Deep: 2**

Qty	Part Number	Description
4	801,812,04x.x1	3/32 flat shim (2 each side)
4	801,809,81x.x1	3/32 short flat shim (2 each side next to bottles)
1	801,809,80x.x1	vending cam, grey
1	801,809,79x.x1	adjustable cam, red

**Notes:**

**Cam set in hole #:** 3                      **Rear Spacer set in hole #:** 24  
**Load Package:** caps to the back

**Narrow Column Setup Deep: 2**

Qty	Part Number	Description
1	801,305,21x.x1	rotor, shim
1	900,301,97x.x1	screw, phillips 8/32 x 1/4
1	609,070,15x.x3	bottle shim, right
1	609,072,80x.x3	bottle neck guide assy.
1	609,010,50x.x3	column wall assy., right
1	800,503,83x.x1	Assy, R, Rod Bottle E-Model
1	801,903,25x.x1	yellow tubing
1	801,806,18x.x1	vend cam, brown
1	801,806,61x.x1	adjustable cam, brown

**Notes:** Place rod with yellow tube in hole "A" rear and hole "B" front of rotor. Install rear bottle neck guide assy. to rear spacer. Install rotor shim in rotor.

**Cam set in hole #:** 5                      **Rear Spacer set in hole #:** 24  
**Load Package:** caps to the back.

<b>Discharge Member:</b> large port	<b>Wide Column Capacity:</b> 58
<b>Closure Strip:</b> large port	<b>Narrow Column Capacity:</b> 32
<b>Can Chute Accessories:</b> large port	<b>Total Capacity:</b> 314