## **Vend Test Database**

ECN#: 98-164-02 Test #: 98-606-09

Date: 05/05/99 \*Model: 600E4 SERIES 90 Country: **ENGLAND** \*Size: 500 ML

Release Level:

\*Type: PET

\*Description: DR. PEPPER "DUMBELL"

Pkg. Dia. (inches): 2.68 Pkg Ht. (inches): Instructions: 9.18 O New Pkg. Dia. (mm): Pkg. Ht. (mm): 68.07 233.17 Revised

| Wide Column Setup Deep: 2 |                |  |  |
|---------------------------|----------------|--|--|
| Qty                       | Part Number    | Description  |  |
| 4                         | 801,812,04x.x1 | 3/32 flat shim (2 each side)                       |  |
| 4                         | 801,809,81x.x1 | 3/32 short flat shim (2 each side next to bottles) |  |
| 1                         | 801,809,80x.x1 | vending cam, grey                                  |  |
| 1                         | 801,809,79x.x1 | adjustable cam, red                                |  |
|                           |                |  |  |
|                           |                |  |  |
|                           |                |  |  |
|                           |                |  |  |
|                           |                |  |  |
|                           |                |  |  |
|                           |                |  |  |
|                           |                |  |  |
|                           |                |  |  |

Notes:

Cam set in hole #: 3 Rear Spacer set in hole #: 24

Load Package: Caps to the back.

Narrow Column Setup Deep: 2

| Qty | Part Number    | Description                 |
|-----|----------------|-----------------------------|
| 1   | 801,305,21x.x1 | rotor, shim                 |
| 1   | 900,301,97x.x1 | screw, philips 8/32 X 1/4   |
| 1   | 609,070,15x.x3 | bottle shim, right          |
| 1   | 610,071,30x.x3 | bottle neck guide assy.     |
| 1   | 610,011,60x.x3 | column wall assy., right    |
| 1   | 800,503,83x.x1 | Assy, R, Rod Bottle E-Model |
| 1   | 801,903,25x.x1 | yellow tubing               |
| 1   | 801,806,18x.x1 | vend cam, brown             |
| 1   | 801,806,61x.x1 | adjustable cam, brown       |
|     |                |                             |

Notes: Place rod with yellow tube in hole "A" rear and hole "B" front of rotor. Install rear bottle neck guide assy. to rear spacer. Install rotor shim in rotor.

Cam set in hole #: 5 Rear Spacer set in hole #: 24

Load Package: Caps to the back.

Discharge Member: Wide Column Capacity: Large Port Closure Strip: Narrow Column Capacity: 36 Large Port Can Chute Accessories: Large Port **Total Capacity:** 356