## **Vend Test Database**

ECN#: 001967 Test #: 98-606-11

Date: 05/25/2004 \*Model: 501E SERIES 90 Country: **ENGLAND** 

\*Size: 500 ML \*Type: PET \*Description: DR. PEPPER "DUMBELL"

Release Level:

Pkg. Dia. (inches): 2.68 Pkg Ht. (inches): 9.18

Pkg. Dia. (mm): Pkg. Ht. (mm): 68.07 233.17 O New Revised Instructions:

Wide Co	Wide Column Setup Deep: 2			
Qty	Part Number	Description		
4	801,812,04x.x1	3/32 flat shim (2 each side)		
4	801,809,81x.x1	3/32 short flat shim (2 each side next to bottles)		
1	801,809,80x.x1	vending cam, grey		
1	801,809,79x.x1	adjustable cam, red		

Notes:

Cam set in hole #: 3 Rear Spacer set in hole #: 24

Load Package: Caps to the back.

Narrow Column Setup Deep: 2

Qty	Part Number	Description
1	805,701,15x.x1	bottle shim, right
1	609,072,80x.x3	bottle neck guide assy.
1	609,010,50x.x3	column wall assy., right
1	800,503,83x.x1	Assy, R, Rod Bottle E-Model
1	801,903,25x.x1	yellow tubing

Notes: Place rod with yellow tube in hole "A" rear and hole "B" front of rotor. Install rear bottle neck guide assy. to rear spacer.

Rear Spacer set in hole #: 24 Cam set in hole #: 5

Load Package: Caps to the back.

Discharge Member: Wide Column Capacity: 56 Large Port Closure Strip: Narrow Column Capacity: 30 Large Port Can Chute Accessories: Large Port **Total Capacity:** 296