## **Vend Test Database**

ECN #: 2000-016-004 Test #: 98-633-06

 Date:
 02/15/2002
 \*Model:
 501E SERIES 90
 Country:
 ENGLAND

\*Size: 375 ML \*Type: PET \*Description: ROBINSONS JUICE

shim angle (1 each side next to bottles)

Description

Release Level:

Qty

12

Wide Column Setup

Pkg. Dia. (inches): 2.31 Pkg Ht. (inches): 7.23

Deep: 1

**Part Number** 

801,812,04x.x1

610,070,06x.x3

801,809,80x.x1

801,809,79x.x1

Pkg. Dia. (mm): 58.67 Pkg. Ht. (mm): 183.64

vending cam, grey

adjustable cam, red

3/32 flat shim (6 each side)

0	New	
	Revised	

Fruit Bred

Instructions:

Notes:

Cam set in hole #: 1 Rear Spacer set in hole #: 13

Load Package: caps to the back

Narrow Column Setup Deep: 2

Qty	Part Number	Description
1	805,701,14x.x1	can stop shim, right
1	609,011,20x.x3	assy. Column wall, narrow
1	609,075,20x.x3	assembly, bottle divider
1	432,070,17x.x3	narrow sold out paddle
2	800,503,83x.x1	Assy, R, Rod Bottle E-Model
1	801,903,24x.x1	white tube
1	801,904,04x.x1	black tube

**Notes:** Place one rod with black tube in hole "C" of rotor. Place one rod with white tube in hole "A" of rotor.

Cam set in hole #: 3 Rear Spacer set in hole #: 13

**Load Package:** Load back bottles first caps to the back, then install bottle divider assembly., then front bottles caps to the back.

Discharge Member:large portWide Column Capacity:70Closure Strip:large portNarrow Column Capacity:34Can Chute Accessories:large portTotal Capacity:342