

merchant MEDIA

User Guide 7" Touchscreen



CRANE[®]

3330 Dixie Narco Blvd • Williston SC 29853

www.cranems.com

P/N CR0021457 Rev 10.9.9 July 2015

Table of Contents

- Compliance Requirements Page 3
- Specifications Page 6
- Cautions & Definitions Page 8
- Inspection & Installation Page 10
- Daily Cleaning Page 19
- Initial Start up Page 22
- The Selection Process Page 34
- The Touch Screen Page 29
- Access Service Mode Page 41
- How do I Access the Service Modes Page 44
- Service Mode Chart Page 48
- Troubleshooting Charts Page 283
- Wiring Diagram Page 293
- Software License Information Page 296

Compliance Requirements

LOCATION OF MANUFACTURER:

- All machines are built at the Crane Merchandising Systems manufacturing facility, located at 3330 Crane Way, Williston SC 29853, USA

DATE OF MANUFACTURE:

- Date of manufacture can be determined by viewing the Manufacturing Date on the Serial Number decal, located on the top left rear corner of the back of the machine cabinet.

PERMITTED & NON PERMITTED USES OF THIS MACHINE

- This machine is designed to dispense pre-packaged food, candy, beverage, snack and similar products. Use of unwrapped food products is not permitted.
- It is not permitted to use this machine outdoors, or in an environment where flammable or explosive vapors are present.
- This machine is not designed, nor should it be used to dispense flammable or explosive items, nor any other item that could not be safely dispensed by dropping it into the delivery bin.
- This machine is not suitable for installation in an area where a water jet could be used.
- This appliance is not to be used by persons (including children) with a reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction. Children must be supervised not to play with the appliance.

Nutritional Content Information

- Crane Merchandising Systems is providing the nutritional content information, based on information provided by the product manufacturers, and Crane MS is cannot accept responsibility for content created by others.

Compliance Requirements

All models are built to meet or exceed all applicable standards, including but not limited to:

- International (CE) Approvals to meet or exceed the below listed standards:
 - 83/23/EEC (93/68/EEC) Low Voltage Directive.
 - 89/336/EEC EMC Directive
 - EN 60335-1 Safety of household and similar electrical appliances.
 - DIN VDE 0700 T224 Safety requirements for Automatic and coin-operated machines and control devices for commercial use.
 - EN 55022 Class B Limits and methods of measurements of Radio interference characteristics of information technology equipment.
 - IEC 801-1 Electromagnetic compatibility for industrial-processing measurement and control. Part 1: General.
 - IEC 801-2 Part 2; Electrostatic discharge requirements for industrial process measurement control equipment.
 - IEC 801-3 Part 3; Radiated electromagnetic field requirements.
 - IEC 801-4 Part 4; Electrically fast transient.
 - IEC 801-5 Draft; Surge immunity requirement.
 - IEC 801-6 Draft; Immunity to conducted disturbances induced by radio frequency.
 - EN 50082-1 Generic immunity requirements; Residential, Commercial, Light industry.
- Machines built for the US Market meet or exceed the requirements for UL751 for ambient machines, and UL541 for chilled machines, and have also been reviewed and passed the NAMA Construction Standard, and are permitted to bear the NAMA Mark.

Compliance Requirements

- **NOISE LEVEL**
 - This machine operates at less than 70 db (A).
- **ACCEPTABLE AMBIENT OPERATING TEMPERATURE RANGE.**
 - This equipment was designed and tested to work properly in a temperature range of 10°C to 32°C (50°F to 90°F) in still air (45% Relative Humidity, non-condensing). Usage at ambient conditions outside the range of the testing may cause unacceptable appearance or performance.
- **STORAGE CONDITIONS**
 - The machine capable of being stored in a temperature range of -18°C to 68°C (0°F to 155°F). Storage temperatures below 0°C (32°F) require that the operator to take the required precautions to ensure that any water is removed from the condensate system prior to storage.
- **INDOOR USE ONLY**
 - This machine is designed to be used in an Indoor Setting only. Indoor Setting is defined as inside a structure constructed with four walls and a roof, and sufficiently protected from ambient conditions and not subjected to the effects of weathering. Any other usage is in direct violation of these instructions, and will void the warranty of the machine and its components.

Specifications

186 & 187 Ambient Snack

Specifications	Model 186 Domestic 4 wide Ambient	Model 186 Export 4 wide Ambient	Model 187 Domestic 6 wide Ambient	Model 187 Export 6 wide Ambient
Height	72 inches	183 cm	72 inches	183 cm
Width	32.8 inches	83.312 cm	43.75 inches	111.13 cm
Depth	38.5 inches	97.79 cm	38.5 inches	97.79 cm
Floor Space	8.8 Sq ft	.82 Sq Meter	11.7 Sq ft	1.09 Sq Meter
Container Size	52.8 Cu Ft.	1.50Cu Meter	70.2 Cu Ft.	1.99 Cu Meter
Shipping Weight	510 lbs	231 kg	610 lbs	276 kg
Voltage (AC)	120V	230V	120V	230V
Running Amperes	3A	1.5A	3A	1.5A
Refrigerant Charge	Not Applicable		Not Applicable	
Compressor size				
High Side Test Pressure				
Low Side Test Pressure				

Specifications

471 & 472 Combo

Specifications	Model 471 Domestic 4 wide Combo	Model 471 Export 4 wide combo	Model 472 Domestic 6 wide Ambient	Model 472 Export 6 wide Ambient
Height	72 inches	183 cm	72 inches	183 cm
Width	32.8 inches	83.312 cm	45.5 inches	115,57 cm
Depth	32.5 inches	82.55 cm	32.5 inches	82.55 cm
Floor Space	7.4 Sq ft	.69 Sq Meter	10.3 Sq ft	.96 Sq Meter
Container Size	44.4 Cu Ft.	1.26 Cu Meter	61.6 Cu Ft.	1.75 Cu Meter
Shipping Weight	629 lbs	285 kg	729 lbs	330 kg
Voltage (AC)	120V	230V	120V	230V
Running Amperes	8A	4A	8A	4A
Refrigerant Charge	7.5 oz	.213 kg	9.8 oz	.278 kg
Compressor size	1/3 hp	1/3 hp	Super 1/3	Super 1/3
High Side Test Pressure	250 psi	17.24 bar	250 psi	17.24 bar
Low Side Test Pressure	105 psi	7.24 bar	105 psi	7.24 bar

Cautions & Definitions

It is critical that all cautions and warnings be reviewed and complied with during the unpacking, installation, operation, and repair of this machine



CAUTION: This machine is designed for indoor usage only. Any other usage will void the Manufacturer's Warranty



CAUTION: Any procedure marked with the symbol at left requires that the Machine have the power applied and a shock hazard exists. Only a trained and authorized person should attempt these repairs.



CAUTION: It is important that this machine is hooked up to the proper voltage and polarity for your country. Use a Voltmeter to verify voltage and polarity. Should the reading be any different than a normal reading or if you are unsure of what the reading should be, contact an electrician.



CAUTION: Different countries may have unique plug arrangements. Ensure that the machine is properly grounded before operating. .



CAUTION: The power cord for all machines are of a type X attachment. If the power cord is damaged, it should be replaced by a trained service agent, or a similarly qualified person in order to avoid a hazard.

Cautions & Definitions



CAUTION: The machine is a heavy item. Ensure that sufficient personnel are available for lifting and transporting the machine. Use proper lifting procedures and equipment.



CAUTION: This machine is designed to dispense pre-packaged food, candy, beverage, snack and similar products. Use of unwrapped food products is in direct contradiction to these cautions.



CAUTION: If this machine is used to dispense perishable food, and local health codes require that the machine monitor the cabinet temperature, and prevent vending when the temperature exceeds a defined limit for a period of time, then the Health Code function must be enabled for those affected selections – see Health Code Setup



CAUTION: The electronic system components in this machine utilize static sensitive components. Precautions for handling sensitive devices should be observed when handling these items.

Inspection and Unpacking

The Merchant Media is assembled and packed so that a minimum amount of time is necessary for preparation to install it on location. The following steps are recommended to ensure correct unpacking.

- **Shipping Damage:** Thoroughly inspect the exterior of the carton for damage which may have occurred during shipment. Report any damage to delivering carrier and follow their instructions.
- Remove the remainder of the packing material. On machines shipped with the lock in place, the keys are taped inside the coin return.
- Removal of shipping boards: There are 2 methods available for removal of the shipping boards on the bottom of the machine, and they are dependent upon the style of packaging used: 2 flat shipping boards (Style A), or 2 L shaped assemblies (Style B).
- **Style A**
 - a) Using a motorized lifting device (i.e. a forklift) raise the machine to a comfortable working height and remove the leg levelers with the use of a socket or wrench (1 5/16"). Do this on one side at a time. After the front and rear leg levelers are removed, the shipping board can then be removed. Replace the leg levelers in the legs of the machine before lowering to the ground, OR
 - b) When using a pallet jack (non-motorized) insert a pry bar into the slit on the front and rear of the wooden boards, and twist the bar to force the boards to split apart, and remove from the machine. Screw the leg levelers all the way in before lowering the machine to the ground.
- **Style B**
 - a) Each of the 4 legs has a hex head screw securing the leg to the wooden pallet. Remove the screw from each leg, then using either a motorized lifting device, or a pallet jack, raise the machine sufficiently to slide the 2 assemblies out from under the machine and lower it to the floor.
- **NOTE:** On the machine, the weight concentration is toward the back of the cabinet. Trucking and lifting should be done from the back. **CAUTION** should be taken when trucking from side.
- On machines with lock in place, first unlock and turn handle to open door. When no lock is furnished, remove clip and turn handle. Swing door to its full open position.
- Remove all additional packing material from the machine.

Unpacking ADA Bin


Attention!

To avoid damage to the ADA delivery bin mechanism, remove the **SHIPPING BOLTS** from the bin sides prior to operating the ADA delivery bin!!!

The Shipping Bolts must be installed any time the machine is moved or transported. Failure to do so could result in damage to the delivery bin

To tilt the bin down to access the shipping bolts, swing the small latches on the top corners of the bin to release the bin.

Make sure you latch the bin after removing the shipping bolts.



View of shipping bolt
(2 shipped per bin)

Shipping Location

(two bolts – back of bin sides on left and right)



Bin pulled out to access bolts



Bin Latch Locations

Moving the merchandiser through a narrow doorway

Note: If necessary, this Merchandiser can be moved through an opening as narrow as 30 inches (76.20cm) by removing the panels at the top and bottom of the cabinet.

Step 1- Remove the top Panel

1. Remove the screws that secure each end of the panel to the cabinet.
2. Pull the panel forward to remove it from the merchandiser.

Note: This only applies to an Ambient machines.




Figure 1



CAUTION: This procedure requires the use of tools, and should only be completed by a trained technician or operator.

Moving the merchandiser through a narrow doorway

Step 2

REMOVING THE LOWER PANEL AND DELIVERY BIN (Refer to Figures 2 and 3 at right.)

1. Open the slide-out monetary and the glass door. Locate the silver tab of the delivery bin latch on the lower delivery bin side of the monetary wall.
2. Lift the latch up to allow the delivery bin assembly to hinge down.
3. Lift up the delivery bin slightly and lift up on the drop rods to allow the rods to clear the stop brackets.
4. Slide the delivery bin assembly to the right to clear the hinges. The delivery bin assembly will not be attached to the machine.
5. Unhook the SureVend™ harness at the SureVend™ board, noting the wire routing.
6. Remove the screws that secure the bottom panel to the cabinet.
7. Pull the panel forward to remove it from the cabinet.

NOTE

To fit the merchandiser through some of the most narrow doorways, you may have to remove the trays. If you do, follow the procedure outlined on the following page.




Figure 2





Figure 3

Installation


Leveling the unit

- **Leveling the Machine**
 - Leveling the machine on location is important for the proper function of the machine. There are four leveling screws in the legs of the machine to make any necessary adjustments. After positioning the machine, level it from front to rear and right to left directions. After leveling, turn front right (lock side) leveling screw in about one-half turn to drop this corner slightly to make the door easier to close and lock.



- **Clearance Requirements**

- It is necessary on all machines to have 25mm (1”) clearance on the left side of the machine for the door to properly open to access the shelves.
- All chilled or refrigerated machines require 150mm (6”) of clearance behind the machine for air circulation.



Installation

Electrical Supply Check



CAUTION: It is important that this machine is hooked up to the proper voltage and polarity for your country. Use a Voltmeter to verify voltage and polarity. Should the reading be any different than a normal reading or if you are unsure of what the reading should be, contact an electrician.

• Power Requirements

- The merchandiser is supplied with a service cord for the country of use, and is terminated in a grounding type. The wall receptacle used for this merchandiser must be properly polarized, grounded and of the correct voltage. Operating the merchandiser from a source of low voltage will void the warranty. Each machine should have it's own circuit, and that circuit should be protected with a circuit breaker or fuse to conform to local regulations.
 1. **Voltage Check** - Place the leads of the voltmeter across the Line and Neutral sockets of the wall receptacle. The voltmeter should indicate a stable voltage in a range of 110 to 130Vac for 120V 60Hz locations, or 220 to 240Vac for 230V 50Hz locations.
 2. **Polarity Check** - Place the leads of the voltmeter across the Line and Ground sockets of the wall receptacle. The voltmeter should indicate a stable voltage in a range of 110 to 130Vac for 120V 60Hz locations, or 220 to 240Vac for 230V 50Hz locations.
 3. **Noise Potential Check** - Place the leads of the voltmeter across the Neutral and Ground sockets of the wall receptacle. The voltmeter should indicate zero voltage. A measurement greater than 1.5V could result in operational issues for the merchandiser's electronics caused by electrical noise.

Note: Any deviation from these requirements could result in unreliable performance from your merchandiser.



CAUTION: This procedures requires the use of tools, and should only be completed by a trained technician or operator.

Initial Setup

Key Steps


- After unpacking and installing the machine on location the Key steps to setting up the machine the first time are:
 1. Load a change fund into the coin mechanism.
 2. Set the selection prices in the machine.
 3. Test vend at least one selection on each shelf to verify:
 - a. Pricing is correct, and coin mech, bill acceptor and credit card device are working correctly.
 - b. Product and nutrition information are correct.
 - c. Selection delivers products.
 - d. Delivery bin delivers product to customer.

Filling the Machine

Loading the Machine

- 1) Lift the front edge of the shelf and pull the shelf forward until it stops
- 2) Insert products into spirals
- 3) Once the shelf is loaded, push the shelf back into the machine until you feel front edge raise up over the ramp.

Note: If tall product hits the shelf above when restoring the shelf to the normal vend position, raise the upper shelf to provide clearance



Daily Cleaning

Daily Cleaning

Before leaving the machine each visit, the machine should be inspected and cleaned as follows:

- ① Glass – inside and out – use glass cleaner and disposable towels
- ② Front of monetary panel – do not use ammonia based cleaners as it may cause premature crazing of the polycarbonate surface. We recommend the use of Novus #1 plastic cleaner & polish.

For units equipped with a touch screen, never spray any cleaner directly on the touchscreen, nor permit liquids to flow onto the screen. Apply cleaner to a disposable towel and then apply to the pill or touchscreen. Treat the touchscreen as you would any sensitive electronic device and never use abrasive cleaning materials.

- ③ Delivery Bin – Inside and out – clean any spills or residue with a mild soap and water solution, and wipe dry.



Preventative Maintenance

Cashless Devices

- If your machine is equipped with a cashless device, whether it is a credit card reader, or a proprietary closed system pre-paid card, the magnetic head used to read the payment cards needs to be cleaned regularly to insure proper operation.
- The defined tool for cleaning a magnetic head is a pre-saturated cleaning card, which are commercially available from various sources.
- Based on credit card industry standards, the busier a machine is, the more frequently the magnetic head should be cleaned
- For cashless uses more than 100 times per day – clean it every day
- For cashless uses between 50 and 100 times per day – clean it every other day
- For cashless uses between 10 and 50 times per day – clean it one time per week.
- Actual conditions may vary, and be affected by site conditions, for example a machine located outdoors should be cleaned more frequently.
- Follow the instructions provided with the cleaning card, and slide it past the magnetic head as directed.



Payment Systems

The Media Merchandisers are capable of accepting multiple forms of payment systems using a Multi Drop Buss or Executive (export only) interface.

- All payment devices are mounted on the slide out assembly. The front of this slide out assembly is called a Pill. There are multiple configurations of the Pill available should you need to add or take away payment peripherals in the future.
- If your payment peripherals were installed at the factory they should already be enabled in the electronics. Currently we enable only \$1 and \$5 bills (notes) in manufacturing. Instructions from the manufacturer for all peripherals installed at the factory are included in the bag assembly in the machine. Please refer to these instructions for information on filling coin tubes, adding bills to recyclers or other pertinent information.
- If your payment peripherals were not installed in manufacturing, please refer to the instructions that came with payment system for set up and installation.
- See the service modes section of this document for information on enabling or disabling different bills and/or additional peripherals.

Initial Start Up



Powering up the machine

Turn on the power switch located on front of the power box accessible by pulling out the swing panel.



Power Switch

The Media Merchandisers run on the Linux operating system, it is essentially a computer so it will take several minutes to power up just like your computer at home.



Initial Start Up

Features and Benefits

Merchant Media Touch - Key Features

- Merchant Media Touch uses Crane's latest vending electronic platform built on NAMA Open Standards integrating touch screen technology, cashless payments, and telemetry in a seamless solution.
- 7" color touch screen offers the latest capacitive touch screen technology providing scratch resistance, high durability and a rich consumer experience.
- Built-In Credit Card Reader option and communication screens throughout the vending process facilitate the use of credit cards.
- A 2nd Card Reader option (e.g. college campus cards) can complement credit cards offering more options to consumers. With Media you can have both credit cards and another cashless system as long as the second system follows the MDB protocol.
- Shopping Cart makes it easy to buy multiple products and enables promotions. This key feature helps you drive sales especially when using credit cards as consumers tend to buy more.
- Media Touch Main Menu can provide consumers the options of: 1) Make a Selection, 2) View Promotions, 3) Nutrition Facts, and 4) Select Language. If these features are not enabled, the consumer can go directly to the keypad bypassing Main Menu providing just a simple vending experience. Depending on the location, you can decide what's best for your consumers.

Initial Start Up

Features and Benefits

Merchant Media Touch - Key Features, Continued

- Built-In Multi-Product Promotions can be selected through the Service Menu. You can select the specific promotion and program the discount that will show in the screen when the machine is idle. Consumer can also access the promotions from the Main Menu. Multi-Product Promotions can help you increase the transaction size and improve the consumer value.
- Multiple languages can be selected by the consumer meeting the needs of key locations. As languages become available they can be enabled through the Service Menu letting the consumer select the language for his vending experience from the Main Menu.
- A Built-In Product Library (of 250 products) with images and nutrition facts lets you build a Planogram or enable browsing without a Planogram. If needed, a custom product library can be developed with your specific products – please contact your Crane sales representative for more information.
- Crane's field service support team is here to assist you and make sure you and your customers have a great experience. Please don't hesitate to contact us.

Initial Start Up

Programming tips

- This Programming Guide is based on software version 10.9.9 or higher
- The software version is shown on the bottom right of the display anytime you are in the Service mode. The software version can also be displayed by pressing the Firmware Information icon in the service mode and reading the LE board information.
- Earlier or later versions of software may not contain all the same menus and/or options. Some Menu items may also be in different places within the menus & program differently.
- This programming guide is specific about what icons or menu bars to touch within the Modes. When certain Menu items are enabled and disabled additional menu items may appear or disappear. Most of the time this guide will be correct but rely on the display for the correct icons or menu bars to touch.

Initial Start Up

Quick Start Tips

Below is a list of Menus that should be set up or checked before operating the Machine:

1. When opening the service door on the machine you will be prompted for a PIN, enter 3333 on the touchpad.
2. Set the Prices by selecting button Price Icon in the service mode.
3. Make sure the Shopping Cart Size (max 3) and Shopping Cart Max Value is set to the cart size times the highest price in Product Configuration. Touch: Product Configuration > Shopping Cart Setup.
4. If you have added, moved or removed any motors touch: Product Configuration > Selection Configuration > Perform Auto Configuration > Start Auto Configuration.
5. If any motors are being coupled on the candy tray or squat tray Touch: Product Configuration>Couple Motors.
6. Verify your Coin Mechanism, Bill Validator and Card Reader are enabled in the Monetary Menu.
7. Verify the bills you want to accept are enabled in the Monetary Menu > Bill (Note) Acceptance.
8. Set the Time and Date in the System Setting Menu > Set Time and Date.

Initial Start Up

Quick Start Tips

If your machine contains a refrigeration unit you must also set the following:


1. Verify or set the Configuration Version, go to System Settings > Press the lower half of the down arrow to scroll down and verify the Configuration Version is set correctly.
2. To change the Configuration Version touch the Configuration Version menu bar, your options are Ambient, Refrigerated, European Control, Non-perishable and Chilled. Do not choose European Control unless your area is within the region covered by these requirements.
3. Press Done to save your choice.
4. Next select Refrigeration Settings, this menu does not appear if the machine is set to Ambient.
5. Touch Adjust Temperature if required.
6. If set to Refrigerated or European Control, Touch Health Control to assign the selections to work with Health Control. The health control menu will not appear if you machine is set to anything other than Refrigerated.
7. Effective with the release of 10.8.x software, if Refrigerated or European Control is selected, all selections in the machine are enabled for Health Control. If you are not using perishable products in all selections, non-perishable products should have the Health Code disabled.

Quick Start Tips – Loading the Coin Mechanism

Prior to placing the machine in service, you must add an initial amount of change to the coin mechanism to prevent a “Use Correct Change” condition. Initial loading of coins should be done through the menu provided to insure the coin mech accurately counts all change available for payback to the customer. *Recommended minimum amount is \$17.00 (1 roll each of 5¢, 10¢, 25¢ coins).* This minimum amount of change should remain in the machine at all times.

Adding Initial Change Load

1. Enter the required PIN: 3333,
2. Touch the Monetary Icon on the screen.
3. Touch the Coins In/Out menu Bar
4. Increase the amount of Change Available by inserting coins to thru the chute on the top of the coin mech. Totals (count and value) for each coin should increase as coins are added.
5. Press the left arrow to exit and return to the main menu.




Coin	Count	Value
0.05	35	\$1.75
0.25	20	\$5.00
0.50	15	\$7.50
1.00	1	\$1.00
0.05		

The Touch Screen

The 7 inch Touch Screen


- The 7" color touch screen offers the latest capacitive touch screen technology providing scratch resistance, high durability and a rich consumer experience.
- The touch screen provides instructions and information required by the customer to make a purchase.
- The touch screen is also utilized in the service mode to set up the machine.
- The Touch Screen is an industrial screen that can withstand medium hard hits w/ hammer similar to gorilla glass used in mobile phones.



Should the Touch Screen ever need to be calibrated, follow the instructions on the following four pages.

Touch Screen Calibration

- The Touch Screen in new machines will come from the factory already calibrated.
- To change the sensitivity of the Touch Screen press and hold the green service switch on the board for 4 seconds.
- If the software was just updated, when the machine is booted-up the machine may automatically take you to the Touch Screen Setup Mode.
- This mode consists of two functions:
 - Sensitivity Setting
 - Touch screen Alignment
- These activities must be done in sequence, and completed to ensure proper operation of the touch screen.




Touch Screen Setup Calibration

Sensitivity Setting

Setting the sensitivity of the touch screen.


- Press the green switch on the control board, and the Sensitivity Index number will increase.
- Tap the display and listen for a single beep from the controller, indicating that it detected the touch.
- Continue to press the green switch on the board until an acceptable level of sensitivity is achieved over the whole surface of the touch screen.
- It is important to check the sensitivity of the screen throughout the entire Touch Screen, especially along the left and right edge.
- Tap at a speed of approximately 1 tap per second.
- The recommended initial range is 4 to 6.
- When finished, advance to the target screen by pressing and holding the green service button for 3 seconds.



Touch Screen Setup Calibration

Touch Screen Alignment

The screen will show 5 targets. Touch each target in the sequence shown on the display. The Sequence is indicated by the larger circle around the target.




After pushing each button a second time the display will show you where it has assigned your touches.



Touch Screen Setup Calibration

Touch Screen Alignment

- If the distance between the 5 targets and the indicators are within a reasonable distance (less than 1/8" or 3mm), tap the touch screen twice to accept the settings
- If the distance between the targets and indicators is unacceptable, tap the screen one time to restart the Initial Touch screen Setup Mode.
- After tapping the screen twice the machine will proceed through a normal boot-up sequence.



The Selection Process

Idle Loop Screens

When the machine is not being used the Touch Screen is showing the Idle loop. The Idle Loop screens will vary depending on what peripherals you have installed and the promotions that are enabled. To enable or disable specific Idle Screens and credit card logos. See System Settings > Advertisements. Touching any of these screens will take you to the Main Menu.




The Selection Process

The Main Menu

Main Menu Screen

- The Main Menu allows your customer to view promotions when enabled and view nutritional facts when a Product Library is present.
- When product libraries or multiple promotions are not used this is an extra screen that is not necessary and bypassing it speeds up the vend process.
- When using plan-o-grams the customer can check the nutritional information when making a selection even if this menu is disabled.
- As a default the machine is set to Skip the Main Menu.
 - The menu item to turn the Main Menu on or off can be found in the Special Vend Modes menu.
- When the Main Menu disabled and the idle loop screen is pressed, the screen will immediately transition to the numeric keypad screen.





The Selection Process

Making Selections and Navigating the Shopping Cart

Use the Keypad to make a selection. Your selection will be placed in a shopping cart. The Keep Shopping and Checkout Icons will start flashing. Choose Keep Shopping to add additional selections (maximum 3) to your cart. Press Check Out when finished.

Note: The shopping cart can be disabled by enabling Rapid Vend under the Special Vend Modes Icon and the machine will immediately go to checkout after making a selection.



The Selection Process

Making Selections and Navigating the Shopping Cart

If you have a planogram installed an image of the product will appear on the screen



Pressing the information Icon next to the product image will show a popup with nutritional information for that product



The Selection Process

Making Selections and Navigating the Shopping Cart

If you do not have a planogram installed, or a product assigned, an image of a generic product will appear on the screen



To remove a product from the shopping cart press the red X



The Selection Process

Making Selections and Navigating the Shopping Cart

Any Discounts or Surcharges will be shown to the right of the shopping cart as well as the Total of all products in the cart.



At any time you can press the cancel icon to cancel the entire sale. If nothing happens for 30 seconds (settable) the machine will cancel the transaction and go back to the idle screen



The Selection Process

Making Selections and Navigating the Shopping Cart

Any type of payment, cards, coin or bills can be inserted any time during the transaction. Pressing checkout will cause the settlement screen to appear if money has not already been inserted

The settlement screen will communicate to the customer their Monetary payment options



Accessing the Service Modes

When the monetary compartment is opened, the display will prompt the operator to enter a PIN number on the Touch Screen to gain access to the service modes.

- The default PIN for route driver access is **1111** (limited access).
- The default PIN for programming access is **3333**.
- If errors exist, an **!** will appear on the bottom right corner of the screen. Pressing the **!** allows the user to view the existing errors without entering one of the pin number above.




Service Modes

Initial Screens

If **Errors Exist**, an error list will be shown on the display that includes the time and date of each error.

The errors do not need to be cleared, once corrected the error will be erased automatically.

To escape to the home screen press the  Back arrow, or the Home Icon



The screenshot shows a 'Diagnostics' screen with a table of error logs. At the top, there is a navigation bar with four icons: a back arrow, a home icon, a key icon, and a power icon. The table has three columns: 'undefined', 'time', and 'date'. The first row is a header row. The second row shows 'SureVend Comm Error' at '20:17' on '09 May'. The third row shows 'Coin Return Motor' at '18:32' on '09 May'.

undefined	time	date
SureVend Comm Error	20:17	09 May
Coin Return Motor	18:32	09 May


How Do I Access the Service Modes?

If PIN **1111** was entered and **No Errors Exist**, the home screen for the Driver menu will appear. This menu allows limited access to the service modes. Touching an icon on the screen will provide access to that menu.

Driver access allows you to:


- View Resettable and Non Resettable sales data.
- Send a wireless DEX read.
- Manage or Audit the existing Planogram.
- Home all Un-homed Motors.

For access to all other service modes use PIN # 3333



How Do I Access the Service Modes?

- If PIN **3333** is entered and **No Errors Exist**, the home screen for the programming menu appears allowing access to the service Icons.
- Each of the icons on the screen represent a tiered menu that provides access to the menus under the corresponding heading.
- Pressing an Icon on the screen provides access to that menu.



How do I use the TouchScreen in the Service Mode?


- For Programming purposes the Merchant Media platform uses the 7" LCD touch screen and a series of icons to provide access to the Service Modes.
- Touching an icon will take you to the top level menu for that Service Mode.
- The concept of the touch screen and the use of icons is similar to many devices that feature touch screen technology.
- A successful touch of an icon will change the color of the icon, and sound a beep to acknowledge acceptance of the touch on the screen before proceeding to the selected menu.



How do I use the TouchScreen in the Service Mode?


Main Menu

- Across the top of the Main Service Menu is a series of four icons that will always be present when in the service menu.
 - The left arrow returns you to the prior menu
 - The small house icon returns you to the Main Service Menu
 - The Key icon is not currently used.
 - The Power icon is not currently used.
- The content of the Main Menu area will change depending what menu you are in. This helps you remember which menu you are in.



How do I use the TouchScreen in the Service Mode?

- All the features normally associated with a touch screen, its icons and menu bars are possible, including:
 - Touching an icon to toggle it's current state (On to Off, Yes to No, etc), or
 - Touching a menu item to access another level of the tiered menu system.
 - Alpha & numeric keypads will pop up when required for input.
 - Confirmation boxes will appear to confirm an item to be added or deleted.
- Another feature of this screen is that it shows the current time and date, and current Atlas LE board software revision at the bottom of the screen.



Menu Chart

Service Mode Menu Chart

Menus 1 to 6



Non Resettable Sales Data
 Resettable Sales Data
 Events
 Identification Number
 SureVend™ Corrected

Shows Errors w Time Date

Test Vend
 Coin Return Motor
 Surround Lighting Test
 Screen Test
 Refrigeration System
 NFC/MagTeck Head Test
 Cashless System Test
 Health Control Test
 SureVend Calibration
 Motor Test Summary
 Detailed Motor Test
 Lighting Relay
 Keypad Test



Individual Selections
 Entire Machine
 Price Tray 1
 Price Tray 2
 Duplicates for all trays

Selection Configuration
 Space to Sales (FIFO)
 Universal Product Code
 Shopping Cart Setup
 View Planogram
 Remove Product Library
 Couple Motors
 SureVend
 Browse Categories
 Browse All Products

Free Vend
 Winner Vend
 Combo Vend
 Token Enabled
 Rapid Vend
 Multi Vend Discount
 Skip Main Menu
 Select Theme



Menu Chart

Service Mode Menu Chart

Menu 7 to End



Coins In/Out
 Bill Validator
 Coin Mechanism
 Card Reader
 Bill Acceptance
 Declining Balance
 Change Without Purchase
 Accept On Low Change
 Low Change Message
 Credit For Failed Vend
 Card Revalue

Machine Information
 Time & Date
 Language
 DTS
 Software Updates
 Backup/Restore
 Copy Configuration
 Custom Configurations
 Screen Brightness
 Led Color
 Idol Timeout
 Advertisements
 Custom Messages
 Configuration Version
 Refrigeration Settings


Enter Pin
 Change Route Pin
 Change Operator Pin




Time of Day Events
 Backup Events
 Power Save Events

Send Dex
 Ping Server
 Sync Time w Server
 Get Network Status
 Send Log Files
 Update Configuration
 Load Network
 Get Cashless Terminal Cfg
 Enable Mesh
 Assign Unit
 Un Assign Unit

Peripheral Firmware Info
 SureVend Version
 I/O Board Version
 LE Board





Data Recall Menu

- The Data Recall Menu permits the operator to review a variety of accountability and operational information including:
 - Non Resettable Sales Data
 - Resettable Sales Data
 - Events
 - ID Numbers (boards & peripherals)
 - SureVend Corrected Vends





Data Recall Menu

Non Resettable vs Resettable Sales Data


The Non-Resettable and Resettable data screens are exactly the same and therefore not duplicated in this programming guide. There is one additional menu in the Resettable menu, Clear Data. This menu allows you to reset back to zero the resettable data. As a default the Resettable Data is also reset each time the machine successfully transmits a DEX file. The Non-Resettable Data can not be reset.

Non Resettable Data



Resettable Data





Non Resettable Sales Data

+

or


Resettable Sales Data

Data Recall Menu

Overall Totals

Touch Overall Totals



The screen will show a summary of the Overall Totals
Press the  to return to the previous menu

		#
Sales	\$50.00	5
Discounts	\$0.00	0
Surcharge	\$0.00	0
Test Vend	\$180.00	18
Free Vend	\$0.00	0
Total	\$230.00	23



Non Resettable Sales Data

+

or

Resettable Sales Data



Data Recall Menu

Data by Tray

Touch By Tray

Touch a tray number to see the sales data for that tray.

Totals for the tray selected will be shown on the display. Press the left arrow to exit



		#
Sales	\$30.00	3
Discounts	\$0.00	0
Surcharges	\$0.00	0
Test Vend	\$0.00	0
Free Vend	\$0.00	0



+

Non Resettable Sales Data

or



Resettable Sales Data


Data Recall Menu

Data by Product

Touch By Product to view sales data By Product.

Touch any tray to see the sales data for that tray.





+


Non Resettable Sales Data
or
Resettable Sales Data


Data Recall Menu

Data by Product

The UPC code will show up when used, along with the selection number. Touch a selection on the keypad to view Sales Data by Product. Use the arrow on the right to scroll down to additional selections.

Totals for the selection chosen are shown on the display, including the last vend with the time & date. Press the left arrow to exit





Non Resettable Sales Data

+

or


Resettable Sales Data

Data Recall Menu

Cash Totals

Touch Cash

The value and number of cash sales will be shown on the screen below.



		#
Cash In	\$2.00	___
To Cashbox	\$0.00	___
To Tubes	\$0.00	___
Bills In	\$2.00	___
Dispensed	\$0.00	___
Manual Dispensed	\$0.00	___
Sales	\$50.00	5
Discounts	\$0.00	0
Surcharge	\$0.00	0
Overpay	\$0.00	0



Non Resettable Sales Data

+


or

Resettable Sales Data

Data Recall Menu

Cashless Sales Data


Touch Cashless



The screen will show the Cashless Sales and the number of Cashless Vends by vend type, including Revalue if applicable

A screenshot of the Cashless Sales Data table. The table has four columns: Vend Type, Amount, and Count. The data is as follows:

		#
Sales	\$0.00	0
Discounts	\$0.00	0
Surcharge	\$0.00	0
Revalue	\$0.00	0



Non Resettable Sales Data


+

or

Resettable Sales Data

Data Recall Menu Token Sales Data

Touch Token to view the Token/Coupon Totals.



This Screen allows you to view Token sales, both by value and number of Tokens/Coupons vends.

Tokens and Coupons are both considered Tokens in accountability and setup. See Token setup in this manual.

Note: This menu only show up if Tokens/Coupons are enabled in the monetary menu under Bill Acceptance.

		#
Vend Tkn	\$0.00	0
Value Tkn	\$0.00	0
Overpay	\$0.00	0



+


Non Resettable Sales Data
or
Resettable Sales Data

Data Recall Menu

Bills Sales Data

Touch Bill Data

This Screen below allows you to view information about bills by denomination, both accepted and paid out when using a validator or recycler. Also included is the current value of bills stored in a recycler cassette.



Data Recall

	In	Out
One	\$0.00	\$0.00
Two	\$0.00	--
Five	\$0.00	\$0.00
Ten	\$0.00	--
Twenty	\$0.00	--
Fifty	\$0.00	--
Hundred	\$0.00	--
Recycler Contents		\$28.00




+ Resettable Sales Data

Data Recall Menu

Clear Resettable Data

- There is one additional menu in the Resettable Menu that is not in the Non-Resettable Menu, Clear Data.
- This menu allows you to clear the Resettable Data. The Non-Resettable Data can not be cleared.
- The resettable data is also cleared each time the machine successfully transmits a DEX file.





Events

Data Recall Menu

Events

Event History

This menu allows the operator to review the most recent times for the following events:

Touch Power Loss or Door Open History to view a historical list of events.

The following information will show without entering a Menu.

- Last Data Clear
- Last Vend Information
- Last Price Change
- Last Clock Set
- Last Health Control Event (if set to refrigerated).





+ Events

Data Recall Menu

Events – Power Losses

Touch Power Loss History



Power Losses are shown on the display including Duration, Date and Time

Duration	Date	Time
42 hours 21 min	08/01/13	18:02:46
2 hours 30 min	07/01/13	06:05:21



+

Events

Data Recall Menu


Events – Door Events

Touch Door Events History



The Door Events are shown on the display including Date and Time

Event	Date	Time
Door Open	08/01/13	18:02:46
Door Close		
Door Open		
Door Close		
Door Open		
Door Close		




+ Identification Numbers

Data Recall Menu

Identification Numbers

Touch Identification numbers

All Items attached to the controller using MDB communications will be shown. Press the left arrow to exit.





+ SureVend™ Corrected Vends


Data Recall Menu

SureVend™ Corrected

SureVend™ Corrected

This menu allows the operator to review the number of SureVend™ Corrections by:

- Machine/Tray Totals.
- By product.
- The last corrected vend information is viewable without entering the menu.






+ SureVend™ Corrected Vends

Data Recall Menu SureVend™ Corrected

Touch SureVend™
Corrected Vends



Touch Machine/Tray Totals
to see overall totals



The display will show
resettable & non resettable
SureVend™ corrected totals
by Machine and Tray

	R	NR
Machine Total	0	0
Tray #1	0	0
Tray #2	0	0
Tray #3	0	0
Tray #4	0	0
Tray #5	0	0
Tray #6	0	0
Tray #7	0	0



Data Recall


+ SureVend™ Corrected Vends

Data Recall Menu SureVend™ Corrected

Touch By Product to view detailed SureVend™ information by selection.

Touch a tray to view SureVend™ corrected information by selection

The display will show resettable & non resettable SureVend™ corrected totals by Selection number



Data Recall

	R	NR
201	0	0
202	0	0
203	0	0
204	0	0
205	0	0
206	0	0
207	0	0
208	0	0
209	0	0
210	0	0
211	0	0
212	0	0




Diagnostics Menu

- Touching the Diagnostics Icon will cause the Diagnostics screen to appear. This screen will show any existing errors along with time and date the errors occurred.
- The Icon will be Red when there are errors, otherwise it will be gray like the rest of the icons.
- The diagnostics screen automatically appears when entering the service mode if errors exist.
- The errors do not need to be cleared, when an error is corrected it will automatically be deleted from the error list.
- If the error screen is full, a down arrow will appear on the right side of the screen allowing the user to scroll down to a second screen of errors.





undefined	time	date
SureVend Comm Error	20:17	09 May
Coin Return Motor	18:32	09 May




Test Menu

Test Menu

- Touch the Test Icon from the main menu to access the Test Menu.
- Touch any of the menu items listed on the Test Screen to access the test menu for that item.
- Touch the down arrow to the right side of the screen to scroll down to the additional menu items capable of being tested.







Test Menu


Test Vend

Touch Test Vend



Touch SureVend™ to toggle between enable or disable for the test.






Test Menu


Test Vend

Touch Select Product and a keypad will appear allowing you to enter the selection number to be tested, followed by Done



Touch Start Vend to test the selection entered.






Test Menu


Coin Return Motor

Touch coin return Motor



The display will show “Coin Return motor should now be running”,







Test Menu


Surround Lighting Test

Touch Surround Lighting Test

Touch Perform test to confirm the Lighting Test

The Surround lights should be changing colors






Test Menu


Screen Test


Touch Screen Test



The display will illuminate with Red, Green & Blue.

Press X to Exit.








Test Menu

Refrigeration System

Touch Refrigeration System Test **Note:**
the refrigeration test menu will not
appear if the machine is set to ambient.

The display will show the current
temperature for all the sensors in the
machine as well as the current
refrigeration Status ON/Off/Idle/Defrost
and Time left on health if applicable.





Test Menu

Refrigeration System

Touch Refrigeration Deck Test to Start the Test.

Note: The Refrigeration Deck Test will only function with the Monetary door open, and the glass door closed

\Test\Test

Cabinet	30 °F
Return Air	40 °F
Evaporator Coil	33 °F
Condenser Inlet	35 °F
Refrigeration State	Idle
Refrigeration Deck Test	Idle

NOTE: Refrigeration Deck Test will only function with the door open.

Touch the appropriate menu bar to toggle the Compressor or Evaporator Fan On/Off

\Test\Test

Toggle Compressor


Current Status - Off

Toggle Evaporator Fan

Current Status - Off

Warning! Compressor should not be turned on if it has been less than two minutes since it was last energized.

The Evaporator Fan will remain on at all times that the Compressor is energized.





Test Menu

MagTeck Head Test

Touch NFC/MagTeck
Head Test

Swipe or Tap a card to test. The display will keep track of how many good swipes or taps versus bad, 28 good swipes or taps out of 30 is considered passing





Test Menu

Cashless System Test

The Cashless System Test detects


- A bad or missing Cashless Terminal Configuration file,
- If the machine is assigned, problems with the card itself and,
- If there is a valid communications path to the credit card processing server.
- This test is limited and is not designed to catch system errors that involve actual card authorization for a vend.
 - (For example, swiping a membership card may give a 'System is OK' status in the test, but it's not valid as a credit card).

Touch Cashless System Test



Swipe card or view most recent swipe status.






Test Menu


Health Control Test


Health Control Test not defined at the time this user guide was written.

Touch Health Control Test



To start the test, touch the menu bar to toggle Health Control Test to on.






Test Menu


SureVend™ Calibration

Touch SureVend™ Calibration. If SureVend™ is disabled or disconnected it will show the status on the screen below.



Number 1 is the sensor closest to the trays. Number 9 is closest to the glass. Fours, fives and sixes are all good. When you get into the teens that indicates a partial blockage. Zero indicates a complete blockage or bad sensor.


Test	
Sensor number	
1	4
2	4
3	4
4	4
5	4
6	4
7	5
8	5
9	4



Test Menu


Motor Test Summary

Touch Motor Test Summary (in some cases you may have to touch the down arrow to scroll down to the menu bar).



The display will show the status of the Motors. You also have the option to Home All motors or Home the Motors on an individual tray by touching one of the Icons below.






Test Menu


Detailed Motor Test

Touch Detailed Motor Test (in some cases you may have to touch the down arrow to scroll down to the menu bar).



Touch the tray you wish to view







Test Menu

Detailed Motor Test

- **“H”** indicates that spiral is homed
- **“X”** indicates the spiral is present, but not configured
- **“F”** indicates spiral is a FIFO member
- **“C”** indicates spiral is coupled
- **“ERR”** indicates error is present for the spiral.
- **“W”** indicates spiral is a Winner member, Token member or a Combo member.
- **“T”** indicates spiral is a Time of Day event member.







Test Menu

Light Relay


Touch the highlighted down arrow to scroll down to Light Relay Test



Touch Light Relay



Touch Toggle Cabinet Lighting to toggle the light relay between Off and On. Press the left arrow to exit






Price Menu

From the Main Menu Touch the Price Icon to access the price setting Menu.

There are three options for setting prices:

- By Tray
- Entire Machine
- Individual Prices





Price Menu

Setting Prices by Tray

Setting Prices by Tray

- Touch the tray you wish to Price.
- A numeric keypad will appear on the screen along with a window to enter the price.
- The left arrow above Done is your backspace key.
- Use the numeric keypad to enter the price for the tray being set and press Done to save.






Setting Entire Machine Prices

Setting Prices by Entire Machine

- Touch Entire Machine on the display.
- A numeric keypad will appear on the screen along with a window to enter the price.
- The left arrow above Done is the backspace key.
- Use the numeric keypad to enter the price for the Entire Machine and press Done to save.







Price Menu

Setting Individual Prices

Step 1 –
Touch Individual Prices



Step 2 –
Touch a Tray



Step 3 –
Touch a Selection






Price Menu

Setting Individual Prices

Setting Individual Prices


- A numeric keypad will appear on the screen along with a window displaying the current price.
- The left arrow above Done is your backspace key.
- Use the numeric keypad to enter the new price for the that selection, Press Done to save.





Product Configuration

- The Product Configuration menu provides access to the following modes in the machine:
 - Selection Configuration
 - First in-First out (FIFO) Setup
 - UPC Setup (Package UPC)
 - Shopping Cart Setup
 - View Planogram
 - Remove Product Library
 - Couple Motors
 - SureVend™
 - Browse Categories
 - Browse all Products







Product Configuration

Selection Configuration - Autoconfiguration

Touch Selection Configuration to enter the menu.



To automatically configure the motors
Touch Perform Autoconfiguration .



Touch Start Autoconfiguration and the controller will scan all the motors and automatically enable all motors that are detected.







Product Configuration

Selection Configuration - Autoconfiguration

The display will say working then change to Autoconfiguration Finished. Touch View Results.

Choose a Tray to view results .

All Selections with a checkmark were found and added to the configuration



Caution: Performing an **Autoconfiguration** on a machine will reset all prices to the factory default of \$99.95, and remove any existing coupled motors!




Product Configuration

Selection Configuration – Set Up Selections

Touch Setup Selections to manually configure selections.

Select the desired tray to view or change the enabled selections. Disabling a selection can be used when a bad selection motor is present

Use the keypad to add or remove a checkmark. Motors with a checkmark are part of the configuration. In some cases the down arrow will be lit, indicating you can scroll down for additional selections.





Product Configuration

FIFO

First In, First Out (FIFO)

- **FIFO** allows you to program your machine to run multiple selections as a single selection.
- No matter which selection ID of the group is entered, the Merchant™ will vend round-robin from the group of spirals, skipping selections that are out-of-service.
- This feature can provide a First-In-First-Out for perishable foods.
- It also helps to prevent one spiral of duplicate selections from going empty before the others of the same selection.
- **Note: Ensure that all selections chosen for each FIFO group are the same price. If not, the machine will price all selections to the highest price in the group.**





Product Configuration

FIFO Continued

The FIFO menu allows you to:

- Add a Group
- Delete a Group
- Edit a Group
- View Existing Groups (Mappings)





Product Configuration

FIFO – Add a Group

Touch Add a FIFO Group



Touch the desired tray to add selections to the Group.



All available selections are shown. Touch the selection to add a checkmark to the motors to be part of the Group. In some cases the down arrow will be lit to scroll to additional selections.






Product Configuration

FIFO – Add a Group

All available selections are shown. Touch a selection to add a checkmark to the motors that will be part of the Group. In some cases the down arrow will be lit allowing you to scroll to additional selections. Press the left arrow to go back and add more selections from another tray or to Create the Group.



Note: It is Important that you Touch Create New Group after you have chosen the selections to be part of the Group or no Group will be created.






Product Configuration

FIFO – Delete a Group

Touch Delete Group to Delete a FIFO Group

Touch the desired Group to be Deleted.

A confirmation box will appear, Touch Yes to confirm or No to cancel





Product Configuration

FIFO – Edit a Group

Touch Edit a FIFO Group



Touch the desired group to Edit.






Product Configuration

FIFO – Edit a Group

Select the Tray you wish to Edit

Touch selections to check or uncheck them from the group. Press the left arrow when finished to exit.

Be sure to save the changes by Touching Save Group





Product Configuration

FIFO – Mappings

Touch FIFO Mappings.



Touch a tray to view the current mappings.



The display will show the current Mapping for the motors on the tray selected.






Product Configuration

Universal Product Code

To View or change the current UPC Touch Universal Product Code.



Select the tray that the product is on that you wish to view or change.



The display shows the current 12 digit UPC assigned to the selections, choose the selection you wish to change.






Product Configuration

Universal Product Code

- For a UPC code to be valid, The UPC Code must be in the Library or Planogram loaded in the machine.
- Deleting a UPC Code will cause that selection to show a generic picture on the display and no nutritional information will be available for that selection.
- You can use the same UPC Code for multiple selections if you want two or more selections of the same product.
- Use the Numeric Keypad to enter the 12 digit UPC code you wish to add.
- The left arrow above Done serves as a backspace key.
- Press Done to save and X to exit without changes.
- Use the Aa key to switch to Alpha & #@ for symbols.






Product Configuration

Shopping Cart Setup

- This menu provides access to set up the Shopping Cart.
- Shopping Cart permits the user to select multiple items, and place them into a virtual “Shopping Cart” and purchase them in a single financial transaction.
- Recommended Shopping Cart maximum size is 3 items.
- Max Fund amount can should be calculated by multiplying the highest vend price in the machine times the Shopping Cart size.

Note: When Rapid Vend is turned on under the Special Vend Mode the Shopping Cart function is automatically disabled.



Continued 





Product Configuration

Shopping Cart Setup

Touch Shopping Cart Size. Use the numeric keypad to enter the quantity of items allowed in the Shopping Cart. Press Done when finished

Select Max Fund Amount to set the maximum amount of funds in the cart. We recommend the cart size times the highest vend price. Press Done when finished.






Product Configuration

Shopping Cart Setup

Note: The Max Fund amount menu can also be utilized allow the machine to be used as a bill changer.

For example, if you wish to allow for change of a \$10.00 bill, you can set the Shopping Cart Max Fund Amount to \$10.05, which will allow the machine to stack a \$5 or \$10 bill. When the coin return is pressed, change is returned. The same idea applies to a \$5 or \$20 bill, using \$5.05 or \$20.05 respectively.

If Rapid Vend is turned on you must turn it off for the shopping cart menu to appear, set the amount to be paid back in this menu, then turn Rapid Vend back on if desired.






Product Configuration

View Planogram

Touch Planogram to View an existing Planogram



Touch a tray to view the existing Planogram



If a Planogram has been loaded into the machine, a picture of the product for each selection will be shown. If not a generic picture will be shown






Product Configuration

Remove Product Library

Touch Remove Product Library to remove an existing library.



A confirmation box will appear, Touch Yes to confirm or No to cancel






Product Configuration

Couple Motors

Touch Couple Motors
to enter the Menu.



All available selections that can be coupled are shown. Use the keypad to add a checkmark to the selections to be coupled. In some cases there may be a down arrow on the right side of the key pad to scroll to additional selections.






Product Configuration

SureVend™

SureVend™

- ***The SureVend™ Bin Sensor ensures a positive vend every time.***
- The sensor is installed in the delivery bin and senses that a product has been delivered.
- If no product was delivered, the spiral will make two additional turns.
- If the product is not delivered after three attempts, the machine will allow the customer to make another selection or press the coin return and receive their change back.






Product Configuration

SureVend™ - Current State

Touch SureVend™ to enter the SureVend™ Menu.



Touch current state to toggle between on and off.






Product Configuration


SureVend™ Options

Touch SureVend™ Options to toggle between Must Surevend and Optional SureVend™



Option SureVend™, if the SureVend™ stops working the machine will stay in order and the spiral will turn only once.

Must SureVend™, if the SureVend™ stops working, the entire machine will go out of service.







Product Configuration

SureVend™

Touch to change the Anti-Jackpot (AJT) timer, the default time is 10 minutes

Use the Keypad to enter a new time (in minutes) and press Done. If a spiral turns 3 times and no product is detected by the SureVend™ sensor, that selection will be unavailable for the period of time set. After the AJT is expired, the selection will be available for purchase again, The SureVend™ will protect the customer from losing money during this time.






Product Configuration

SureVend™

Touch to change the Anti-Jackpot Trigger, the default is 2.

The Anti-Jackpot Trigger is how many consecutive selections the machine will allow to turn 3 times before assuming there is a SureVend™ issue and take the money. The default setting is 2. Use the keypad to enter the new setting and press Done.






Product Configuration

Browse Categories

Browse Categories

- The Browse Categories menu allows your customer to view nutritional information by category.
- This menu will enable nutritional information categories for all selections that have valid UPC code assigned to a selection.
- If you want the customer to browse all products (250) in the library, not just the products assigned to selections page down to the Browse all Products menu to enable.
- The library of UPC codes installed must have had a category associated with that UPC code when the library was created for the Browse Categories option to work.
- *The Skip Main Menu option under the Special Vend Modes icon must be set to no for Browse by Categories to work.*







Product Configuration

Browse Categories

Touch Browse Category to access the menu to enable or disable categories



Touch a menu bar to add or remove a checkmark from the categories you wish to enable/disable






Product Configuration

Browse All Products

Browse all Products

- This feature allows the consumer browse the nutritional information for entire contents of the product library installed, all 250 items as a default.
- You do have the option to go through and enable or disable selections by categories or by specific product.
- If you want the customer to browse only the products in the machine do not enable this menu, use the Browse Categories menu.
- The library of UPC codes installed must have had a category associated with that UPC code when the library was created for the Browse Categories option to work.
- *The Skip Main Menu option under the Special Vend Modes icon must be set to no for Browse by Categories to work.*








Product Configuration

Browse All Products

Toggle Browse all Products to yes to view all product in the Library. Touch a category to enable or disable specific items for browsing.

This screens allows you to enable or disable specific products for browsing






Special Vend Modes

Special Vend Modes provides access to:

- Free Vend
- Winner Mode
- Combo Vend
- Token Enable
- Rapid Vend
- Multi Vend Discount
- Skip Main Menu
- Select Theme






Special Vend Modes

Free Vend

Free Vend

- Touch Free Vend to toggle the free vend setting between OFF and ON.
- When set to ON all items will be free until turned off.





Special Vend Modes

Winner Mode


Winner Mode

When Winner Mode is turned on:

- The customer will receive their product and get their money back or an additional item (programmable) at no charge.
- The display will prompt the customer if they are a winner.
- The frequency of a winner is programmable.



Continued




Special Vend Modes

Winner Mode

Winner Mode

By touching a menu bar on the screen you can:

- Add a Group
- Delete a Group
- Edit a Group
- View the current selections assigned to a Winner Group






Special Vend Modes

Winner Mode – Add a Group

Adding a New Winner Group:

- To add a New Winner Group you must first set the Mode, Frequency, Prize and Selections that are to be part of the group.
 - Once selections are set, Touch Add a New Winner Group to create the Group
- Note: You will not be allowed to add a new group without assigning selections first.*

The screenshot shows the 'Special Vend Modes' app interface. At the top, there are navigation icons: a back arrow, a home icon, a key icon, and a power icon. Below the title 'Special Vend Modes', there is a large button labeled 'Add New Winner Group' with the text 'nothing selected' and a right-pointing chevron. Underneath, the 'Trays' section is visible, containing four rows of settings: 'Mode' with a dropdown menu currently showing 'prize', 'Frequency' with the value '100', 'Prize' with the value '101', and 'Parameters' which includes four rows for 'Tray #2', 'Tray #3', 'Tray #5', and 'Tray #7', each with a right-pointing chevron.




Special Vend Modes

Winner Mode – Add a Group

Touch Mode to toggle between Prize and Winner. If set to Winner the customer will receive their money back based on the frequency set

If set to Prize, another menu item will appear on the display. This is where you choose the item the customer will win based on the frequency set.







Special Vend Modes


Winner Mode – Add a Group

Touch Frequency to choose how often a customer will be a winner.



Use the keypad to enter the Frequency of a winner and press Done.







Special Vend Modes

Winner Mode – Add a Group

Touch Prize to enter the selection number that will contain the prize. This menu will not be shown if winner was selected instead of prize

Use the keypad to enter the selection number that will contain the prize and press Done to save.








Special Vend Modes

Winner Mode – Add a Group

Select the tray containing the selections you want to work with the Winner Mode event.

Use the keypad to Select All, Clear All or add a checkmark to the selections to work with Winner Mode. Press the  to exit and choose another tray to add selections to if desired.






Special Vend Modes

Winner Mode – Add a Group

Save your work!

After entering your Parameters and selections for Winner Mode you must touch Add New Winner Group. If you do not touch Add New Winner Group before exiting, your settings will not be saved!


The screenshot shows the 'Special Vend Modes' app interface. At the top, there are navigation icons: a back arrow, a home icon, a key icon, and a power icon. Below the title 'Special Vend Modes', there is a large button labeled 'Add New Winner Group' with a right-pointing chevron and the text 'nothing selected' below it. Underneath, the 'Trays' section is visible, containing three input fields: 'Mode' (set to 'prize'), 'Frequency' (set to '100'), and 'Prize' (set to '101'). The 'Parameters' section follows, with four rows for 'Tray #2', 'Tray #3', 'Tray #5', and 'Tray #7', each with a right-pointing chevron.




Special Vend Modes

Winner Mode – Delete a Group


Touch Delete a Group




Touch group to Delete



Touch Yes to confirm or No to cancel






Special Vend Modes

Winner Mode – Edit a Group

Touch Edit a Group



Touch the Promotion you wish to Edit



Touch the item you wish to Edit and press OK. **Save the changes when you are done editing by selecting Save Group!**






Special Vend Modes

Winner Mode – Winner Selections Assigned


Touch Winner Selections Mappings to view selections currently assigned to Winner Groups.




Touch the tray you wish to View.



The display will show you what groups each selection on the tray is assigned to.






Special Vend Modes


Combo Vend

Combo Vend

- The Combo Vend Menu allows you to set up a selection to be offered in conjunction with another selection.
- A combo vend can be a combination of two or three products.
- All products in a combo vend can be discounted or just the last item.
- Items can be discounted by a value or percentage.
- Touch Combo Vend to access the Combo Vend set up mode.



Continued



Special Vend Modes


Combo Vend

How Combo Vend Works

1. Select the first item and place it in the “Shopping Cart” by pressing the shopping cart icon.
2. Select the second item and place it in the “Shopping Cart”, if a third item is part of the Combo Vend it must be placed in the cart also.
3. Insert money and press OK
4. All items in the cart will be delivered.
5. The discount will be displayed and returned as change.

Rules for setting up Combo Vend

- The Rapid Vend feature must be set to NO, so that the “Shopping Cart” function is activated.
- Both “Shopping Cart” Value & number of items must be set high enough to accommodate the needs of the Combo Vend Promotion.
- Two items from the same group will not get a discount.
- For two of the same item to be discounted that item must be in group 1 & 2.





Special Vend Modes

Combo Vend

The Combo Vend Menu allows you to:

- Toggle the discount type between value and percentage.
- Add a new Combo Vend.
- Delete an existing promotion.
- Edit an existing promotion.
- View the existing selections set for a Combo Vend promotion.






Special Vend Modes

Combo Vend – Discount Type

Discount Type

- Touch Discount Type to toggle the Discount Type between type between Value and Percentage.
- Based on your selection in this menu the display will say discount percentage or value when you choose the Add New Combo Menu.
- You can create & save both Discount and Value promotions but you must come back to this screen to change the discount type before you add a new combo vend if the discount type is different.





Special Vend Modes


Combo Vend – Add a New Combo Vend

Touch Add New Combo Promotion



Note: You must set up your combo vend options before you can save them by Touching Add New Combo Promotion. See step by step instructions on the following pages.






Special Vend Modes


Combo Vend – Add a New Combo Vend

You can choose to have 2 or 3 selections as part of a combo vend group. Touch Number of Groups in Promotion to toggle between 2 and 3. If you choose 3, the customer must buy three items that are part of the group for the discount to apply.



Use the keypad to enter the Discount Percentage or Value or of the discount. The screen will say either discount or value based on your choice of discount type in the previous menu. Press Done to save.





Special Vend Modes


Combo Vend – Add a New Combo Vend

Discount All

- Touch Discount All to toggle between Yes and No.
- If you choose **Yes** all items that are part of a combo vend group will all be discounted by the amount set.
- If you choose **No** only the last item in the discount group will be discounted.

A screenshot of a mobile application interface for adding a new combo promotion. At the top, there are four navigation icons: a back arrow, a home icon, a key icon, and a power icon. Below the icons is the title "...Add New Combo Promotion". The main content area consists of several rows of controls:


- "Add New Combo Promotion" with a right-pointing chevron and the text "Groups Not Selected" below it.
- "Number of Groups in Promotion" with a slider set to 2.
- "Discount Percentage" with a value of 0.
- "Discount All" with a toggle switch set to "Yes".
- "Edit Group 1" with "0 Selected" and a right-pointing chevron.
- "Edit Group 2" with "0 Selected" and a right-pointing chevron.
- "Enable Custom Message" with a toggle switch set to "Yes".




Special Vend Modes


Combo Vend – Add a New Combo Vend

Touch the menu bar set selections for group one, group two and group three. Group 3 will only appear if the number of groups is set to three.




Choose the tray or trays that contain selections to be added to the group.






Special Vend Modes

Combo Vend – Add a New Combo Vend


- To add all selections on the tray to the group Touch Set All.
- To remove all selections on the tray from the group Touch Clear All.
- Touch any selection number to add or remove a checkmark from that selection. A checkmark means that selection will be active for the Combo Vend group.
- In some cases there will be a down arrow on the right side of the screen, touching it will allow you to scroll down to additional selections on the shelf that do not fit on the screen.
- Press the  key to exit and choose another tray to add selections to if desired.





Special Vend Modes

Combo Vend – Add a New Combo Vend


After entering all selections for all groups Press the  key to go back to the screen on the right.

If you are setting a custom message for Combo vends continue to the next screen.

Important: If you are not setting a custom message, be sure to save your Combo Vend settings by Selecting Add New Combo Promotion. If you fail to do so your settings will not be saved! You must have selections added into all groups before you can save by Touching Add New Combo Promotion.

The screenshot shows a mobile application interface for adding a new combo promotion. At the top, there is a navigation bar with four icons: a back arrow, a home icon, a key icon, and a power icon. Below the navigation bar, the title is "...Add New Combo Promotion". The main content area consists of several rows of settings:

- Add New Combo Promotion**: A button with the text "Groups Not Selected" and a right-pointing chevron.
- Number of Groups in Promotion**: A slider control set to the value 2.
- Discount Percentage**: A text input field containing the value 0.
- Discount All**: A toggle switch set to "Yes".
- Edit Group 1**: A button with the text "0 Selected" and a right-pointing chevron.
- Edit Group 2**: A button with the text "0 Selected" and a right-pointing chevron.
- Enable Custom Message**: A toggle switch set to "Yes".




Special Vend Modes

Combo Vend – Enable Custom Message

Touch Enable Custom Message to toggle to Yes to set a custom message. This message will be displayed when Combo Vend is active.






An additional menu bar will appear, touch Message to create the Custom Message






Special Vend Modes

Combo Vend – Enable Custom Message

- A keypad will appear on the screen along with a window to enter the Message.
- Use the keypad to enter the Message.
- Press **Done** when finished
-  is your backspace key.
-  is your exit key.
-  switches the keypad to numeric.
-  switches the keypad between uppercase & lowercase.
-  switches the keypad to symbols and numbers.



Continued 




Special Vend Modes

Combo Vend – Enable Custom Message

After entering your custom message and touching done the display will switch back to the screen on the right.

Important: Save your Combo Vend settings by touching Add New Combo Promotion. If you do not save your settings they will be gone!






Special Vend Modes

Combo Vend – Delete Promotion


Touch Delete an existing promotion




Select the promotion to Delete



Press YES to confirm or NO to cancel






Special Vend Modes

Combo Vend – Edit Promotion

Touch Edit Promotion

Select the promotion you want to Edit.

Select the item you wish to Edit. **Save the changes when you are done Editing by pressing Save Promotion.**







Special Vend Modes


Combo Vend – View Assigned Selections

Touch Combo Vend Selection Mapping to view selections currently assigned to a combo Vend

Select the tray you wish to View

The display shows each selection on the tray and the promo # it is assigned to.






Special Vend Modes


Token Enable

Token Enable

- This Menu allows you to choose the selections the customer is permitted to purchase with Tokens or Coupons.
- *Note: Tokens must be enabled in the Monetary menu under Bill Acceptance for Tokens or Coupons to work.*
- Your Coin Mechanism or Bill Acceptor must be tuned and/or configured to accept your Token or Coupon.




Continued 



Special Vend Modes

Token Enable

Touch Token Enabled to assign selections to work with Tokens/Coupons




Select the tray you wish to assign selections to work with Tokens/Coupons



Touch select all, clear all or individual selections to add a checkmark to the selections that you want to work with Token/Coupons





Special Vend Modes


Rapid Vend

Rapid Vend Mode

- When Rapid Vend Mode when set to YES the machine will work as a single vend only merchandiser.
- The product will vend as soon as a selection is made without touching Purchase.
- Touch Rapid Vend to toggle between Yes and No

Note: The shopping cart is automatically disabled when Rapid Vend is turned on, and will prevent consumers from making multiple selections during a single transaction.






Special Vend Modes

MultiVend Discount

MultiVend Discount

- When MultiVend Discount is set to YES all selections in the shopping cart with two or more items are discounted by the percentage specified.
- This discount applies to all selections and is not settable by specific selections.
- This discount, once enabled, will be on until it is turned off, it is not settable by time of day or days of week.
- If you want to set specific selection combinations to be discounted or discounts by time of day see the Combo Vend or Timed Events Menus in this guide.







Special Vend Modes


MultiVend Discount

Touch the MultiVend Discount Enable menu bar to toggle to yes.

A Percent Discount menu bar will appear. Touch the menu bar to change the Percentage of Discount.

Use the keypad on the display to enter a new discount percentage. Press Done when finished.







Special Vend Modes

Skip Main Menu

Skip Main Menu

- When Skip Main Menu is set to yes (disabled) and the idle loop (standby screens) screen is pressed the screen will immediately transition to the numeric keypad screen bypassing the Main Menu screen shown to the right.
- When plan-o-gram libraries or multiple promotions are not used this is an extra screen that is not necessary and eliminating it speed up the vend process
- The default for Skip Main Menu is Yes, meaning the menu is skipped.
- Touch Skip Main Menu to toggle between Yes and NO.





Special Vend Modes

Select Theme

Select Theme

- This Menu allows you to choose from a number of different themes preprogrammed into the controller.
- Touch Select Theme and select one of the following Themes. The factory setting is default.







Monetary Menu

Monetary Menu Icon

- Allows you to program the settings for all credit devices and related functions.
- Touch Money to enter the Menu.








Monetary Menu

The Monetary Menu

- Coins In/Out
- Bill Validator
- Coin Mechanism
- Card Reader A&B
- Onboard Cashless
- Bill Acceptance
- Correct Change Parm
 - Declining Balance
 - Force Vend
 - Accept on Low Change
 - Low Change Message
 - Credit For Failed Vend
 - Allow Customer Overpay
- Stack Bills
- Card Revalue A&B
- Cash Discount






Monetary Menu

Coins In/Out

Touch Coins In/Out menu.



The display will show the coin tube values and counts. Increase the amount of change available by inserting coins to thru the chute on the top of the coin mech. Totals (count and value) for each coin should increase as coins are added.

Coin	Count	Value
0.05	35	\$1.75
0.25	20	\$5.00
0.50	15	\$7.50
1.00	1	\$1.00

0.05 >

0.25 >

0.50 >


1.00 >



Monetary Menu

Coins In/Out


Touch Coins In/Out menu.



This menu can also be used to dispense coins from coin mechanism by touching the menu bar showing the value of each coin.

Coin	Count	Value
0.05	35	\$1.75
0.25	20	\$5.00
0.50	15	\$7.50
1.00	1	\$1.00

- 0.05 >
- 0.25 >
- 0.50 >
- 1.00 >
- Setup channels >



Monetary Menu

Coins In/Out

To set up the channels in your coin mechanism press Setup channels.
This setting is not typically changed from the default of auto detect.

Coin	Count	Value
0.05	35	\$1.75
0.25	20	\$5.00
0.50	15	\$7.50
1.00	1	\$1.00

0.05 >


0.25 >

0.50 >

1.00 >

Setup channels >

Touch Auto Detection to toggle Auto Detection for the coin tubes from ON to OFF (not recommended). This will enable a menu that allows you to turn the coin mechanism channels on and off independently






Monetary Menu

Coins In/Out

Touch a channel menu bar to add or remove checkmarks from the channels. Removing a checkmark from a channel will disable the coin tuned to that channel.

Press down arrow on the right to scroll to the remainder of the 16 channels.






Monetary Menu

Bill Validator Enable

Touch Bill Validator to toggle between **MDB** or **No Bill** validator.



Once communication is established the communication level of the Bill Validator will be shown






Monetary Menu


Coin Mechanism Enable

Touch Coin Mechanism to choose the coin mechanism type. The current setting is shown without entering the menu.



Touch the desired Coin Mechanism option and press Done to save.
Note: Exec is not used in the US.







Monetary Menu Card Reader Enable

Card Reader / Cashless Options

- There are three menu Bars as shown on the right for Card reader and/or cashless options.
- There are two menus for MDB card reader and one for an onboard reader.
- MDB is an add on card reader that plugs into the MDB harness in the machine. Your options in this menu are MDB card reader or no MDB card reader. This option is set under the Card reader Menu Bar.
- Onboard is a swipe built into the front of the machine.
- When using Onboard Cashless an NFC (tap and go) option is available beginning with firmware version 10.9.8.
- Note: It is possible to have two MDB card readers or one MDB and one Onboard reader in the machine at the same time. An example would be a college where you accept both credit cards and a college ID cards that are tied to students accounts.






Monetary

Monetary Menu

Card Reader Enable

Touch Card Reader A or B to choose your MDB card reader option. The current setting is shown without entering the menu.

Touch MDB or No Card Reader, Touch Done to save or X to exit without saving.






Monetary Menu

Onboard Cashless Enable

Touch Onboard Cashless Enable to toggle between Yes and No. An Onboard card reader is a built in card swipe that plugs directly into the Atlas controller at J42.




Continued 




Monetary Menu

Onboard Cashless Enable

- Crane Onboard Cashless accepts NFC (tap and go) transactions beginning with firmware version 10.9.8.
- If you have a separate NFC reader installed, as long as the onboard card reader is assigned, enabled and the NFC reader cable is connected to a USB on the controller the NFC reader will work.
- The radio should be plugged into USB 1.
- We recommend connecting the USB cable for the NFC reader into USB 2.





Monetary Menu

Bill Acceptance

Touch Bill Acceptance to enter the menu. All denominations the Validator is capable of accepting will be shown.

Touch the value on the display to select or unselect the bill/note denominations you wish to accept/not accept. The switches on the Validator must also be enabled. Token must be enabled to accept Tokens or Coupons. You will also need to choose what selections work with tokens or coupons in the Special Vend Modes Menu.








Monetary Menu

Correct Change Parameters

The Correct Change Parameters Menu includes the following submenus:

- Declining Balance
- Force Vend
- Accept on Low Change
- Low Change Message
- Credit for Failed Vend
- Allow Customer Overpay








Monetary Menu

Correct Change Parameters - Declining Balance

Declining Balance

- If Declining Balance is set to Yes the change due back after a vend will remain on the display allowing the customer to add more money to make an additional purchase.
- *Note: If set to Yes, customer may touch cancel to return remaining credit.*
- Touch Declining Balance to toggle between Yes and No.
- Touch  to exit.







Monetary Menu

Correct Change Parameters - Declining Balance

Touch Correct Change Parm's to access the Declining Balance Menu.



Touch Declining Balance to toggle between No and Yes.





Correct Change Parameters - Force Vend

Force Vend


Touch Force Vend to Toggle Between Yes and No.


When Force Vend is set to **No**:

- All money inserted can be paid back by pressing cancel to end the transaction.

When Force Vend is set to **Yes**, a consumer will not be able to receive their credit back when:

- The established credit meets or exceeds the minimum price of the selections in the machine
- Any bills are stacked in establishing credit.
- Any non-tube coins are inserted in establishing credit
- A “No Change Without Purchase” message will be displayed when a consumer attempts to return credit.







Monetary Menu

Correct Change Parameters - Force Vend

Touch Correct Change Params to access the Declining Balance Menu.



Touch Force Vend to toggle between Yes and No.






Correct Change Parameters - Accept on Low Change

Accept On Low Change

- Used to set acceptance of a bill depending on how much change is registered in the coin mechanism.
 - If set to default \$0.00, the machine will only accept a bill when the coin mechanism has enough change to pay back full credit.
 - If a value is set to anything other than \$0.00 bills will be accepted to the set value even though change may not be available (customer may get short changed).





Monetary Menu

Correct Change Parameters - Accept on Low Change

Touch Correct Change Params to access the Declining Balance Menu.




Touch Accept on Low Change to enter the value of money you wish to accept when no change is available. Setting this to anything other than \$0.00 may cause the customer to get short changed. Touch Done to save.







Correct Change Parameters – Low Change Message

Low Change Message

- Used to set the lowest amount registered in the coin mechanism before the display shows “USE EXACT CHANGE”
- Touch Low Change Message to enter lowest value on corresponding line above (default setting of \$1.00 recommended)
- Touch Done to save the setting.
- Touch  to exit this menu mode.



Continued 





Monetary Menu

Correct Change Parameters – Low Change Message

Touch Correct Change Params to access the Declining Balance Menu.


Touch Low Change Message, enter lowest value of change available before the display shows the Low Change Message (setting of \$1.00 recommended) Touch Done to save






Correct Change Parameters - Credit for Failed Vend

Credit For Failed Vend

- Press the down arrow to view lower screen.
- Press Credit for Failed Vend on the keypad to change between the two settings:
 - **Return** = In the event of a failed vend, the credit will be returned automatically.
 - **Hold** = In the event of a failed vend the credit will remain on the machine
- Press Done to save
- Press the  button to exit this menu mode.




Continued 



Monetary Menu

Correct Change Parameters - Credit for Failed Vend


Touch Correct Change Parm
to access the Declining
Balance Menu.



Touch Credit For Failed
Vend to advance to the
next screen



Touch to Return Change or
Hold Credit after a failed vend.
Touch Done to save.







Correct Change Parameters – Allow Customer Overpay

Allow Customer Overpay

- When Consumer Overpay set to Yes, based on other settings in the machine the customer would be allowed to make a purchase even if change is not available. This could result in a potential situation where the consumer gets short changed.
- When Consumer Overpay set to No, the machine will not accept any currency for which it cannot make change, regardless of Low Change Message setting or Accept on Low Change setting.







Monetary Menu

Correct Change Parameters – Allow Customer Overpay

Touch Correct Change Params to access the Declining Balance Menu.



Touch the Menu Bar to toggle Allow Customer Overpay between Yes and No.








Monetary Menu

Card Revalue

Card Revalue

- This Menu will appear when the machine is equipped with a card reader(s) or other monetary device that is capable of having value added.
- Choose the card reader A and/or B that is capable of adding value.
- Touch Card Revalue on keypad to toggle the setting between Off and On.
 - **Off** = Credit cannot be transferred.
 - **On** = Allows credit be transferred.
- Touch  to exit this menu mode.







Monetary Menu

Card Revalue

Touch Correct Change Params to access the Declining Balance Menu.

Touch Card Revalue to toggle reader A and/or B between Off and On.






Monetary Menu

Cash Discount

Cash Discount

- This menu shows your current discount for cash.
- This only applies to onboard cashless transactions, and is chosen in the forms when you set up your telemetry account.
 - The cash discount can not be changed at the machine.
 - The Cash discount can be configured to charge by the item or by transaction.
 - The Cash Discount can be set as either a percentage or a flat fee.
- To enable or change cash discounts contact your Distributor or CMS sales representative.
- When enabled, Cash Discount applies to all products in the machine.
- No discount is applied if any cashless transaction is involved, even in a mixed tender transaction.
- Both Cash and Credit prices are shown at bottom of the shopping cart screen.
- The prices set in the machine and shown in the consumer and service mode screens are the cash sales prices. In other words, the cash discount has already been applied.






Monetary Menu

Cash Discount

Touch Correct Change Params to access the Declining Balance Menu.

The Value of the Cash Discount is shown on the bottom right corner of the Menu bar






System Settings

Systems Settings Menu Icon

- Allows you to program the overall systems functions.
- Touch System Settings icon to enter the Menu.







System Settings

System Settings

- Touching the System Setting Icon from the home screen allows access to the System Settings Menus shown on the two screens to the right.
- Touch the down arrow to scroll to the next menu screen.
- Touch the up arrow to return to the previous menu screen.






System Settings

Machine Information

Touch Machine Information to access Identification numbers used for Dex.








Touch Machine ID or Location ID to assign or change the number. This ID can be text, numeric or a combination both.





System Settings

Machine Information

- A keypad will appear on the screen along with a window to enter the ID or Location information.
- Use the keypad to enter the information.
- Touch **Done** when finished
-  is your backspace key.
-  is your exit key.
-  switches the keypad to numeric.
-  switches the keypad between uppercase & lowercase.
-  switches the keypad to symbols and numbers.







System Settings

Time and Date


Touch the Time and Date menu bar to access the Time and Date Menu.



Touch to set your Time Zone



Touch your Time Zone followed by Done.







System Settings

Time and Date

Touch Time Format to change the Format between 24 hours and AM/PM.



Touch your desired format.
Touch Done to save.







System Settings

Time and Date

Touch the Time menu bar to change the current time .



Touch the arrows key above and below the hour or minutes to change the time. Touch the AM/PM or 24 hour icon change your time format. If the format is changed here it will also be changed in Time Format menu. Touch Done when finished. **Press the door switch after setting the time and/or date, this will cause a reboot and ensure the Time & Date are saved.**






System Settings

Time and Date

Touch the Date menu bar to change the Current Date .



Touch the arrow keys above and below the Day, Month and Year to change the date.
Touch Done when finished.

Press the door switch after setting the time and/or date this will cause a reboot and ensure the Time & Date are saved.





System Settings

Language

The Language Menu allows you to:

- Customize the Languages available to your customer.
- As shown in the picture to the right, you can enable multiple Languages at one time.
- The Language used in the service menus can also be changed and are independent of the customer languages set.
- Additional Languages can now be uploaded without changing the software, starting with version 10.8.4.

Note: You must have “Skip Main Menu” set to No when multiple Languages are enabled. This menu is located under the “Special Vend Modes” icon accessible from the main menu.






System Settings

Language

Touch Language to change the Language options.



Touch Service Application or User Interface to change the current Language options.







System Settings

Language

To change the Language used in the Service Menus Touch the Service Application menu bar.



Touch a Language and Press Done to apply that Language as a default for the Service Menus.







System Settings

Language

To change the Language used to communicate with the customer press the User Interface menu bar.



This menu allow you to choose which Languages are available to your customer as well as the default Language.






System Settings

Language

Choosing Enable Languages will bring up a list of Languages available to be used on the screen to communicate with your customer

Touch one or multiple menu bars to enable the Languages that will be available as an option for your customer to choose when using the machine. If there are multiple versions of the same language only one can be selected.





System Settings

Language

Choosing Default Language will bring up a list of Languages available to be used for the idle screen (Standby messages)



Choose a default Language for your idle screen (stand by) messages. Once the idle screen message is touched during vending you will have an option to change to one of the previously enabled languages.








System Settings

Language

The screenshot below shows the workflow of a customer who has already touched the idle Screen. **Note:** You must have “Skip Main Menu” set to no. This menu is located under the “Special Vend Modes” icon accessible from the main menu.






System Settings

Data Transfer Standard “DTS”

Data Transfer Standard (DTS)

- This Menu allows you to change what data is sent and control what data is reset on a DEX or DDCMP transfer.
- The defaults for these menus are the standard settings and are typically not changed.
- Before making changes you may want to contact your DEX provider or your Manufacturer Representative.







System Settings

Data Transfer Standard "DTS"

DTS Standby mode to change the transfer type.

Touch DDCMP or Dex on the menu bar to change the transfer type. Touch Done to save.

Note: In the US you will always choose DEX






System Settings

Data Transfer Standard "DTS"

To Modify the Audit List
Touch DTS Audit List.



Touch a menu bar to add or remove items from the audit list. This menu gives you the ability to shorten the DEX file. Do not remove items without contacting your DEX provider or your Manufacturer Representative. Touch the down arrow on the right to scroll through the Audit List





System Settings

Data Transfer Standard "DTS"

Touch CA304 Data Type to change how bills are reported.

Touch Currency or Numeric on the screen to change how bills are reported. Touch Done to save.







System Settings

Data Transfer Standard “DTS”

Touch the Data Reset Menu bar to change preference

Touch Auto or Save. Touch Done to save.



Recommended Setting: Data Reset should be set to Reset. Setting this option to No will result in the size of the DEX file increasing over time to unmanageable levels





System Settings

Data Transfer Standard "DTS"

Touch the Event Reset Menu bar to access the menu.

Select Auto or Save. Touch Done to save.







System Settings

Data Transfer Standard "DTS"

Touch the DTS Cache Settings Menu bar to access the menu.



This setting enables or disables the ability of the Atlas board to prepare a new DEX file every 5 minutes and have it available on demand for quicker DEX reads required for non-Crane telemetry devices.






System Settings

Software Updates

Software Updates

- The Software updates menu provides a means to load firmware updates and other files into the machine.
- This menu is used to load new firmware versions if the file type is XXXXX.bin. If the file type is XXXXX.CJFFS2 the file will automatically load if the USB is installed when the machine is powered up.
- There are numerous files that can be updated through this menu, some of the most common are:
 - **Plan-o-gram files**
 - **Custom Library files**
 - **Advertisements**
- The example of the following page shows a Plano-gram file being loaded but all other update files are loaded the same way.





System Settings


Software Updates – Planogram

Loading a Planogram into the machine using a memory stick

- Before attempting to load a file you must create a folder on your USB flash drive named atlas. Copy your file into the atlas Folder.
- Plug a flash drive in to an unoccupied USB port on the control board.
- You can have multiple Planograms in the atlas folder.
- Touch Software updates to enter menu.

Note: Crane Merchandising Systems is providing the nutritional content information, based on information provided by the product manufacturers, and Crane MS is cannot accept responsibility for content created by others.

(Planogram Updates)





System Settings

Software Updates – Planogram

Touch to access Software Updates
(Planogram Updates)



Touch the file you wish to upload to
the machine and Touch start update.






System Settings

Software Updates – Planogram

- A conformation box will appear if you choose to update the POG.
- Touch YES to continue or No to Cancel.
- If you choose Yes the machine will re-boot. The re-boot will take 5-7 minutes.
- It is a good idea to create a backup once the POG file is loaded.






System Settings

Backup / Restore

Backup / Restore

- Allows you to backup your current Configuration for recovery later if needed.
- Allows you to restore the machine to factory defaults.
- Allows you to restore the machine to a previously saved configuration
- Backups are saved with date created.
- Backups are stored on the controller, not removable media.





System Settings

Backup / Restore

Touch Backup / Restore to access the menu.



Touch Make New Backup to backup your current configuration for recovery later. All previous backups will be listed. You can touch a backup you want to restore or choose to Restore the Factory Backup. In this case we are choosing make a new backup.





System Settings

Backup / Restore

The display show a conformation screen.
Choose Yes continue or No to cancel.



Choosing Yes will update the display with the new backup file including the time and date of the backup. This file can be selected at a later date if you want to restore you machine to this backup file.





System Settings

Clone Configurations / Clone Board

Clone an Existing Configuration or Board

- This menu allows you to copy a machine that has been previously been set up and save that file on a flash drive.
- The difference between Clone Configurations and Clone Board menu is that clone board also copies the meter readings, this allow you to change a board or update software and keep the same meter readings.
- Once you have copied an existing configuration (set up) you can load it into other machines.
- For ease of use in the future the files can be named.
- You can have unlimited clone files in the atlas folder.






System Settings

Clone Configurations / Clone Board

Preparing the Flash drive

- The files size is less than 80kb so you can use any size flash drive.
 - Before attempting to clone an existing machine configuration you must create a folder on your USB flash drive named atlas (lower case is important).
1. Insert the flash drive into an available USB port on the control board, typically USB3
 2. Enter PIN 3333
 3. Touch System Settings, then Copy Configuration.






System Settings

Copy Configuration – Create Configuration Clone

If the Flash Drive is not found you will see the screen below.



Touch Create a Configuration Clone (from the control board to the stick). If there are existing clone files on the flash drive they will show up below Create Configuration Clone and can be chosen to be uploaded to the machine.






System Settings

Copy Configuration – Create Configuration Clone

Touch Create Configuration Clone to copy the existing configuration onto a Flash drive. The Flash drive can then be taken to another machine and uploaded.

Touch Clone Name to Name the configuration. Naming the configuration is optional.






Touch Make Clone to copy without naming.





System Settings

Copy Configuration

- A keypad will appear on the screen along with a window to enter the Clone Name.
- Use the keypad to enter the information.
- Touch **Done** when finished
-  is your backspace key.
-  is your exit key.
-  switches the keypad to numeric.
-  switches the keypad between uppercase & lowercase.
-  switches the keypad to symbols and numbers.







System Settings

Copy Configuration

Touch Make Clone, a conformation box will appear



Touch Yes continue No to cancel







System Settings

Clone Configuration – Uploading from a Flash

All files listed below Create Configuration Clone are valid configurations that can be copied from the flash stick to the control board. Touch a Clone File to upload or delete.

Touch Install or Remove clone file from stick. A confirmation box will appear verifying you want to install or remove the file, Touch Yes to continue or No cancel.






System Settings

Screen Brightness

Touch Screen Brightness



Use the numeric keypad to change the Brightness, the higher the number the brighter the screen. Touch Done to save.





System Settings

LED Color


Touch the down arrow on the right to scroll down to LED Color.



Touch LED Color to change the color of the pill surround and payment devices.



Touch a Color. Touch Done to save.






System Settings

Idle Timeout

Idle Timeout

- If a person starts a transaction on the machine and walks away without Touching the **Cancel** icon, the idle timeout is the amount of time until the machine goes back to it's standby message routine.
- The Idle Timeout is settable from 2 to 180 seconds.
- The factory default for the Idle Timeout is 30 seconds.





System Settings

Idle Timeout

Touch the down arrow on the right side of the display to scroll down to Idle Timeout.



Touch Idle Timeout to enter the menu.



Use the numeric keypad to enter a new time. Touch Done to save!







System Settings

Advertisements

Advertisements

This menu allows the user to turn on and off messages that are shown to the consumer during the idle screen loop.

- The idle loop is a series of messages that are shown on the display when no one is using the machine.
- As a default, all messages are enabled so if an item is selected in a menu that message will automatically be shown in the Idle loop.






System Settings

Advertisements

- On power up the machine will find the coin mechanism and bill acceptor, enable them, and turn on those advertisements.
- The Advertisements will show the values of bills being accepted including 1\$ coins.
- Attaching an MDB card reader or enabling an Onboard Reader will enable the Monetary Card Advertisements
- There are two Menu bars for Monetary Cards, when one is enabled both are enabled. This allows the Monetary Cards Advertisements to be shown more often.
- All Custom Promotions and Combo Vend Advertisements must be enabled when you set up the promotion in their respective menus.





System Settings

Advertisements

Monetary Idle Screens



Selection



Monetary Coins



Monetary Bills



Monetary Cards

Custom Promotions 1-9 are shown below. These promotions must be created and enabled under Timed Events/Time of Day Events/Promotion.



1 Buy any 2 and save X



2 Buy any Snack and any Drink and Save X



3 Buy any Bar and any Drink and Save X



4 Buy any 2 Snacks and Save X



5 Buy any 2 Bars and Save X



6 Buy any 2 Drinks and Save X



7 Buy any 2 Items and Get 1 FREE



8 Buy any 3 Items and Save X



9 Buy Any Food Item with a Snack and a Drink and Save X




System Settings

Advertisements

Touch the down arrow on the right side of the display to scroll down to Advertisements.



Touch Advertisements to modify what messages are shown on the idle screen loop.







System Settings

Advertisements

- Touch a menu bar to add or remove a checkmark.
- Items with a checkmark will be shown on the Idle Screen Loop when enabled in the appropriate menu.
- Choose Credit Card Types Accepted to enable/disable credit and ID card messages.






System Settings

Advertisements

Choose Credit Card Types Accepted to enable/disable card messages.

Touch a card type to add or remove a checkmark. Items with a checkmark will be shown on the Idle Screen Loop. Selecting ID will show a generic picture of a credit card in the idle loop.






System Settings

Custom Messages

Custom Messages

- This menu gives the user to option to both create and enable messages for both the Idle screen and the vending screen independently.
- These Messages can be mixed Text or Numeric characters.







System Settings

Custom Messages

Touch the down arrow on the right side of the display to scroll down to Custom Messages.



Touch to create, change or assign a Custom Message






System Settings

Custom Messages

Touch a menu bar to add a checkmark to enable a Custom message. Adding a checkmark will automatically bring up the next screen








Touch Vending screen message or Idle screen message to create your Custom Message.





System Settings

Custom Messages

- A keypad will appear on the screen along with a window to enter the message.
- Use the keypad to enter the information.
- Press **Done** when finished
-  is your backspace key.
-  is your exit key.
-  switches the keypad to numeric.
-  switches the keypad between uppercase & lowercase.
-  switches the keypad to symbols and numbers.






System Settings

Automatic Reboot Settings

Automatic Reboot Settings

- As a default the machine is set to reboot itself every evening at 2:00 am local time.
- This menu allows you to turn off or change the parameter of the nightly reboot.
- If your machine is equipped with cashless, this setting must be left on the default setting.
- If you find this setting interferes with customer activity, contact the Streamware team to make adjustments to this setting.







System Settings

Automatic Reboot Settings


Touch the down arrow on the right side of the display to scroll down to Automatic reboot settings.



Touch Automatic reboot settings to enter the menu.



Touch Enable Automatic Reboot to toggle between Yes and No. **Any changes will cause the machine to reboot on door closure.**







System Settings

Nightly Reboot Setting

Touch Reboot time and a keypad will appear on the screen allowing you to use the arrow keys to change the Reboot time. Press Done when finished.



Touch Idle Time Seconds and a keypad will appear on the screen. Use the keypad to enter a new time in seconds. Press Done when finished.






System Settings

Start Screen Renewal

Screen Renewal

- The Screen Renewal Menu Item allow you to refresh the screen if it has is blurry or has become burned or are seeing image retention from one screen to another.
- One this menu is enabled the screen will go white for 2 hours and prompt Screen renewal in progress, at the end of 2 hours the machine will go back to the normal Idle Screen Messages.
- If you need to interrupt the Screen Renewal process once it has started turn the power switch on the machine off an back on.






System Settings

Automatic Reboot Settings

Touch the down arrow on the right side of the display to scroll down to Start Screen Renewal.



Touch Start Screen Renewal to start the 2 hour screen Renewal process






System Settings

Configuration Version

Setting the Machine Type

The choices are Ambient, Refrigerated, European Control, Non Perishable or Chilled.

- Ambient will always be selected when a refrigeration unit is not present. When Ambient is selected the Refrigeration Settings Menu Bar will not appear.
- When Refrigerated is chosen the temperature is settable from 33-38°F (1-3°C) and the health control menu will be available.
- When European Control is chosen the temperature is settable from 33-41°F (1-5°C) and the health control menu will be available.
- When Non Perishable is chosen the temperature is settable from 33-45°F (1-7°C) and the health control menu will be not available.
- When Chilled is selected the settable temperature range is from 49-69°F (9-21°C) and the health control menu will **not** be available.






System Settings Configuration Version


Touch the down arrow on the right side of the display to scroll down to Configuration Version.



Touch Configuration Version to enter the menu.



Touch to select the desired Configuration Setting. Do not use European Control in the US. Touch Done to save!





System Settings

Refrigeration Settings


Touch the down arrow on the right side of the display to scroll down to Refrigeration Settings



Touch Refrigeration Settings to enter the menu.



Touch a menu bar below to set the Refrigeration Settings.






System Settings

Refrigeration Settings – Adjust Temperature


Setting the Temperature Range

- In Ambient machines this menu will not appear.
- Refrigerated temperature is settable from 33-38°F (1-3°C) and the health control menu will be available.
- Non Perishable temperature is settable from 33-45°F (1-7°C) and the health control menu will not be available.
- Chilled temperature range is from 49-69°F (9-21°C) and the health control menu will not be available.

Touch Adjust Temperature



On the keypad enter the desired Temperature.
Touch Done to save!







System Settings

Refrigeration Settings – Temperature Units

Touch Temperature Units to change the viewable Temperature between Fahrenheit and Celsius



Touch Fahrenheit or Celsius. Touch Done to save!






System Settings

Refrigeration Settings – Health Control

Touch Health Control to enter the Menu



On the display Touch the tray number you wish to view or change.



All available selections are shown. Touch a selection to add a checkmark to the selections that are active for Health Control.





System Settings

Refrigeration Settings – Diagnostics enable

The Diagnostic Enable menu allows you to turn on or off the warning and errors reported by the evaporator sensor and condenser sensor. These errors are reported when the door is opened if they exist. The default is on for both warnings & errors, and an Error is more severe than a Warning.

High Side errors & warnings are created when the Condenser Outlet Sensor is out of Range, most likely due to blocked inlet screen, dirty condenser, or condenser fan failure

- Warning: If the Condenser Outlet Sensor is greater than 125°F (52°C) for the 30 Minutes.
- Error: If the Condenser Outlet Sensor is greater than 150°F (66°C) for 5 minutes, **cooling is disabled. The error will need needs to be manually reset.**

Low Side errors & warnings are created when the unit goes into Low-Temp Defrost; where the Evaporator Coil Sensor is less than 10°F (-12°C) too frequently. Most likely due to an obstructed evaporator coil, low charge, or an evaporator fan failure.

- Warning: If the unit goes into Low-Temp Defrost at 10°F (-12°C) in more than 5 minutes, but less than 75 minutes after a previous defrost cycle.
- Error:., If the unit goes into Low-Temp Defrost 10°F (-12°C) in less than 5 minutes after a previous defrost cycle, **cooling is disabled. The error will need needs to be manually reset.**





System Settings

Refrigeration Settings – Diagnostics Enable Menu

Touch Diagnostics Enable to enter the Menu.

Each Warning or Error can be toggled between On and Off individually by touching the any of the menu bars below





System Settings

Cab Lights When OOS

Touch the down arrow on the right side of the display to scroll down to Cab Lights when Out of Service (OOS)



Touch CAB Lights When OOS to toggle between Yes and NO. Choosing Yes will cause the cabinet lights to turn off anytime the machine is out of Service






Security Codes

The Security code menu

- The first menu allows you to enter an existing PIN number to access other menus.
- The second and third menus allows you to change the existing PIN numbers.
- **Warning:** If you change the PIN, don't forget it, you won't be able to access the Service Mode.






Security Codes

Enter Pin

Touch Enter the existing pin



The Pin screen will appear, enter your existing PIN.








Security Codes

Change Driver or Operator Pin

Touch a menu bar to change the existing Driver or Operator PIN number

Enter your new Pin Number using the keypad. Touch Done when finished!







Timed Events

Timed Events Menu allows you to:

- Create Time of Day Events including Promotions.
- Backup your Current Events
- Create Power Saving Events






Timed Events

Time of Day Events

Time of Day Events

- When you choose Time of Day Events the following four options will appear on the screen.
 - Price Adjust
 - Free Vend
 - Inhibit
 - Promotions






Timed Events

Time of Day Events – Order of Precedence

- Timed events are arranged in an order of precedence, in other words, one has priority over another.
- The hierarchy of Time of Day events is:
 1. Inhibit
 2. Free Vend
 3. Promotion
- This means that if an Inhibit Event affecting all selections is active, and a Free Vend event or a Promotion event are scheduled, when the Inhibit event is scheduled, the Free Vend and the Promotion event are temporarily disabled until the end of the Inhibit event.
- There are other settings within the machine that could affect the value of the discount provided. If you find that the discount amount appears incorrect, check these settings.
 - Multi-Vend Discount is located in the Special Vend Mode menu, and is a percentage discount provided to a customer for purchasing multiple items in a single transaction
 - Cash Discount is located in the Monetary menu, and provides a defined cash discount to customer who purchase a selection using cash (coins, bills or stored value card) instead of a credit card.




Timed Events

Helpful Tips

Helpful Tips


- All events will not have the same menus. As an example, a Price Adjust Event will have a discount feature that a Power or Backup event would not have.
- In some cases some menus will not be present until another menu is enabled.
- Events are settable daily or weekly. When daily is chosen you choose the days of the week so the event **must not cross over midnight**. As an example, if you were to set a power event from 10:00 PM to 6:00 AM that would be two separate events. The first from 10:00 PM to 11:59 PM and the second from 12:00 AM to 06:00 AM.
- All Events will have a Save This Event menu bar. This is used to save the event after you have set all the other menus in an event. Save your changes frequently.
- If your event has a large menu that continues on to a second screen, **use the up and down arrow key to scroll back up to the first screen to save**. If you use the exit key you will be starting over.



Price Adjust

- The Price Adjust menu allows you to set times and/or day(s) when the prices will adjust automatically.
- The menu bars on the right contain all the options that need to be set and may change depending on your selections.
- Price adjustments can be set by value or discount by changing the Price Adjust Type.
- Price adjust has one menu that is not used in any other event, that menu is:
 - Price Adjust Type – This menu allow you to set to either Discount or Surcharge for the event.
- Save your changes often by choosing save this event. If you exit without choosing save this event your changes will be lost!

A screenshot of a mobile application interface for configuring a "Timed Event". The menu items are: "Save this event" with a right arrow; "Remove this event" with a right arrow; "Enable state" set to "Off"; "Frequency" set to "Daily"; "Start time" set to "12:00 AM"; "Stop time" set to "12:00 AM"; "Days of week" with a right arrow; "Price Adjust Type" set to "Discount"; "Price Adjust Value" set to "0"; and "Selections for event" with a right arrow. The "Price Adjust Type" and "Price Adjust Value" items are highlighted in a darker blue color.




Timed Events

Time of Day Events – Free Vend

Free Vend

- The Free Vend menu allows you to set a time and/or day(s) when the Machine will go on Free Vend automatically.
- The menu bars on the right contain all the options that need to be set up for your event and may change depending on your selections.
- You can choose the selections for your free vend event.
- This Menu is different from Winner mode and all selections chosen will be free for the times and days set.
- **Save your changes often by choosing save this event. If you exit without choosing save this event your changes will be lost!**






Timed Events

Time of Day Events – Inhibit

Inhibit

- The Inhibit menu allows you to set times and/or day(s) when specific selections or all selections in the machine are not available for purchase.
- You can set multiple Inhibit events per day if necessary.
- The menu bars on the right contain all the options that need to be set up for your event and may change depending on your selections.
- **Save your changes often by choosing save this event. If you exit without choosing save this event your changes will be lost!**

A screenshot of a mobile application interface titled "Timed Events". The menu consists of several grey rectangular buttons with white text and a right-pointing chevron icon. The buttons are: "Save this event", "Remove this event", "Enable state" (with "Off" on the right), "Frequency" (with "Daily" on the right), "Start time" (with "12:00 AM" on the right), "Stop time" (with "12:00 AM" on the right), "Days of week", and "Selections for event".



Promotions


- Promotions allows you to choose one or more pre-defined promotions to offer the customer a discount for purchasing multiple items during a single transaction.
- Each promotion has a pre-programmed advertisement that advises the customer that these promotions are available.
- The recommended maximum number of Promotions stored is six.

Available Pre-Defined Promotions

- Buy any 2 and save X
- Buy any Snack and any Drink and Save X
- Buy any Bar and any Drink and Save X
- Buy any 2 Snacks and Save X
- Buy any 2 Bars and Save X
- Buy any 2 Drinks and Save X
- Buy any 2 Items and Get 1 FREE (shown above)
- Buy any 3 Items and Save X
- Buy Any Food Item with a Snack and a Drink and Save X

Timed Events

- Save this event >
- Remove this event >
- Enable state Off
- Promotion Type
- Frequency Daily
- Start time 12:00 AM
- Stop time 12:00 AM
- Days of week >
- Discount Type Value
- Discount Amount 0
- Selections for event >




Timed Events

Time of Day Events – Promotions

Promotions, continued

- The matrix at the right displays the associated graphic for each of the pre-defined Promotions.
- The number to the left of each description corresponds to the assigned Custom Advertisement found in the System Settings/ Advertisements menu.
- If the required custom message is disabled, the promotion is still active, but the customer is not advised that a promotion is active, and available.
- When the assigned Custom Advertisement is disabled, the View Promotions menu item is not shown on the Make Selection idle screen.




1 Buy any 2 and save X




2 Buy any Snack and any Drink and Save X



3 Buy any Bar and any Drink and Save X




4 Buy any 2 Snacks and Save X




5 Buy any 2 Bars and Save X



6 Buy any 2 Drinks and Save X




7 Buy any 2 Items and Get 1 FREE



8 Buy any 3 Items and Save X



9 Buy Any Food Item with a Snack and a Drink and Save X






Timed Events

Backup Events

Backup Events

- The backup Events Menu allows you to create a backup of the events you have created.
- This Menu also allows you to program the time and day or days you wish to backup the Events.






Timed Events

Power Saving Events

Power Saving Events

- The Power Saving Events Menu allows you to create events where the lighting will turn off to save energy.
- This Menu allows you to program the time and day or days you wish the Power Saving Events to be active.
- There is one additional feature that is only in the Power Saving Events Menu. This feature allows you to set the number of minutes of inactivity before the machine goes into Power Saving Mode.
- Inactivity minutes are settable from 1 to 600.






Timed Events

Create New Event


Touch the type of event you wish to Create




If you choose Time of Day you will need to choose the event type, all other choices will take you to the next screen



Touch Create New Event or select an existing event to modify.








Timed Events

Create New Event

Program menu all options before saving.
Once the event details are programmed
Touch Save this event to save or your
changes will be lost!

Touch Remove this Event to delete the event
you are working on. Be aware if you remove
event 1 and you have multiple events, what
was event 2, now will become event 1. Also
there is no conformation screen for removing
an event so be careful!





Timed Events

Enabling & Frequency of the Event

Touch Enable State to toggle the state of the event between Off and On. Choosing off allows an event to remain stored in the machine for future use – it is not necessary to remove the event.


Touch the display to toggle the Frequency of the event between Daily and Weekly.

Timed Events

Save this event	>
Remove this event	>
Enable state	Off
Frequency	Daily
Start time	12:00 AM
Stop time	12:00 AM
Days of week	>
Price Adjust Type	Discount
Price Adjust Value	0
Selections for event	>

Timed Events

Save this event	>
Remove this event	>
Enable state	Off
Frequency	Daily
Start time	12:00 AM
Stop time	12:00 AM
Days of week	>
Price Adjust Type	Discount
Price Adjust Value	0
Selections for event	>



Timed Events


Frequency of the Event

Note: When you choose Daily you have a choice of a start time, stop time and days of the week

Note: When you choose Weekly you have a choice of a start day, start time, stop day & stop time. Because there is one additional menu, Price Adjust has moved down.

Timed Events	
Save this event	>
Remove this event	>
Enable state	Off
Frequency	Daily
Start time	12:00 AM
Stop time	12:00 AM
Days of week	>
Price Adjust Type	Discount
Price Adjust Value	0
Selections for event	>


Timed Events	
Save this event	>
Remove this event	>
Enable state	Off
Frequency	Weekly
Start Day	Monday
Start Time	00:00
Stop Day	Friday
Stop Time	23:59
Price Adjust Type	-
Price Adjust Value	




Timed Events

Setting Start Time

Touch Start Time on the display to enter the time you want the event to start. As an example, if this is an inhibit event set for all selections, this is the time the machine will stop accepting money.



Touch the arrows key above and below the hour or minutes to change the time. Touch the AM/PM to toggle. If 24 hour clock was selected in the Time/Date menu under System Settings AM/PM will not appear. **Touch Done when finished! Press X to exit without changing the time.**





Telemetry

The Telemetry Menu is used to set up your:

- Integrated Wireless Radio
 - Cashless
 - Remote DEX Alerts
 - Mesh Network.
- The Telemetry Menu also allows you to send a DEX file on demand in addition to the scheduled times.
 - A welcome packet was sent with your machine that will provide additional information on configuring and setting up your account information for Telemetry.





Telemetry

Assigning Unit

Assigning a Unit

Before assigning the unit, you must establish an account with the card processor and Crane Streamware. All of the information and Applications are included in the Welcome packet that came with the machine. If you have any questions, contact your Crane Distributor or Sales Person.

- When the customer account is established, Crane Streamware will email the customer configuration (VIX) file to upload and assign the Merchant Media.
- Create a folder on your USB flash drive named atlas. Copy your VixConfigData.cfg file to this folder.





Telemetry Assigning Unit

Verify the radio is connected to USB1 (top Left USB port). USB1 is the high-power USB port and the only one that will support the radio.







Telemetry Assigning Unit

Access the service mode
by entering PIN 3333

Insert the Flash Drive with the
VixConfigData.cfg file into
USB 3 on the control board

Touch Telemetry on the
screen






Telemetry

Assigning Unit

Touch Assign Unit, the VMC will update the customer information from the flash drive. Once this is complete, the Media Merchant will reboot. This will take a few minutes.






When the machine reboots the following screen should appear. Touch the display to enter a Machine ID number






Telemetry

Assigning Unit

- A keypad will appear on the screen along with a window to enter the Machine ID.
- Use the keypad to enter the information.
- Touch **Done** when finished
-  is your backspace key.
-  is your exit key.
-  switches the keypad to numeric.
-  switches the keypad between uppercase & lowercase.
-  switches the keypad to symbols and numbers.






Telemetry

Assigning Unit

After Touching Done the following screen should appear with the ID number in the right hand corner. Touch Validate Entries to finalize assignment.



The display will prompt Validating Entries followed by Finalizing Assignment.






Telemetry

Assigning Unit

- Touch Reboot to complete assignment process.
- Once the reboot process is complete remove the flash drive from the USB port and test.
- The top menu bar in the Telemetry Menu will now become Send DEX.
- You will also now have a menu option to Unassign the unit.
- **It is important that if for any reason you change the board you Unassign the unit and assign the new board.**





Send Dex


- Once Telemetry is assigned the first menu on the screen will change to Send DEX.
- Send DEX is also available in the route drive access menu by entering PIN 1111 and selecting Telemetry.
- Touch the Send DEX menu bar to send a DEX file wirelessly when servicing the machine.





Telemetry Ping Server


Touch Ping Server to
Ping the Server.



The yellow LED on
the radio should
illuminate and the
screen below will
show up until Pinging
is complete



The results Pass/Fail will
display to the right of Ping
Server







Telemetry

Get Network Status

To view the current network status touch Get Network Status.

The screen will show the current Network Status.







Telemetry

Get Network Status

Touch Show Network Config



Touch Load Network Config






Telemetry Enable Mesh

Mesh Networking

- The Mesh Module is mounted on the top left corner of the Atlas Controller.
- Mesh uses a proprietary wireless network that CMS uses to communicate to other Mesh devices.
- This network is used for Telemetry device, Client to Gateway communication.
- Mesh allows machines in a area with bad cellular signals to send information to a host machine with a radio, the Host machine becomes a Gateway to send the information for the group of machines.
- Mesh can also communicate with any machine that has Navigator installed which includes a Mesh module.



Mesh Module


Mounting on
Atlas board



Telemetry Enable Mesh

Mesh Networking

- Once the Mesh and radio are installed you will have an option to Enable Mesh.
- Make sure the antenna used with the Mesh Module has a connector with no pin in the center. Connectors with a pin in the center are for the radios only.
- Gateway units should always be set up first.





Firmware Information

Firmware Information

Touching Firmware on the keypad brings up an information screen that displays the following information:

- All the MDB peripherals in the machine including manufacturer, serial number and software version.
- The software version of the SureVend™ board.
- The software version of the I/O board.
- The software version of the LE board.
- The serial number of the Atlas control board, along with the software version, and kernel file version.

The screenshot shows a mobile application interface with a dark background. At the top, there is a navigation bar with four icons: a back arrow, a home icon, a key icon, and a power icon. Below the navigation bar, the title 'Firmware Information' is displayed. The main content is a table with several rows, each representing a different component. The table has three columns: the component name, a status column, and a version column. The 'LE Board' row has sub-columns for 'Ver.' and 'Kernel'. The 'I/O Board Version' and 'SureVend Version' rows have a single version value in the rightmost column.

Firmware Information		
Bill Validator		
disconnected	-/-	-/-
Card Reader		
disconnected	-/-	-/-
Coin Mechanism		
disconnected	-/-	-/-
LE Board	Ver.	Kernel
120400039	10.2.0	2.6.34
I/O Board Version		0222
SureVend Version		0103

Error Description	Probable Cause	Possible solutions
Stuck Keys Fatal	Stuck keys on keypad or shorted connections/harness	<ul style="list-style-type: none"> Check connectors to be properly installed Check harness for damage Replace the keypad
No Monetary Device Fatal	The control board has not been able to detect a working monetary device	<ul style="list-style-type: none"> Check connectors to be properly installed Check harness for damage Check for faulty bill validator/harnessing Retest without the bill validator and harnessing installed Replace the coin mechanism
Coin Mech No Comms	No Communications are occurring between the coin mechanism and the control board	<ul style="list-style-type: none"> Check connectors to be properly installed Check harness for damage Retest without the bill validator and harnessing installed Replace the coin mechanism
Coin Mech ROM Error	Coin Mech ROM Error	<ul style="list-style-type: none"> Replace the coin mechanism
Coin Mech Acceptor Unplugged	Coin Mech Acceptor Unplugged	<ul style="list-style-type: none"> Check the connections within the coin mechanism Replace the coin acceptor Replace the coin Mechanism
Coin Mech Acceptor Jammed	Coins or other items are stuck in the acceptor causing the gate to remain open	<ul style="list-style-type: none"> Remove the coins or other items from the acceptor Replace the acceptor Replace the coin mechanism
Coin Mech Payout Jammed	Coin pay out motor or solinoid is stuck in cycle	<ul style="list-style-type: none"> Check for and remove bent coins or other items causing the jam Replace the coin mechanism
Coin Mech Sensor Error	Bad coin mechanism sensor	<ul style="list-style-type: none"> Check for an item causing a blockage and remove Replace the coin mechanism
Coin Mech All Tubes Error	Coin mechanism not sensing any pay out tubes	<ul style="list-style-type: none"> Check for proper pay out cassette placement Replace the pay out cassette Replace the coin mechanism
Coin Mech Tube Error	Coin mechanism not sensing a pay out tube	<ul style="list-style-type: none"> Check for proper pay out cassette placement Replace the pay out cassette Replace the coin mechanism
Coin Mech Disabled	Coin mechanism has been disabled by the board	<ul style="list-style-type: none"> Power down the machine and re-start Remove bill validator and/or card reader from system Replace the coin mechanism Reset the control board Replace the control board
Exec Price Error	Executive coin mechanism error	<ul style="list-style-type: none"> Check for a price set outside of allowed parameters Replace executive coin mechanism

Error Description	Probable Cause	Possible solutions
No Monetary Device	No monetary device detected by the board	<ul style="list-style-type: none"> Check connectors to be properly installed Check harness for damage Retest without the bill validator and harnessing installed Replace the coin mechanism
Coin Return Motor Not Present	Control board not sensing the presence of a coin return motor	<ul style="list-style-type: none"> Check the connection J6 on the I/O board to the coin return motor Home the coin return motor Replace the coin return motor Check for damage to harnessing Reset or replace the control board
Coin Return motor Run Time Timeout	The board has determined that the coin return motor should have arrived at home position, but it has not	<ul style="list-style-type: none"> Check the connections to the coin return motor Home the coin return motor Replace the coin return motor Check for damage to harnessing Reset or replace the control board
Coin Return Motor Short Circuit	Coin return motor has shorted out	<ul style="list-style-type: none"> Check connections and harnessing for damage Replace the coin return motor
Coin Return Motor Drive Failure	The coin return motor is not engaging the coin return arm on the coin mechanism	<ul style="list-style-type: none"> Check for damaged or missing drive linkage Check for proper mounting of coin mechanism Check for damage on coin mechanism pay out parts
Low Change	The coin mechanism has reported a low or empty condition in one or more of the coin pay out tubes	<ul style="list-style-type: none"> Add coins to the tubes using the coins in/out screen in the monetary section of the service modes Do vends with coins to add coins to the tubes Replace coin mechanism
No IO Comm	The control board is not communicating with the I/O board	<ul style="list-style-type: none"> Check for proper connections on the I/O board Check for proper connections on the control board Check for damage to the harnessing Remove the monetary devices from the system and check for restored communication Replace the I/O board Reset and/or replace the control board
Please Wait	The board is asking you to wait while it completes an ongoing operation	<ul style="list-style-type: none"> Wait for the board to finish the operation Re-start the machine and let it re-boot Remove monetary devices and re-start the machine Reset and/or replace the control board
No Selections Available	The control board is not sensing any motors available for use	<ul style="list-style-type: none"> Check for motors to be homed Check for motors and harnesses to be connected Check for power to I/O board Replace I/O board Reset and/or replace control board

Error Description	Probable Cause	Possible solutions
All Selections Disabled	The control board has disabled all the motors in the machine	<ul style="list-style-type: none"> Check SureVend settings and operation Check motors to be homed and connected properly Check for a timed event to be enabled causing the condition Check/replace I/O board Reset/replace control board
IO Board Voltage	The control board has detected improper voltage for I/O board operation	<ul style="list-style-type: none"> Check voltage to the machine Check voltage to the I/O board Replace the I/O board
Init Failed	The control board has failed to initialize successfully	<ul style="list-style-type: none"> Power down and re-start the machine Power down, disconnect monetary devices and re-start the machine Replace the control board
# XXX Motor Error	The board has detected a problem with a selection motor (XXX indicates the selection involved)	<ul style="list-style-type: none"> Check harness connection Check for damage to the tray harnessing Check for damage to channel harnessing if applicable Replace the snack motor
Health Control Active	The control board has detected a temperature condition which is outside the allowed parameters and has stopped allowing sales of involved products	<ul style="list-style-type: none"> Check for clean screens and condenser Check for acceptable clearance behind the machine Check temperature sensor for accurate readings Check refrigeration system for proper function
SureVend Comm Error	The control board is not communicating with the SureVend board system. Can be fatal or non-fatal depending on SureVend settings (optional or must)	<ul style="list-style-type: none"> Check the harness connections between the SureVend boards and to the I/O board at J3 Check the harnesses for damage (crushed, cut, etc.) Check the right side SureVend board to be an updated board and replace if it is not Replace the SureVend boards
SureVend Is Blocked	The control board has determined that a sureVend sensor is blocked. Can be fatal or non-fatal depending on SureVend settings (optional or must)	<ul style="list-style-type: none"> Check the delivery bin for items that may have hung up and blocked a beam Check harnesses and connections on the SureVend boards Check calibration on the SureVend boards Replace the SureVend boards
SureVend Calibration Error	The control board has calculated a value which is not possible. Can be fatal or non-fatal depending on SureVend settings. (optional or must)	<ul style="list-style-type: none"> Check for damage to the SureVend boards or harnesses Replace the SureVend boards
Anti Jackpot Error	The control board has detected multiple attempts to vend a product from a selection and has not seen a successful delivery	<ul style="list-style-type: none"> Check SureVend calibration Check SureVend function Check motor function

Error Description	Probable Cause	Possible solutions
# XXX Sold Out	The control board has determined that a selection is sold out. (XXX indicates the selection number involved)	Check to see that there is product Check SureVend calibration Check SureVend function Check motor function
Factory Init	An attempt to restore factory default settings has been unsuccessful	Power down, power up and try again Power down, remove monetary devices and try again Replace the control board and reset
Card Reader No Comms	The control board is not able to communicate with the card reader	Check connections for the card reader Check for damage to the harness (cut, pinched, etc.) Replace the card reader Reset the control board Replace the control board
Card Reader Comms Error	The control board is not communicating with the card reader	Check the connections and harness for damage Check the settings on the board and on the reader Replace the reader Reset and/or replace the board
Bill Validator No Comms	The control board is not communicating with the bill validator	Check the connections and settings for the validator Replace the harness Replace the validator
Bill Validator Motor Error	The validator has reported an error to a drive motor within the validator	Check for a broken belt or blockage Replace the bill validator
Bill Validator Sensor Error	The validator has reported an error to a sensor within the validator	Check for a sensor blockage Replace the bill validator
Bill Validator ROM Error	an error has been detected in a main chip in the validator	Replace the bill validator
Bill Validator Acceptor Jammed	A jam in the bill path has been detected	Check the bill path for items that are blocking sensors Check to see that the bill path gates are not open Replace the bill validator
Bill Validator Stacker Error	An error has been reported concerning the bill box	Check the bill box to be mounted to the validator properly Replace the bill box Replace the bill validator
Bill Validator Stacker Full	The bill validator is reporting that the bill box is full of bills	Check for bills and remove them Replace the bill box Replace the bill validator
Bill Validator Disabled	The control board has disabled the bill validator	Check for coins in the payout tubes of the coin mechanism Check for a fault with the bill validator
Check Winner Prize	The control board has detected a failed winner vend	Check for the presence of product Check motor function
POWER OFF	The control board has detected a power outage	Check the power cord and plug Check the circuit breaker Check the On/Off switch in the machine

Error Description	Probable Cause	Possible solutions
DOOR OPEN	The control board is reporting that the door has been opened	Check to see if someone has been in the machine Check the door switch Check switch connections and harnessing for damage
Power Save mode	The machine is in a power save event	Let the event complete Modify or eliminate the event in the software settings
Return Air Temperature Sensor Error	The control board has recorded sensor readings that are outside of allowed parameters	Check the readings for high or low temperatures Check for a defrost event Check for ice buildup on the evaporator
Evaporator Temperature Sensor Error	The control board has recorded sensor readings that are outside of allowed parameters	Check the readings for high or low temperatures Check for a defrost event Check for ice buildup on the evaporator Check for evaporator fan function
Cabinet Temperature Sensor Error	The control board has recorded sensor readings that are outside of allowed parameters	Check the temperature readings against a thermometer, placed at near the same level as the sensor, for accuracy Replace the sensor
Condenser Temperature Sensor Error	The control board has recorded sensor readings that are nearing or outside of allowed parameters	Clean screens and condenser Check to see that the machine has six inches of clearance from the wall Replace the sensor
Condenser High Side Warning	Temperatures at or nearing 150 degrees are being reported	Clean screens and condenser Check to see that the machine has six inches of clearance from the wall Replace the sensor
Condenser High Side Error	Temperatures of an unlikely nature are being reported (such as 999 degrees) Cooling functions are stopped	Check the temperature sensor and connections Replace the temperature sensor
Evaporator Coil Low Side Warning	The control board has recorded sensor readings that are nearing or outside of allowed parameters	Check for evaporator fan function Check for ice buildup on evaporator Check for excessive moisture
Evaporator Coil Low Side Error	The control board has recorded sensor readings that are outside of allowed parameters. Cooling functions are stopped	Check for evaporator fan function Check for ice buildup on evaporator Check for excessive moisture Replace the temperature sensor
IO Even Input Short	The I/O board is reporting that an even input switch has shorted out	Check for motor errors (out of home position) replace the I/O board
IO Odd Input Short	The I/O board is reporting that an odd input switch has shorted out	Check for motor errors (out of home position) replace the I/O board
Sold Out Machine	The control board has determined that all selections in the machine are sold out	Check SureVend settings and function Check for vend motor function Check harnessing connections Check for board function (selection configuration)

Error Description	Probable Cause	Possible solutions
Recycler Motor Problem	A problem has been detected with a motor inside the bill validator	Check for an obstruction or blockage within the recycler which is stopping the motor from completing its cycle Replace the bill validator
Recycler Sensor Problem	A problem has been detected in a sensor within the recycler	Replace the recycler cassette Replace the bill validator
Recycler Jam	The recycler is unable to function	Check for an obstruction or blockage which is preventing the recycler from completing its cycle Replace the recycler cassette Replace the bill validator
Recycler Checksum Error	A communications error has been reported between the recycler and the control board	Check the bill validator harnessing for damage Re-start the system to restore communication Replace the recycler
Recycler Disabled	The recycler has been disabled by the control board	Check for proper function of the recycler unit (errors) Check the recycler cassette for proper installation Replace the bill validator
# XX Coin Mech Tube Empty	The coin mechanism is reporting that there is an empty payout tube. (# XX indicates which tube is empty)	Check for an empty tube and replenish Check for a bad sensor Replace the coin cassette Replace the coin mechanism
Bill Validator Stacker Motor Error	An error has been reported concerning the stacker motor in the bill validator	Check the bill path for a blockage preventing the proper operation of the bill stacker motor Replace the bill validator
Bill Validator Recycler Gate Error	An error has been detected in the recycler gate	Check for an obstruction or blockage in the bill path preventing the gate from functioning Replace the bill validator
Bill Validator Recycler Tape Error	An error has been reported in the operation of the recycler tape within the recycler cassette	Check for a blockage in the bill path which prevents the tape from moving backward and/or forward Replace the recycler cassette Replace the bill validator
Optical Sensor Failure	The failure of an optical sensor within the bill validator has been detected	Check the bill path for an obstruction or blockage which prevents the optical sensor from functioning Replace the bill validator
Magnetic Sensor Failure	The failure of the magnetic sensor within the bill validator has been detected	Check the bill path for an obstruction or blockage which prevents the magnetic sensor from functioning Replace the bill validator
Recycler Cass Jammed	The recycler cassette is not able to move	Check for an obstruction or blockage which is preventing the cassette from moving Replace the recycler cassette Replace the bill validator


Error Description	Probable Cause	Possible solutions
Bill Validator Path Jammed	A blockage of the bill path has been reported	Check for an obstruction or blockage which is preventing the bills from moving thru the bill validator Replace the bill validator
Bill Validator Cashbox Jammed	The bill box has become jammed and is not allowing the stacker motor to complete its cycle	Check for a full bill box Check for damaged bills blocking the operation of the stacker plate Replace the bill box Replace the bill validator
Stacker Out Of Position	The control board has detected that the stacker has stopped out of its home position	Check for a blockage or obstruction which is not allowing the stacker motor to complete its cycle Check for proper installation of the bill box Replace the bill box Replace the bill validator
Recycler Out Of Position	The recycler is not able to accept bills	Check for proper installation of the recycler cassette Check for an obstruction or blockage which is preventing the cassette from locking into position Replace the recycler cassette Replace the bill validator
Cold Drink X Motor Failure	The control board is reporting that the X motor is not functioning	Check for proper connections to the motor Check for damage to the harnessing Check for proper switch function Check for over tightening of the motor Replace the motor
Cold Drink Y Motor Failure	The control board is reporting that the Y motor is not functioning	Check for proper connections to the motor Check for damage to the harnessing Check for proper switch function Check for over tightening of the motor Replace the motor
Cold Drink Picker Motor Failure	The control board is reporting that the picker motor is not functioning	Use the position test functions to test the picker motor Replace the picker cup
Cold Drink Port Motor Failure	The control board is reporting that the port motor is not functioning	Use the port test functions to test for function Check wiring connections Check switch functions including the position cam Replace the motor
Cold Drink Vend Timeout	The control board is reporting that a successful vend cycle has not been completed in the allowed amount of time	Check for a picker cup that did not return to the home position Check for a port door that did not open/close
Cold Drink Cabinet Failure	An error that has not yet been defined	Should not be seen in a machine Replace the control board

Error Description	Probable Cause	Possible solutions
Cold Drink Coin Return Motor Failure	The control board is reporting that the coin return motor has failed	<ul style="list-style-type: none"> Check the wiring connections Check for proper mounting of the motor Check for proper mounting of the coin mechanism Replace the coin return motor
Cold Drink Picker Home Failure	The control board has reported that the picker has failed to return to its home position at the end of a cycle	<ul style="list-style-type: none"> Use the position test functions to test or cycle the picker back to its home position Replace the picker cup
Cold Drink Temperature Sensor Error	the control board is reporting that the temperature sensor has failed	<ul style="list-style-type: none"> Compare the reported temperature against a thermometer Replace the temperature sensor
Cold Drink Cooling System Not Cooling	The control board is reporting that the refrigeration system is not functioning	<ul style="list-style-type: none"> Check for a bad temperature sensor Check for other errors that would cause the refrigeration system to have been shut down by the board
Cold Drink Cabinet Too Hot	The control board is reporting that the cabinet is operating at three degrees, or more, above the allowed parameter	<ul style="list-style-type: none"> Check for an accurate temperature reading Check refrigeration system for proper function (clean screens, condenser also distance from rear wall) Check for proper fan operation
Cold Drink Cabinet Too Cold	The control board is reporting that the cabinet is operating at three degrees, or more, below the allowed parameter	<ul style="list-style-type: none"> Check for an accurate temperature reading Check refrigeration system for proper function (clean screens, condenser also distance from rear wall) Check for proper fan operation
Card Reader Manuf Trans Error	The card reader has reported an error in transmitting data	<ul style="list-style-type: none"> Check the card reader for proper function Replace the card reader
Card Reader Service Error	An internal error has occurred within the card reader	<ul style="list-style-type: none"> Reset the card reader and retry Replace the card reader
Card Reader Manufact Error	An internal error has occurred within the card reader	<ul style="list-style-type: none"> Reset the card reader and retry Replace the card reader
Card Reader Failed OOS Error	An internal error has occurred within the card reader	<ul style="list-style-type: none"> Reset the card reader and retry Replace the card reader
Card Reader Comms OOS Error	An internal error has occurred within the card reader	<ul style="list-style-type: none"> Reset the card reader and retry Replace the card reader
Card Reader Jam OOS Error	An internal error has occurred within the card reader	<ul style="list-style-type: none"> Reset the card reader and retry Replace the card reader
Card Reader Manufact OOS Error	An internal error has occurred within the card reader	<ul style="list-style-type: none"> Reset the card reader and retry Replace the card reader


Error Description	Probable Cause	Possible solutions
Health Check Error	The control board is reporting that an error occurred in the process of conducting a health check	<ul style="list-style-type: none"> Check temperature sensors for proper function Check the refrigeration system for function Reset machine for another cool down period to check for proper health control function Reset the control board to default settings and set up for another test Replace the control board and re-test
Heath Timer Error	The control board is reporting that an error has occurred in the operation of the timer during a health check function	<ul style="list-style-type: none"> Reset machine for another cool down period to check for proper health control function Reset the control board to default settings and set up for another test Replace the control board and re-test
Health Recheck Error	The control board is reporting that an error occurred in the process of conducting a second attempt at a health check	<ul style="list-style-type: none"> Check temperature sensors for proper function Check the refrigeration system for function Reset machine for another cool down period to check for proper health control function Reset the control board to default settings and set up for another test Replace the control board and re-test
Capacity Sensor Failure	An error has been reported with a sensor inside the bill validator	<ul style="list-style-type: none"> Re-start the bill validator and check function Replace the bill validator
Not Calibrated Sensor Error	An error has been reported with a sensor inside the bill validator	<ul style="list-style-type: none"> Re-start the bill validator and check function Replace the bill validator

Atlas Controller

Atlas Controller with Touch Software:
Part # CR0020293




120 Volt AC Box Assembly CR0004739




HIGH VOLTAGE WIRING DIAGRAM

230 Volt AC Box Assembly CR0014549



HIGH VOLTAGE
WIRING DIAGRAM

Low Voltage Wiring Diagram Touch Screen



Software Licenses

GNU General Public License (GPL), version 2

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc. 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed. **Preamble**

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software—to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange;

c) Accompany it with the information you received as to the offer to distribute corresponding source code. This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

one line to give the program's name and an idea of what it does. Copyright (C) yyyy name of author This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version. This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details. You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Boston, MA 02110-1301, USA. Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type `show w'. This is free software, and you are welcome to redistribute it under certain conditions; type `show c' for details. The hypothetical commands `show w' and `show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than `show w' and `show c'; they could even be mouse-clicks or menu items—whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yooyodine, Inc., hereby disclaims all copyright interest in the program "Gnomovision" (which makes passes at compilers) written by James Hacker, signature of Ty Coon, 1 April 1989 Ty Coon, President of Vice This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License.

- Complete text of v2 of the GPL may be found online at <http://www.gnu.org/licenses/gpl-2.0.html>.

Software Licenses

GNU Lesser General Public License (LGPL), version 2.1

GNU LESSER GENERAL PUBLIC LICENSE

Version 2.1, February 1999

Copyright (C) 1991, 1999 Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed. This is the first released version of the Lesser GPL. It also counts as the successor of the GNU Library Public License, version 2, hence the version number 2.1. | **Preamble**

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public Licenses are intended to guarantee your freedom to share and change free software to make the software is free for all its users.

This license, the Lesser General Public License, applies to some specially designated software packages—typically libraries—of the Free Software Foundation and other authors who decide to use it. You can use it too, but we suggest you first think carefully about whether this license or the ordinary General Public License is the better strategy to use in any particular case, based on the explanations below.

When we speak of free software, we are referring to freedom of use, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish); that you receive source code or can get it if you wish; that you can change the software and use pieces of it in new programs; and that you are informed that you can do these things.

To protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to require you to surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the library or if you modify it.

For example, if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights that we give you. You must make sure that they, too, receive or can get the source code. You must also make sure that you provide complete object files to the recipients, so that they can relink them with the library after making changes to the library and recompiling it. And you must show them these terms so they know their rights.

We protect your rights with a two-step method: (1) we copyright the library, and (2) we offer you legal permission to copy, distribute and/or modify the library.

To protect your freedom, we want to make it very clear that there is no warranty for the library. Also, if the library is modified by someone else and passed on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others.

Finally, software patents pose a constant threat to the existence of any free program. We wish to make sure that a company cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. Therefore, we insist that any patent license obtained for a version of the library must be consistent with the full freedom of use specified in this license.

Most GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, the GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary General Public License. We use this license for certain libraries in order to permit linking those libraries into non-free programs.

When a program is linked with a library, whether statically or using a shared library, the combination of the two is legally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore permits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permits more lax criteria for linking other code with the library.

We call this license the "Lesser" General Public License because it does less to protect the user's freedom than the ordinary General Public License. It also provides other free software developers Less of an advantage over competing non-free programs. These disadvantages are the reason we use the ordinary General Public License for many libraries. However, the Lesser License provides advantages in certain special circumstances.

For example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more frequent case is that a free library does the same job as widely used non-free libraries. In this case, there is little to be gained by limiting the free library to free software only, so we use the Lesser General Public License.

In other cases, permission to use a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the GNU C library in non-free programs enables many more people to use the whole GNU operating system, as well as its variants, the GNU/Linux operating system.

Although the Lesser General Public License is Less protective of the users' freedom, it does ensure that the user of a program that is linked with the library has the freedom and the wherewithal to run that program using a modified version of the library.

The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference between a "work based on the library" and a "work that uses the library". The former contains code derived from the library, whereas the latter must be combined with the library in order to run.

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called "this License"). Each licensee is addressed as "you".

A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables.

The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work based on the Library. This includes the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification".)

"Source code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this license; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or works on each copy of the Section 1 above, provided that you also meet all of these conditions:

a) The modified work must itself be a software library.

b) You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.

c) You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.

d) If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful. (For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional; if the application does not supply it, the square root function must still compute square roots.)

These requirements apply to the entire work, whether in part or in whole, if identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose provisions therefore apply to those sections as well.

3. You may copy and distribute copies of the Library as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.

This is the intent of this section: claim right or control your rights to write written entirely by you; rather, the intent is to ensure that you control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute copies of the Library as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you may specify that version instead if you wish.) Do not make any other change to these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy.

4. You may copy and distribute the Library for a portion or derivative of it under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking "work that uses the Library" with the Library is not a "work that uses the Library". The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a "work that uses the Library" uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law.

If such object code uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (in-line functions in C are used without copying), and the section of the object code which is intended to apply to other circumstances, (Executables containing significant pieces of code must portions of the Library will still fall under Section 6.)

Otherwise, if a work is a derivative of the Library, you must distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also combine or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

a) Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2) above; and, if the work is an executable linked with the Library, with the complete machine-readable "work that uses the Library," as object code and/or source code, so that the user can modify the Library and then link to produce a modified executable containing the modified Library. (It is understood that the user who changes the contents of definitions files in the Library will not necessarily be able to compile the application to use the modified definitions.)

b) Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the Library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.

c) Distribute the work as a separate object code, offer equivalent access to copy from a designated place, offer equivalent access to the above specified materials or from the place of performing this distribution.

d) Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

7. For an executable, the required form of the "work that uses the Library" must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

8. If the work is a library, this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

9. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:

a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.

b) Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

10. You may not copy, modify, sublicense, distribute, or sublicense the Library, or any part of it, under any circumstances except as expressly provided under this License. Anyone who does so is responsible for obtaining the permission of the copyright holder, but you must first notify anyone you give a license to use the Library or any part of it, in writing, that you received this license from the copyright holder, not from me.

11. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

12. Each time you redistribute the Library (or any work based on the Library), you must prominently notice the recipients in the usual places that the Library is free software and the section of the license which is intended to apply in other circumstances.

13. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, you do not accept this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For all other cases, your permission to distribute the Library by anyone who receives copies directly or indirectly through you, then only you may occasionally both it and the conditions of this License to be retained entirely from distribution of the Library.

14. If you are part of a corporation that is licensed by the copyright holder to use the Library in a proprietary product, you may still distribute it with the product under the conditions of this License if you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For all other cases, your permission to distribute the Library by anyone who receives copies directly or indirectly through you, then only you may occasionally both it and the conditions of this License to be retained entirely from distribution of the Library.

15. If any portion of this section is held to be unenforceable under any particular circumstance, the balance of the section shall nevertheless be enforceable under other circumstances.

16. This is not the purpose of this section to induce you to infringe any patents or other property rights or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implementing by public license practices. Many people have made generous contributions to the wide range of software distributed through this system in reliance on consistent application of this system; it is up to the author(s) to decide if he or she is willing to accept this license in order to make those contributions clear what is believed to be a consequence of the rest of this License.

17. If the distribution and/or use in the United States of the Library is restricted by copyright notices, the original copyright holder who places the Library under this License may send an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries that is not excluded. In such case, this License incorporates the limitation as if written in the body of this License.

18. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

19. Each version is given a distinguishing version number. The Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

20. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW WILL ANY COPYRIGHT HOLDER, ANY CONTRIBUTOR TO THIS LIBRARY OR ANY DISTRIBUTOR OF THE LIBRARY BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF PROFITS OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Libraries

1. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

2. To apply these terms, attach the following notice to the library. It is safest to attach them to the library in the source code, but you may also attach them to the library in the form of a separate document. You must make sure that you are conveying the terms of this license to the recipient of the library in the same way as you are conveying the library itself.

3. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

4. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

5. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

6. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

7. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

8. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

9. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

10. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

11. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

12. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

13. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

14. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

15. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

16. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

17. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

18. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

19. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

20. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

21. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

22. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

23. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

24. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

25. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

26. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

27. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

28. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

29. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

30. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

31. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

32. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

33. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

34. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

35. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

36. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

37. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

38. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

39. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

40. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

41. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

42. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

43. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

44. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

45. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

46. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

47. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

48. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

49. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

50. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

51. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

52. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

53. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

54. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

55. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

56. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

57. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

58. You develop a new library, and you want it to be of the greatest possible use to the public; you recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

59. You develop a new library, and you want it to be of the greatest possible use to