

20 oz. PET STRAIGHT WALL BOTTLE SHIMMING S002.2

Models Affected: 522 Series 90 Venders Only.

Reason: To supply a vender that will vend the 20 oz. Pet Straight Wall Bottle double depth.

Serial Break: Venders serialized 0001-3165AO and up.

Height: 8" (203.2mm)
Width: 2 63/64" (75.95mm)

20 oz. PET Straight Wall Bottle

Note: This set-up is for the 20 oz. Straight Wall Bottle. See instructions S001.x for 20 oz. Contour Bottle set-up.

LOADING	PARTS PER	CAM	CAM(S) FOR	REAR	OTHER PARTS
DEPTH	COLUMN	SETTING	MOTOR	SPACER	
2	Bottle Neck Support 324,010,150.13 Bottle Neck Support Retainer 324,010,160.03	NA	White Cam 801,806,990.11	Standard 498,071,300.03 Hole Location 23	Can/Bottle Chute 324,000,200.03

NA = Not Applicable


20 oz. BOTTLE CAPACITY IN 522T				
WIDE COLUMN	50			
NARROW COLUMNN	NA			
TOTAL	300			

December 12, 1996 Page 1 of 3


Order per wide column:

1 - 801,806,990.11	White Vending Cam, 20 oz. (1 per column)
1 - 324,010,150.13	Bottle Neck Support (1 per column)
1 - 324,010,160.03	Bottle Neck Support Retainer (1 per column)
2 - 900,301,550.01	#8-32x½Screw (2 per Bottle Neck Support)
1 - 498,071,300.03	Rear Spacer (1 per column)

*1 - 324,000,200.03 Assy., 20 oz. Bottle Chute (1 per vender)




White Vending Cam 801,806,990.01 Figure 1




A) Bottle Neck Support 324,010,150.13

B) Bottle Neck Support Retainer 324,010,160.03 Figure 2



20 oz. Bottle Chute Assy. 324,000,200.03 Figure 3



Oscillator with Bottle Neck Support Figure 4

VENDER SET-UP AND SHIMMING:

- 1. Unplug the vender.
- 2. Set rear spacer in hole location 23.
- 3. Remove the can retainers from the oscillator.
- 4. Install the bottle neck support and retainer. (See figure 4, page 2.)

Note: The distance between the inside front edge of the oscillator and the front of the bottle neck support is $7\frac{1}{2}$.

- 5. Secure the bottle neck support and retainer with two #8-32x½ screws.
- 6. Remove existing cams from vend motors.
- 7. Install new 20 oz. white vending cam (part #801,806,990.11). (See figure 1, page 2.)

Important: The adjustable cam (gold in color) is not used. Do not place it on the motor.

- 8. Remove existing can/bottle delivery chute.
- 9. Install new can/bottle chute (part# 324,000,200.03). (See figure 3, page 2.)
- 10. Set the discharge member and closure strip for bottles.
- 11. Load the bottles cap to cap.

Important: Always load the front bottle first, then the rear bottle so the caps overlap with the rear bottle's cap on top as shown in figure 5.




Figure 5