

Technical Bulletin

 Bulletin Number: 454
 Revision Number: R-10

 Release Date: October 16, 1992
 Revision Date: April 6, 1998

SUBJECT: MISCELLANEOUS WORLDWIDE NON RETURNABLE GLASS BOTTLE SHIMMING IN SHIMLESS STACK SERIES 90 VENDERS.


MODELS AFFECTED: All Shimless Stack Series 90 Venders.

<u>REASON:</u> To provide the shimming and set-up of various non-returnable glass bottles used Worldwide.

INDEX

| A) | Package Shape Illustrations | Page 2 |
|----|---|---------------------|
| B) | Package Dimensions | Page 3 |
| C) | Part Illustrations | Page 4 |
| D) | Column Wall Kit Installation Instructions | Pages 5 and 6 |
| E) | Shimming and Set-Up Chart | Pages A1 through A2 |
| F) | Individual Column Set-Up & Shimming | Pages B1 through B6 |

Package Shapes



TB 454 Page 2 of 6

Package Shapes


| | Package | Country/ | CI | | ight | | meter |
|---------------------|---------|---------------|-------|--------|---------------|-------|---------|
| Description | Size | Township | Shape | | <u>s (mm)</u> | | es (mm) |
| Coca-Cola "Contour" | 300 ml | Australia | 1 | 7.63" | (193.8) | | (61.7) |
| Coca-Cola | 330 ml | Germany | 2 | 6.5" | (165.1) | 2.56" | (65) |
| Coca-Cola "Contour" | 330 ml | Germany | 1 | 8.06" | (204.7) | 2.44" | (62) |
| Pepsi-Cola | 330 ml | Germany | 2 | 6.5" | (165.1) | 2.56" | (65) |
| Water | 330 ml | Germany | 2 | 6.5" | (165.1) | 2.56" | (65) |
| Coca-Cola | 10 oz. | Mexico | 2 | 5.8" | (147.3) | 2.62" | (66.5) |
| Coca-Cola | 12 oz. | Mexico | 2 | 6.75" | (171.5) | 2.63" | (66.8) |
| "Bellingham & TJ" | 250 ml | South Africa | 3 | 7.27" | (184.7) | 2.39" | (60.7) |
| "Chateau Libertas" | 250 ml | South Africa | 4 | 7.27" | (184.7) | 2.23" | (56.6) |
| Clear Wine | 250 ml | South Africa | 3 | 7.81" | (198.4) | 2.22" | (56.4) |
| Colombiana | 10 oz. | South America | 2 | 5.375" | (136.5) | 2.63" | (66.8) |
| Fruitopia | 330 ml | Spain | 5 | 6.34" | (161) | 2.54" | (64.5) |
| Barq's | 8 oz. | United States | 4 | 7.63" | (193.8) | 2.22" | (56.4) |
| Cappio | 8 oz. | United States | 6 | 6.98" | (176.4) | 2.38" | (60.5) |
| Coca-Cola "Contour" | 8 oz. | United States | 1 | 7.73" | (196.3) | 2.34" | (59.4) |
| Dr. Pepper | 8 oz. | United States | 6 | 7.58" | (192.5) | 2.27" | (57.7) |
| Ocean Spray | 10 oz. | United States | 5 | 5.94" | (150.9) | 2.65" | (67.3) |
| Sprite | 8 oz. | United States | 1 | 7.63" | (193.8) | 2.30" | (58.4) |
| Tropicana | 10 oz. | United States | 2 | 6.03" | (153.2) | 2.57" | (65.3) |
| Coca-Cola "Contour" | 12 oz. | United States | 1 | 9.25" | (235) | 2.48" | (63) |
| Nantucket Nectars | 12 oz. | United States | 5 | 6.63" | (168.4) | 2.61" | (66.3) |
| Coca-Cola | 250 ml | Uruguay | 1 | 7.46" | (189.5) | 2.29" | (58.2) |
| Fanta | 250 ml | Uruguay | 7 | 7.40" | (188) | 2.28" | (57.9) |
| Sprite | 250 ml | Uruguay | 7 | 7.41" | (188.2) | 2.29" | (58.2) |

- 1. Where the symbols *, + and @ are used refer to the following: (Use plastic tubes only where called out.)
 - * Where the symbol * appears on the shim chart, place the 10-3/4" long (9/32"ID, 3/8"OD) yellow plastic tube over the rod.
 - + Where the symbol + appears on the shim chart, place the 10-3/4" long (9/32"ID, 7/16"OD) red plastic tube over the rod.
 - Where the symbol @ appears on the shim chart, place the 10-3/4'' long (9/32"ID, 17/32"OD) white plastic tube over the rod.
- 2. Where **REAR A/FRONT C** appears on the shim chart, this means the rod is installed (spring end first) in hole "A" at the rear of the rotor and the front end of the same rod is installed in hole "C".


PARTS ILLUSTRATIONS

| Ē | | | | | | | I |
|---|--|--|---|---|--|--|---|
| 5 | | | | | | | r |
| | | | r | 5 | | | ł |
| | | | | | | | L |
| i | | | | | | | l |
| | | | | | | | |


Flat Black Shim 801,804,96x.x1



Bottle Shim (White Plastic) 801,805,23x.x1




w/a Bottle Shim, left -2 443,010,60x.x3



Grey Shim 801,805,12x.x1



Flat Shim (Metal) 901,303,63x.x1



w/a Bottle Shim, right -2 443,010,70x.x3

INSTALLATION OF COLUMN WALL KIT:

WIDE COLUMNS

- 1. Unplug the vender.
- 2. Move the rear spacers to the rear of each column.
- 3. Identify the right and left parts for proper placement.
 - A. See Figures 1 and 2 on the next page for identification.
 - Note: The dimension from the bottom of the part to the first clip is 6-1/8" (155.6mm) on a right side part and is shown to assist in part identification. The dimension on the left hand part from the bottom of the part to the first clip is 8-1/8" (206.4mm).
- 4. Take the right kit and locate the "clips" which are welded to the back side of the part.
- 5. Place the right kit in the column so the "clips" are towards the right column wall.
- 6. Align the "clips" with the existing slots in the right stack wall.

Note: There are two (2) upper and two (2) lower slots in each stack wall.

For the right kit use the lower slots at each location.

- 7. Push the wall in position to secure (clips in slots).
- 8. Install the left kit wall by repeating steps 4, 5, 6 and 7 using the upper slots at each location.
- 9. Set the rear spacer in the proper position.
- 10. Set the cams in the proper position.
- 11. Load the product and test for proper vending.




FIGURE 1

FIGURE 2

Use this chart to "set-up" and "shim" the "Shimless Stack" vender. Series 90, beginning S/N 0001-3162AO & up (except run numbers 3164AO, 3166AO, and 3167AO). Pre-Series 90, beginning S/N 0001-3098AN to 0001-3162AO (Except 1954-3161AO to 2003-3161AO & 2656-3161AO to 2750-3161AO) (Includes production runs 3164AO, 3166AO, and 3167AO)

NON RETURNABLE GLASS BOTTLES

| | | | | Wide Colu | mns | | All Columns | | Narrow Co | lumns | | | |
|--|-----------------|---------------------|---------|--|----------------|---------------|----------------------------|------------------|---|-----------|-----------|----------------|----------------|
| PACKAGE DESCRIPTION & VENDERS APPROVED | COUNTRY | SEE PAGE(S) | LOADING | PARTS PER COLUMN | CAM SETTING | CAMS REQ'D | REAR SPACER LOCATION | LOADING DEPTH | PARTS REQ'D PER COLUMN | ROD IN | ROD IN | CAM SETTING | OTHER PARTS |
| 300 ml NR Coca-Cola Glass Bottle in Model 368 | Australia | 2, 4, & B1 | 1 | 4 flat black shims | 2 notches | blue/gold | Hole 13 | 1 | 1 flat shim right & 1 plastic bottle shim right | A | - | #4 | none |
| 330 ml NR Coca-Cola Glass Bottle in Models 432 & 360 | Germany | 2, 4, & B1 | 1 | 2 flat black shims | 2 notches | blue/gold | Hole 10 | NA | NA | NA | NA | NA | none |
| 330 ml NR Coca-Cola Contour Glass Bottle in Models 180, 300, & 360 | Germany | 2, 4, & B1 | 1 | w/a right & left shim and 4 flat black shims | 2 notches | blue/bold | Hole 14 | NA | NA | NA | NA | NA | none |
| 330 ml NR Pepsi Cola Glass Bottle in Models 300 & 180 | Germany | 2, 4, & B1 | 1 | 2 flat black shims | 2 notches | blue/gold | Hole 10 | NA | NA | NA | NA | NA | none |
| 330 ml NR Glass Water Bottle in Models 432, 360, 300, & 180 | Germany | 2, 4, & B1 | 1 | 2 flat black shims | 2 notches | blue/gold | Hole 10 | NA | NA | NA | NA | NA | none |
| 10 oz. NR Coke Glass Bottle in Model 276 | Mexico | 3, B1, & B2 | 2 | 0 | 4 notches | blue/gold | Hole 23 | 2 | 0 | - | - | #3 | none |
| 12 oz. NR Coca-Cola Glass Bottle in Models 368 & 440 | Mexico | 2 & B2 | 1 | 0 | 2 notches | blue/gold | Hole 10 | 1 | 0 | NA | NA | #4 | none |
| 250 ml NR Glass Wine "Bellingham & TJ" Bottle in Model 276 | South Africa | 2, 4, & B2 | 1 | 6 flat black shims | 2 notches | blue/gold | Hole 12 | 1 | 1 flat shim right & 1 white plastic shim | А | - | #4 | none |
| 250 ml NR Glass Wine "Chateau Libertas" Bottle in Models 276 & 440 | South Africa | 2, 4, 5, 6, & B2 | 1 | w/a right & left bottle shim & 6 flat black shims | 2 notches | blue/gold | Hole 12 | 1 | 1 flat shim right & 1 white plastic shim | А | - | #4 | none |

| | | | | Wide Colu | mns | | All Columns | | Narrow Col | umns | | | |
|---|------------------|---------------------|---------|--|----------------|---------------|----------------------------|------------------|---|---------------------------|-----------|----------------|------------------|
| PACKAGE DESCRIPTION & VENDERS APPROVED | COUNTRY | SEE PAGE(S) | LOADING | PARTS PER COLUMN | CAM SETTING | CAMS REQ'D | REAR SPACER LOCATION | LOADING DEPTH | PARTS REQ'D PER COLUMN | ROD IN | ROD IN | CAM SETTING | OTHER PARTS |
| 250 ml NR Glass Clear Wine Bottle in Model 276 | South Africa | 2, 4, 5, 6, & B3 | 1 | w/a right & left column wall & 6 grey shims | 2 notches | blue/gold | Hole 13 | 1 | bottle shim right, bottle shim left, flat shims right, rear spacer assy. | - | - | #4 | none |
| 10 oz. NR "Colombiana" PLB Glass Bottle in All Shimless Stack Models | South America | 2 & B3 | 2 | 1 can retainer | 4 notches | blue/gold | Hole 23 | 2 | 0 | NA | NA | #3 | none |
| 330 ml Fruitopia Glass Bottle in Models 276, 348, & 368 | Spain | 2, 4, & B3 | 1 | 2 flat black shims | 2 notches | blue/gold | Hole 10 | 1 | no shims required | - | - | #4 | none |
| 8 oz. NR Cappio Glass Bottle in Model 276 | United States | 3, 4, B3, & B4 | 1 | 6 flat black shims | 2 notches | blue/gold | Hole 10 | 1 | 1 bottle shim right, 2 flat shims right & rear spacer assy. | A* | - | #4 | none |
| 8 oz. Barq's, 8 oz. Sprite, and 8 oz. NR Coca-Cola "Contour" Glass Bottle in Models 180, 276, 300, & 368 | United States | 2, 5, 6, & B4 | 1 | w/a right & left column wall | 2 notches | blue/gold | Hole 14 | NA | DO NOT VEND | NA | NA | NA | none |
| 8 oz. NR Dr. Pepper Glass Bottle in Model 368 | United States | 3, 5, 6, & B4 | 1 | w/a right & left column wall | 2 notches | blue/gold | Hole 13 | NA | DO NOT VEND | NA | NA | NA | none |
| 10 oz. NR Glass Ocean Spray Bottle in Model 368 | United States | 3 & B4 | - | WILL NOT VEND | - | - | Hole 23 (Top) | 2 | Rear spacer assy. | - | - | #3 | none |
| 10 oz. Tropicana Glass Bottle in Model 368 | United States | 3, 4, & B5 | 1 | Spring shim - right & left, 4 flat grey shims | 2 notches | blue/gold | Hole 9 | 1 | 0 | B* | - | #4 | divider angle |
| 12 oz. NR Coca-Cola "Contour" Glass Bottle in Models 276, 368, 432 & 440 | United States | 2, 4, & B5 | 1 | 4 flat grey shims | 2 notches | blue/gold | Hole 17 | 1 | 0 | A | C+ | #4 | none |
| 12 oz. NR Nantucket Nectars Juice Bottle in Models 276 & 368 | United States | 2, 4, & B5 | 1 | 2 flat black shims | 2 notches | blue/gold | Hole 10 | 0 | Do not recommend vending in narrow columns | - | - | - | none |
| 250 ml NR Coke and 250 ml NR Sprite Glass Bottle in Models 276 & 300 | Uruguay | 3, 4, 5, 6, & B6 | 1 | w/a right & left column wall | 2 notches | blue/gold | Hole 12 | 1 | 1 bottle shim right, 4 flat shims behind bottle shim | Front C Rear A | - | #4 | none |
| 250 ml Fanta Glass Bottle in Models 276 & 300 | Uruguay | 2, 4, 5, 6, & B6 | 1 | w/a right & left column wall | 2 notches | blue/gold | Hole 12 | 1 | rear spacer assy., 1 bottle shim right, 4 flat shims behind bottle shim | Front C@ Rear A@ | - | #4 | none |

INDIVIDUAL COLUMN SET-UP & SHIMMING

300 ml NR Coca-Cola Glass Bottle (Australia) (In model 368)

| Wide Column Set-Up 1 deep | | | | | | |
|------------------------------|--------------------------------|--|--|--|--|--|
| 4 - 801,804,96x.x1 | flat black shims (2 each side) | | | | | |
| 1 - 801,806,39x.x1 | cam, blue vending | | | | | |
| 1 - 801,806,40x.x1 | cam, gold adjustable | | | | | |
| Cam setting #1 or 2 notches. | | | | | | |
| Rear spacer set in hole #1 | 3. | | | | | |
| * | | | | | | |

Narrow Column Set-Up 1 deep

1 - 901,303,63x.x1 flat shim right side
1 - 801,805,23x.x1 white plastic bottle shim (right side in front of flat shim)
1 - 267,012,30x.x3 rod and spring assembly
Place rod in hole "A" of rotor.
Cam setting #4 or 1 notch.
Rear spacer set in hole #13.
SET DISCHARGE MEMBER AND CLOSURE STRIP FOR BOTTLES.

330 ml NR Coca Cola Glass Bottle (Germany) (In models 432 & 360) 330 ml NR Pepsi Cola Glass Bottle (Germany) (In models 300 & 180) 330 ml NR Glass Water Bottle (Germany) (In models 432, 360, 300 & 180)

Wide Column Set-Up 1 deep

| 2 - 801,804,96x.x1 | flat black shims (1 each side) | | | | | |
|------------------------------|--------------------------------|--|--|--|--|--|
| 1 - 801,806,39x.x1 | cam, blue vending | | | | | |
| 1 - 801,806,40x.x1 | cam, gold adjustable | | | | | |
| Cam setting #1 or 2 notches. | | | | | | |
| Rear spacer set in hole #1 | 0. | | | | | |
| - | | | | | | |

Narrow Column Set-Up Not Applicable.

330 ml NR Coca-Cola "Contour" Glass Bottle (Germany) (In models 360, 300, & 180)

Wide Column Set-Up 1 deep

| 4 - 801,804,96x.x1 | flat black shims (2 each side) |
|---------------------------|------------------------------------|
| 1 - 443,014,00x.x3 | w/a bottle shim, left -3 |
| 1 - 443,014,10x.x3 | w/a bottle shim, right -3 |
| 1 - 801,806,39x.x1 | cam, blue vending |
| 1 - 801,806,40x.x1 | cam, gold adjustable |
| Cam setting #1 or 2 note | hes. |
| Rear spacer set in hole # | 14. |
| SET DISCHARGE MEM | IBER AND CLOSURE STIP FOR BOTTLES. |
| | |

Narrow Column Set-Up Not Applicable.

10 oz. NR Coca-Cola Glass Bottle (Mexico) (In model 276)

Wide Column Set-Up 2 deep No shims required. 1 - 801,806,39x.x1 cam, blue vending 1 - 801,806,40x.x1 cam, gold adjustable Cam setting #2 or 4 notches. Rear spacer set in hole #23.

10 oz. NR Coca-Cola Glass Bottle (Mexico) (In model 276)

Narrow Column Set-Up 2 deep No shims required. Cam setting #3 or 2 notches. Rear spacer set in hole #23. SET DISCHARGE MEMBER AND CLOSURE STRIP FOR BOTTLES.

12 oz NR Coca-Cola Glass Bottle (Mexico) (In models 368 & 440)

Wide Column Set-Up 1 deep No shims required. 1 - 801,806,39x.x1 cam, blue vending 1 - 801,806,40x.x1 cam, gold adjustable Cam setting #1 or 2 notches. Rear spacer set in hole #10.

Narrow Column Set-Up 1 deep No shims required. Cam setting #4 or 1 notch. Rear spacer set in hole #10.

250 ml NR Glass Green Wine "Bellingham & TJ" Bottle (South Africa) (In model 276)

Wide Column Set-Up 1 deep

6 - 801,804,96x.x1 flat black shim (3 each side) 1 - 801,806,39x.x1 cam, blue vending 1 - 801,806,40x.x1 cam, gold adjustable Cam setting #1 or 2 notches. Rear spacer set in hole #12.

Narrow Column Set-Up 1 deep

1 - 901,303,63x.x1 flat shim, metal right
1 - 801,805,23x.x1 white plastic bottle shim (right side in front of flat shim)
1 - 267,012,30x.x3 rod and spring assembly
Place rod in hole "A" of rotor.
Cam setting #4 or 1 notch.
Rear spacer set in hole #12.
SET DISCHARGE MEMBER AND CLOSURE STRIP FOR BOTTLES.

250 ml NR Glass Wine "Chateau Libertas" Bottle (South Africa) (In models 276 & 440)

Wide Column Set-Up 1 deep

| 1 - 443,010,60x.x3 | w/a bottle shim, left -2 | | | | | |
|------------------------------|---|--|--|--|--|--|
| 1 - 443,010,70x.x3 | w/a bottle shim, right -2 | | | | | |
| 6 - 801,804,96x.x1 | flat black shim (3 each side behind metal shim) | | | | | |
| 1 - 801,806,39x.x1 | cam, blue vending | | | | | |
| 1 - 801,806,40x.x1 | cam, gold adjustable | | | | | |
| Cam setting #1 or 2 notches. | | | | | | |
| Rear spacer set in hole #1 | 12. | | | | | |
| - | | | | | | |

Narrow Column Set-Up 1 deep 1 - 901,303,63x.x1 flat shim, metal right 1 - 801,805,23x.x1 white plastic bottle shim (right side in front of flat shim) 1 - 267,012,30x.x3 rod and spring assembly Place rod in hole "A" of rotor. Cam setting #4 or 1 notch. Rear spacer set in hole #12. SET DISCHARGE MEMBER AND CLOSURE STRIP FOR BOTTLES.

250 ml Glass Clear Wine Bottle (South Africa) (In Model 276)

| Wide Column Set-Up 1 deep | |
|-----------------------------|---|
| 1 - 443,011,30x.x3 | 276 w/a wall left |
| 1 - 443,011,40x.x3 | 276 w/a wall right |
| 6 - 801,805,12x.x1 | flat grey shim (3 each side behind column wall) |
| 1 - 801,806,39x.x1 | cam, blue vending |
| 1 - 801,806,40x.x1 | cam, gold adjustable |
| Cam setting #1 or 2 notch | es. |
| Rear spacer set in hole #1 | 3. |
| | |
| Narrow Column Set-Up 1 deep | |
| | |

| 2 - 801,805,23x.x1 | white plastic bottle shim |
|----------------------------|---|
| | (1 on right side) |
| | (1 on left side with ridges toward left wall) |
| 4 - 901,303,63x.x1 | flat metal shim (4 per right side behind bottle shim) |
| 1 - 493,070,70x.x3 | rear spacer assembly with bottle retainer extension |
| Cam setting #4 or 1 notch | 1. |
| Rear spacer set in hole #1 | 3. |
| SET DISCHARGE MEM | BER AND CLOSURE STRIP FOR BOTTLES. |

10 oz NR "Colombiana" PLB Glass Bottle (South America) (In all shimless stack models)

Wide Column Set-Up 2 deep

No shims required. 1 - 801,806,39x.x1 cam, blue vending 1 - 801,806,40x.x1 cam, gold adjustable Cam setting #2 or 4 notches. Rear spacer set in hole #23.

Narrow Column Set-Up 2 deep No shims required. Cam setting #3 or 2 notches. Rear spacer set in hole #23.

330 ml Glass Fruitopia (Spain) (In models 276, 348, & 368)

Wide Column Set-Up 1 deep

| 1 - 801,806,39x.x1 | cam, blue vending |
|-------------------------|-------------------------------|
| 1 - 801,806,40x.x1 | cam, gold adjustable |
| 2 - 801,804,90x.x1 | flat black shim (1 each side) |
| Cam setting #1 or 2 not | ches. |
| Rear spacer set in hole | #10. |

Narrow Column Set-Up 1 deep No shims required. Cam setting #4 or 1 notch. Rear spacer set in hole #10. SET DISCHARGE MEMBER AND CLOSURE STRIP FOR BOTTLES.

8 oz. NR Cappio Glass Bottle (United States) (In model 276)

Wide Column Set-Up 1 deep 6 - 801,804,96x.x1 flat black shim (3 per side) 1 - 801,806,39x.x1 cam, blue vending 1 - 801,806,40x.x1 cam, gold adjustable Cam setting #1 or 2 notches. Rear spacer set in hole #10.

8 oz. NR Cappio Glass Bottle (United States) (In model 276)

| Narrow Column Set-Up 1 deep | |
|---|---|
| 1 - 801,805,23x.x1 | bottle shim, right (close to bottle) |
| 2 - 901,303,63x.x1 | flat shim, long (close to column wall) |
| 1 - 267,012,30x.x3 | rod and spring assembly |
| 1 - 901,901,95x.x1 | yellow tubing |
| 1 - 493,070,30x.x3 | rear spacer assembly with retainer extension |
| Place rod with yellow tub | 1 0 |
| Cam setting #4 or 1 notc | |
| Rear spacer set in hole # | |
| - | IBER AND CLOSURE STRIP FOR BOTTLES. |
| | |
| 8 oz. NR Sprite Glass Bottle (United Stat | tes) (In models 276 & 300) |
| 8 oz. NR Barq's Glass Bottle (United Sta | |
| - | States) (In models 180, 276, 300, & 368) |
| Wide Column Set-Up 1 deep | |
| 1 - 270,010,20x.x3 | 276, 300, & 368 w/a wall left |
| 1 - 270,010,30x.x3 | 276, 300, & 368 w/a wall right |
| 1 - 275,010,50x.x3 | 180 w/a wall left |
| 1 - 275,010,60x.x3 | 180 w/a wall right |
| 1 - 801,806,39x.x1 | cam, blue vending |
| 1 - 801,806,40x.x1 | cam, gold adjustable |
| Cam setting #1 or 2 notc | • • |
| | |
| Rear spacer set in hole # | 14. IBER AND CLOSURE STRIP FOR BOTTLES. |
| SET DISCHARGE MEN | IBER AND CLOSURE STRIP FOR BOTTLES. |
| Narrow Column Set-Up | |
| Do not vend. | |
| Do not vend. | |
| 8 oz. NR Dr. Pepper Glass Bottle (United | d States) (In model 368) |
| Wide Column Set-Up 1 deep | (In model 500) |
| 1 - 443,011,30x.x3 | w/a wall left |
| 1 - 443,011,40x.x3 | w/a wall right |
| 1 - 801,806,39x.x1 | • |
| 1 - 801,806,39x.x1 1 - 801,806,40x.x1 | cam, blue vending |
| | cam, gold adjustable |
| Cam setting #1 or 2 note | |
| Rear spacer set in hole # | 13. |
| | |
| Nomer Column Cot Un | |
| Narrow Column Set-Up | |
| Narrow Column Set-Up Do not vend. | |
| Do not vend. |) (In model 269) |
| Do not vend. 10 oz. Glass Ocean Spray (United States |) (In model 368) |
| Do not vend. 10 oz. Glass Ocean Spray (United States Wide Column Set-Up |) (In model 368) |
| Do not vend. 10 oz. Glass Ocean Spray (United States |) (In model 368) |
| Do not vend. 10 oz. Glass Ocean Spray (United States Wide Column Set-Up Will not vend. |) (In model 368) |
| Do not vend. 10 oz. Glass Ocean Spray (United States Wide Column Set-Up Will not vend. Narrow Column Set-Up 2 deep |) (In model 368) |
| Do not vend. 10 oz. Glass Ocean Spray (United States Wide Column Set-Up Will not vend. Narrow Column Set-Up 2 deep No shims required. | |
| Do not vend. 10 oz. Glass Ocean Spray (United States Wide Column Set-Up Will not vend. Narrow Column Set-Up 2 deep No shims required. 1 - 497,074,40x.x3 | maximum depth rear spacer assy. (bottom hooks to hanger rod) |
| Do not vend. 10 oz. Glass Ocean Spray (United States Wide Column Set-Up Will not vend. Narrow Column Set-Up 2 deep No shims required. 1 - 497,074,40x.x3 Cam setting #3 or 2 notc | maximum depth rear spacer assy. (bottom hooks to hanger rod) hes. |
| Do not vend. 10 oz. Glass Ocean Spray (United States Wide Column Set-Up Will not vend. Narrow Column Set-Up 2 deep No shims required. 1 - 497,074,40x.x3 Cam setting #3 or 2 note Rear spacer set in hole #2 | maximum depth rear spacer assy. (bottom hooks to hanger rod) hes. 23 (top), bottom hooks to hanger rod. |
| Do not vend. 10 oz. Glass Ocean Spray (United States Wide Column Set-Up Will not vend. Narrow Column Set-Up 2 deep No shims required. 1 - 497,074,40x.x3 Cam setting #3 or 2 note Rear spacer set in hole #2 | maximum depth rear spacer assy. (bottom hooks to hanger rod) hes. |
| Do not vend. 10 oz. Glass Ocean Spray (United States Wide Column Set-Up Will not vend. Narrow Column Set-Up 2 deep No shims required. 1 - 497,074,40x.x3 Cam setting #3 or 2 note Rear spacer set in hole #2 | maximum depth rear spacer assy. (bottom hooks to hanger rod) hes. 23 (top), bottom hooks to hanger rod. |
| Do not vend. 10 oz. Glass Ocean Spray (United States Wide Column Set-Up Will not vend. Narrow Column Set-Up 2 deep No shims required. 1 - 497,074,40x.x3 Cam setting #3 or 2 note Rear spacer set in hole #2 | maximum depth rear spacer assy. (bottom hooks to hanger rod) hes. 23 (top), bottom hooks to hanger rod. |
| Do not vend. 10 oz. Glass Ocean Spray (United States Wide Column Set-Up Will not vend. Narrow Column Set-Up 2 deep No shims required. 1 - 497,074,40x.x3 Cam setting #3 or 2 note Rear spacer set in hole #2 | maximum depth rear spacer assy. (bottom hooks to hanger rod) hes. 23 (top), bottom hooks to hanger rod. |

10 oz. Glass Tropicana (United States) (In model 368)

| Wide Column Set-Up 1 deep | |
|----------------------------|---|
| 1 - 000,004,09x.x6 | spring shim, right |
| 1 - 000,004,08x.x6 | spring shim, left |
| 4 - 801,805,12x.x1 | flat grey shim (2 each side behind spring shim) |
| 1 - 801,806,39x.x1 | cam, blue vending |
| 1 - 801,806,40x.x1 | cam, gold adjustable |
| Cam setting #1 or 2 notch | es. |
| Rear spacer set in hole #9 | |
| | |

Narrow Column Set-Up 1 deep No shims required. 1 - 276,012,30x.x3 rod and spring assembly 1 - 901,901,95x.x1 yellow tubing Place rod with yellow tube in hole "B" of rotor. Cam setting #4 or 1 notch. Rear spacer set in hole #9. SET DISCHARGE MEMBER AND CLOSURE STRIP FOR BOTTLES.

12 oz NR Coca-Cola "Contour" Glass Bottle (United States) (In models 276, 368, 432 & 440)

Wide Column Set-Up 1 deep

 4 - 801,805,12x.x1
 flat grey shim (2 each side)

 1 - 801,806,39x.x1
 cam, blue vending

 1 - 801,806,40x.x1
 cam, gold adjustable

 Cam setting #1 or 2 notches.
 Rear spacer set in hole #17.

Narrow Column Set-Up 1 deep

No shims required.2 - 267,012,30x.x3rod and spring assembly1 - 901,902,00x.x1red tubingPlace one rod in hole "A" of rotor.Place one rod with red tube in hole "C" of rotor.Cam setting #4 or 1 notch.Rear spacer set in hole #17.SET DISCHARGE MEMBER AND CLOSURE STRIP FOR BOTTLES.

12 oz. NR Nantucket Necktars Juice Bottle (United States) (In models 276 & 368)

Wide Column Set-Up 1 deep

 2 - 801,804,96x.x1
 flat black shim (1 each side)

 1 - 801,806,39x.x1
 cam, blue vending

 1 - 801,806,40x.x1
 cam, gold adjustable

 Cam setting #1 or 2 notches.
 Rear spacer set in hole #10.

Narrow Column Set-Up Not recommended. SET DISCHARGE MEMBER AND CLOSURE STRIP FOR BOTTLES.

250 ml NR Coke Glass Bottle (Uruguay) (In models 276 & 300) 250 ml NR Sprite Glass Bottle (Uruguay) (In models 276 & 300)

Wide Column Set-Up 1 deep

 1 - 270,010,20x.x3
 w/a wall left

 1 - 270,010,30x.x3
 w/a wall right

 1 - 801,806,39x.x1
 cam, blue vending

 1 - 801,806,40x.x1
 cam, gold adjustable

 Cam setting #1 or 2 notches.
 Rear spacer set in hole #12.

Narrow Column Set-Up 1 deep

1 - 801,805,23x.x1bottle shim, right (close to bottle)4 - 901,303,63x.x1flat shim, long (close to wall)1 - 267,012,30x.x3rod and spring assembly1 - 493,070,50x.x3rear spacer assembly with bottle retainer extensionPlace rod in hole "C" front and hole "A" in rear of rotor.Cam setting #4 or 1 notch.Rear spacer set in hole #12.SET DISCHARGE MEMBER AND CLOSURE STRIP FOR BOTTLES.

250 ml NR Fanta Glass Bottle (Uruguay) (In models 276 & 300)

Wide Column Set-Up 1 deep

| 1 1 | | |
|------------------------------|----------------------|--|
| 1 - 270,010,20x.x3 | w/a wall left | |
| 1 - 270,010,30x.x3 | w/a wall right | |
| 1 - 801,806,39x.x1 | cam, blue vending | |
| 1 - 801,806,40x.x1 | cam, gold adjustable | |
| Cam setting #1 or 2 notches. | | |
| Rear spacer set in hole #12. | | |
| | | |

Narrow Column Set-Up 1 deep

| 1 - 801,805,23 | 3x.x1 | bottle shim, right (close to bottle) |
|---|-------|---|
| 4 - 901,303,63 | 3x.x1 | flat shim, long (close to wall) |
| 1 - 267,012,30 |)x.x3 | rod and spring assembly |
| 1 - 901,901,90 |)x.x1 | white tubing |
| 1 - 493,070,50 |)x.x3 | rear spacer assembly with bottle retainer extension |
| Place rod with white tube, front in hole "C" and rear in hole "A" of rotor. | | |
| Cam setting #4 or 1 notch. | | |
| Rear spacer set in hole #12. | | |
| | | |

SET DISCHARGE MEMBER AND CLOSURE STRIP FOR BOTTLES.