



3330 Dixie-Narco Blvd.
Williston, SC 29853
www.dixienarco.com

M092.1 Energy Star Evaporator Fan Motor Sub-Assembly 501E/600E HVV

Revised 06/10/09



Models affected: All Pepsi HVV (HT3) 600E/501E-Model Venders Produced Beginning Production Run 6757DZ and higher.

Reason: To Provide Step-by-Step Instructions for the removal of the current Evaporator Fan Shroud Assembly and installation of the new Energy Star Evaporator Fan Shroud Assembly. This kit is designed to be installed in venders with factory installed Environmental Control Kits and SBC (Single Board Controller) E Model electronics. Additional information for the Environmental Control Assembly (631,004,00x.x4) can be obtained from Instruction E013.x or contact your Dixie-Narco Representative or the Technical Service Department.

Safety Precautions!

- Please read these instructions in their entirety before proceeding.
- Ensure that the Electrical Power is disconnected from the Vending Machine by removing Vending Machine Power Cord from the wall outlet.
- Remember use caution working with the Refrigeration Unit parts. These parts may have sharp edges and corners.
- Failure to comply with these instructions could result in injury or electrical shock, which can be serious or fatal.

Order Kit: 646,070,10x.x3 Energy Star Evaporator Fan Motor, Wide Sub-Assembly

Kit contents:


Part Number	Description	Quantity in Kit
609,050,73x.x3	Housing, Right Evap. 58mm ECM Motor	1
609,050,74x.x3	Housing, Left Evap. 58mm ECM Motor	1
609,050,71x.x3	Shroud, Fan Evap. Wide EBM Papst	1
609,050,72x.x3	Cover, Evap. Top Wide 58mm ECM Motor	1
800,902,51x.x1	Clamp, P Nylon Cable 5/16" White	1
803,301,57x.x1	Foam, Poly Strip Self Adhesive	2
803,301,56x.x1	Foam, Poly Strip, Wide	1
804,501,54x.x1	Assy., Fan Evap. EBM Papst 1850RPM	1
804,926,92x.x1	Choke, Capacitor & MOV 120V	1
804,926,73x.x1	Harness, ECM Evap. Fan Choke Ext.	1
800,304,31x.x1	Screw, 8-18x½ Philip Pan AB Machine	10
900,901,80x.x1	Clamp, P Nylon Cable 1/2"	1
801,100,81x.x1	Rivet, 1/8 Steel Zinc Plate	6
901,901,00x.x1	Tie, Wire 4" Length	1
901,901,36x.x1	Bushing, Evap. Fan Shroud 1" #2210	1
800,304,28x.x1	Screw, 10-32x1¼ Phil Pan Type F	1
M092.x	Energy Star Evap. Fan Motor Sub-Assy. HVV E Model	1

Introduction: Read the entire instructions and verify all the parts of the kit are included before beginning installation. **IMPORTANT:** This kit is designed to work with SBC E Model Control Board (refer to Tech Bulletin 520 for kit numbers if needed) and the Environmental Control Assembly (see Installation Instructions E013.1 for kit number if needed). If your vender does not include these parts, they need to be installed prior to installing the Energy Star Evaporator Fan Motor Sub-Assembly. If you have any questions, contact your Dixie-Narco Representative or the Technical Service Department before proceeding with the installation.


Tools Needed: Phillips Screwdriver with #2 nib– preferably with 6” shaft
Note: A drill with a magnetic holder will make installation of the kit faster.

Energy Star Evaporator Fan Motor, Wide Sub-Assembly Installation:


1. Disconnect the Main Power Cord from the Wall Outlet.
2. Open the Main Door.
3. Remove the two (2) Screws from the Can/Bottle Chute (See Figure 1).
4. Remove the Can/Bottle Chute from the vender.



5. Locate and disconnect the Evaporator Fan Leads (See Figure 2) from the Main Power Harness.




6. Remove the two (2) fasteners from the Top Evaporator Cover (Figure 3 marked "A") and discard them.
7. Remove the Screw securing the P-Clamps (Figure 3 marked "B") and discard the screws and clamps.
8. Remove the fasteners securing the Evaporator (Figure 3 marked "C") to the Fan Shroud.




9. Carefully move the Evaporator Counter-clockwise as shown in Figure 4. ***Be careful not to kink or bend the refrigeration tubing.***
10. Remove the Screws, identified with arrows marked "A" in Figure 4, from the Evaporator Fan Shroud.

11. Carefully remove the Cold Control Sensor, marked “B” in Figure 4, from the Evaporator Fan Shroud. Important: ***Do not kink or bend Cold Control Sensor Lead.***
12. Remove and discard the old Evaporator Fan Shroud.
13. Remove the Screws, marked “C” in Figure 4, securing the Evaporator Fans.
14. Remove and discard the old Evaporator Fans.



15. Lay the new Evaporator Fan Shroud Assembly on a flat surface as shown in Figure 5.



16. Align the male fan connectors to the female fan connectors of the Main Power Harness. When connecting, align the ribbed wires with ribbed wires and smooth wires with smooth wires. Ensure nothing is in the fan blade area.
17. Plug the end of the Power Cord to the Wall Outlet to test the fan assembly. ***Warning: Do not touch Fan Blades while they are moving.***
18. The fan will start slowly and increase speed slowly until it reaches peak speed.

19. Disconnect the end of the Main Power Cord from the Wall Outlet.
20. Disconnect the male fan connectors from the female fan connectors of the Main Power Harness.
21. Clean all dirt and debris from the bottom of the Cabinet Tank.
22. Carefully maneuver the new Evaporator Fan Shroud Assembly in the rear of the Cabinet Tank.
23. Center the Evaporator Fan Shroud Assembly in the back of the Cabinet so it rests on the bottom of the Tank.
24. With a drill, secure the Evaporator Fan Shroud Assembly with five (5) new Self Drilling Screws (800,304,18x.x1). See "A" in Figure 6.




Figure 6

25. Carefully move the Evaporator clockwise to the surfaces of the new Evaporator Fan Shroud.
26. Align the holes of the Evaporator to the holes of the Evaporator Fan Shroud Brackets.
27. Secure with four (4) new Screws (800,304,31x.x1) that were removed in Step #8.
28. Carefully insert the Cold Control Sensor in the slot in the shroud. See Figure 8.
29. Align the male fan connectors to the female fan connectors of the Main Power Harness shown in Figure 7. When connecting, align ribbed wires with ribbed wires, smooth with smooth.




Figure 7





Figure 8

30. If the Can/Bottle Chute is metal proceed to Step# 31. For Plastic Can/Bottle Chutes follow instructions below:
- Remove existing gasket from the Can/Bottle Chute.
 - Clean or remove dirt, glue, or syrup from the Can/Bottle Chute surface.
 - Remove protective film from the new Gasket.
 - Install new Gasket on the plastic Can/Bottle Chute as shown below in Figure 9.



- Lay the new Top Evaporator Cover (609,050,72x.x3) on top of the new Evaporator Fan Shroud.
- Secure with (2) Tinnerman Clips (800,903,49x.x1), one on each side.
- Install the Can/Bottle Chute.
- Install and secure the Can/Bottle Chute with the two (2) Screws removed in Step #3.
- Plug in the Main Power Cord to the wall outlet and test new fan for proper operation.